


NSK

MEGATORQUE® MOTOR SYSTEM

User's Manual

(ESA23 Driver Unit System)



M-E099SA0C2-053

NSK Ltd.

Document Number: C20053-06

Limited Warranty

NSK Ltd. warrants its products to be free from defects in material and/or workmanship which NSK Ltd. is notified of in writing within, which comes first, one (1) year of shipment or 2400 total operation hours. NSK Ltd., at its option, and with transportation charges prepaid by the claimant, will repair or replace any product which has been proved to the satisfaction of NSK Ltd. to have a defect in material and/or workmanship.

This warranty is the sole and exclusive remedy available, and under no circumstances shall NSK Ltd. be liable for any consequential damages, loss of profits and/or personal injury as a result of claim arising under this limited warranty. NSK Ltd. makes no other warranty express or implied, and disclaims any warranties for fitness for a particular purpose or merchantability.

Copyright 1996-2000 by NSK Ltd., Tokyo, Japan

All rights reserved.

No part of this publication may be reproduced in any form or by any means without permission in writing from NSK Ltd.

NSK Ltd. reserves the right to make changes to any products herein to improve reliability, function or design without prior notice and without any obligation.

NSK Ltd. does not assume any liability arising out of the application or use of any product described herein; neither does it convey any licence under its present patent nor the rights of others.

Patents issued and patents pending.

“MEGATORQUE” is a registered trademark of NSK Ltd. in Japan and that of NSK Corp. in the United States of America.

MEGATORQUE®
MOTOR
SYSTEM

User's
Manual

NSK Ltd.

(Blank Page)

About This Manual

- Before operating the Megatorque Motor System, this manual should be read thoroughly. The Megatorque Motor System is a unique device, so 'common sense' based upon experience with servo motor may not apply here. Careful consideration of the mechanical design as described in "Chapter 6" is especially important.
- This manual describes the interface, function and operation of the Megatorque Motor System. This manual provides information on the ESA23 Driver Unit. If your model is not ESA23, contact NSK for respective information.

Technical Information

- For technical assistance and sales information, please contact your local NSK office. A list of NSK offices is provided in the back cover.

Terminology

It will be necessary to be familiar with some terms used in this document.

b.p.s.	bit per second; the unit of communication speed.
CCW	Motor rotating direction, counterclockwise; seen from the outside of rotor.
closed	logic output state; output current will flow.
CW	Motor rotating direction, clockwise; seen from the outside of rotor.
Driver Unit	means Megatorque Motor System's driver unit when capitalized.
Home Return	a built-in sequence program for setting the home position.
kpps	kilo pulse per second; the unit of pulse frequency.
Motor	means Megatorque Motor System's motor when capitalized.
OFF (all capital)	logic input state; input will see an open circuit.
ON (all capital)	logic input state; there will be a current path to the common DC supply.
open	logic output state; no output current
P control	proportional-only control; the servo algorithm.
PI control	proportional and integral control; the servo algorithm.
position gain	shorter name for position loop proportional gain
position integrator frequency	shorter name for position loop integrator cutoff frequency
position loop control mode	a control mode within the position control loop; P control or PI control available.
Programmable Indexer	Driver Unit's built-in indexing ability.
pulse train	a series of pulses used as a position command.
quadrature output	two pulse train outputs with 90° phase difference.
rated stall torque	the rated torque available at zero speed.
rated torque	the torque not to exceed the maximum Motor winding temperature.
r.p.s.	revolution per second; the unit of velocity.
r.p.s./s	rps per second; the unit of acceleration.
servo-lock	one typical state of servo-on; the Motor provides torque and remains in position.
servo-off	the state where the Driver Unit provides no current to the Motor, and the Motor provides no torque. The Motor rotor can be rotated easily.
servo-on	the state that the Driver Unit is ready to control the Motor, or is controlling the Motor.
shipping set	a parameter setting or a Driver Unit function setting at shipping.
stall torque	the torque available at zero speed.
System	means Megatorque Motor System when capitalized.
velocity gain	shorter name for velocity loop proportional gain
velocity integrator frequency	shorter name for velocity loop integrator cutoff frequency
velocity loop control mode	a control mode within the velocity control loop; P control or PI control available.

Contents

1. Introduction	1-1	5. Connector Specifications	5-1
1.1. Overview	1-1	5.1. CN1 : RS-232C Serial Communication	
1.2. Functional Principle	1-2	Connector	5-1
1.2.1. Motor	1-2	5.1.1. CN1 Pin-Out	5-1
1.2.2. Driver Unit	1-3	5.1.2. CN1 Signal List	5-1
2. Notes to Users	2-1	5.1.3. RS-232C Communication Specifications ----	5-2
2.1. Operational Remarks	2-1	5.1.4. Sample Wiring Diagram	5-2
3. System Outline	3-1	5.2. CN2 : Control I/O Connector	5-3
3.1. System Configuration	3-1	5.2.1. Setting I/O Type	5-4
3.2. Reference Number Configuration	3-2	5.2.2. CN2 Pin-Out	5-5
3.2.1. Motor	3-2	5.2.3. CN2 Signal List	5-6
3.2.2. Driver Unit	3-2	5.2.4. Setting the Polarity (A contact or B contact)	
3.2.3. Cable Set	3-2	of the Input Ports	5-9
3.2.4. Handy Terminal	3-2	5.2.5. Changing I/O Type and Contact Polarity	
3.3. Standard Combination	3-3	at Once	5-11
3.3.1. YS Series Motor	3-3	5.2.6. CN2 Electrical Specifications	5-12
3.3.1.1. Motor and Driver Unit	3-3	5.2.6.1. General Input Signal	5-12
3.3.1.2. Cable Set	3-3	5.2.6.2. Pulse Train Input	5-12
3.3.2. JS Motor Series	3-4	5.2.6.3. General Output Signal	5-12
3.3.2.1. Motor and Driver Unit	3-4	5.2.6.4. Control Output Signal	5-13
3.3.2.2. Cable Set	3-4	5.2.6.5. Position Feedback Output Signal ----	5-13
4. Specifications	4-1	5.2.7. Wiring Diagram (CN2)	5-15
4.1. Motor Specifications	4-1	5.3. CN3 : Resolver Cable Connector	5-20
4.1.1. YS Series Motor	4-1	5.3.1. CN3 Pin-out	5-20
4.1.1.1. Name of Each Parts	4-1	5.3.2. CN3 Signal List	5-20
4.1.1.2. Specifications	4-1	5.4. CN4 : Motor Cable Connector	5-21
4.1.1.3. Dimensions	4-3	5.4.1. CN4 Pin-out	5-21
4.1.2. JS Series Motor	4-7	5.4.2. CN4 Signal List	5-21
4.1.2.1. Name of Each Parts	4-7	5.5. TB : Terminal Block for Power Supply	5-22
4.1.2.2. Specifications	4-7	5.5.1. Terminal List	5-22
4.1.2.3. Dimensions	4-9	5.5.2. Wiring Diagram (TB)	5-22
4.2. Driver Unit	4-11		
4.2.1. Name of Each Parts	4-11		
4.2.2. Specifications	4-12		
4.2.2.1. General Specifications	4-12		
4.2.2.2. Functional Specification	4-13		
4.2.2.3. Driver Unit Dimensions	4-15		
4.3. Cable Set	4-16		
4.3.1. Cable Set for YS Motor	4-16		
4.3.2. Cable Set for JS Motor	4-16		
4.4. Handy Terminals	4-17		
4.4.1. Name of Each Part and Dimensions	4-17		
4.4.2. Specifications	4-18		

6. Installation -----	6-1	9. Operational Function -----	9-1
6.1. Unpacking and Inspection -----	6-1	9.1. General Operation and Function -----	9-1
6.2. Motor and Driver Unit Combination -----	6-2	9.1.1. Servo "ON" -----	9-1
6.3. Motor Mounting -----	6-3	9.1.2. Emergency Stop -----	9-2
6.3.1. Bearing Load -----	6-4	9.1.3. Position Error Counter Clear Input -----	9-2
6.3.1.1. Attaching the Load -----	6-4	9.1.4. Overtravel Limit -----	9-3
6.3.1.2. Bearing Load -----	6-4	9.1.4.1. Hardware Overtravel Limit -----	9-3
6.3.2. Using a "Dummy" Load -----	6-5	9.1.4.2. Software Overtravel Limit -----	9-4
6.3.3. Load Inertia -----	6-7	9.1.5. Alarm Output -----	9-5
6.3.4. Fluctuating Load Inertia -----	6-7	9.1.6. Brake Signal Output -----	9-5
6.3.5. Motor Operating Condition -----	6-7	9.1.7. In-Position Output -----	9-6
6.4. Driver Unit Mounting -----	6-8	9.1.7.1. Output Signal Format -----	9-7
6.4.1. Connecting Power -----	6-9	9.1.7.2. Parameter "IN" -----	9-8
6.4.2. Ground Connection and Wiring -----	6-11	9.1.7.3. Parameter "IS" -----	9-8
6.5. Connecting Motor and Driver Unit -----	6-12	9.1.7.4. "IPOS" Output for Special Occasion ---	9-9
6.6. Power On and Servo On -----	6-13	9.1.8. Position Feedback Signal -----	9-10
6.6.1. Precautions -----	6-13	9.1.9. Monitor Functions -----	9-11
6.6.2. Turning Power On -----	6-13	9.1.9.1. Velocity Monitor -----	9-12
7. Handy Terminal Communication -----	7-1	9.1.9.2. Monitoring the I/O State -----	9-13
7.1. When Power is Turned ON -----	7-1	9.1.9.3. Reading the Present Position -----	9-14
7.2. Command Entry -----	7-2	9.2. To Have More Advanced Operation -----	9-15
7.3. Password -----	7-2	9.2.1. Position Scale -----	9-15
7.4. Cancelling Command -----	7-3	9.2.1.1. Resolution -----	9-15
7.5. Error -----	7-3	9.2.1.2. Direction of Position Scale -----	9-15
7.6. Readout Command -----	7-4	9.2.1.3. Position Scale Types -----	9-16
8. Trial Running and Adjustment -----	8-1	9.2.1.4. Position Scale Reset -----	9-19
8.1. Adjustment Sequence -----	8-1	9.2.1.5. Position Scale Setting Example -----	9-19
8.2. Automatic Tuning (Adjustment Level 1) -----	8-2	9.2.2. Digital Filter -----	9-20
8.2.1. Precautions -----	8-2	9.2.3. Feed Forward Compensation -----	9-21
8.2.2. Initialize Servo Parameters -----	8-3	9.2.4. Integrator Limiter : ILV -----	9-22
8.2.3. Execute Automatic Tuning (Adjustment Level 1) -----	8-4	9.2.5. Dead Band Setting : DBP -----	9-22
8.2.4. Trial Running (Adjustment Level 1) -----	8-5	9.3. RS-232C Communication -----	9-23
8.2.5. Minor Servo Gain Adjustment (Adjustment Level 2) -----	8-7	9.3.1. Communication Specification -----	9-23
8.3. Manual Adjustment -----	8-9	9.3.2. Communication Procedure -----	9-23
8.3.1. Precautions -----	8-9	9.3.2.1. When Power is Turned ON -----	9-23
8.3.2. Adjustment of the Velocity Gain (VG) -----	8-9	9.3.2.2. Command Entry -----	9-24
8.3.3. Adjustment of Velocity Integrat or Frequency -----	8-11	9.3.2.3. Password -----	9-25
8.4. Setting Filters (Adjustment Level 2) -----	8-13	9.3.2.4. Cancelling Command -----	9-26
		9.3.2.5. Error -----	9-27
		9.3.2.6. Readout Command -----	9-28
		9.3.3. Daisy-Chain Communication -----	9-30
		9.3.3.1. Procedure to Set Daisy-chain Communication -----	9-30
		9.3.3.2. Initial Setting -----	9-31
		9.3.3.3. Interfacing -----	9-31
		9.3.3.4. Power On -----	9-33
		9.3.3.5. Operation -----	9-34

10. Positioning -----	10-1
10.1. Preparation -----	10-1
10.1.1. Wiring Check -----	10-1
10.1.2. Procedure -----	10-1
10.2. Home Return -----	10-1
10.2.1. Home Return Parameter List -----	10-4
10.2.2. Adjusting the Home Limit Switch and Home Offset Value -----	10-5
10.2.3. Programming the Home Return Operation (example) -----	10-7
10.3. Programmable Indexer -----	10-8
10.3.1. Programmable Indexer Channel Switching -----	10-9
10.4. Pulse Train Command -----	10-10
10.4.1. Pulse Train Signal Format -----	10-10
10.4.2. Pulse Train Resolution -----	10-11
10.4.3. Input Timing -----	10-14
10.5. RS-232C Position Commands -----	10-15
10.6. Jog Operation -----	10-16
10.7. Programming -----	10-16
10.7.1. Commands and Parameters -----	10-17
10.7.2. Program Editing Command -----	10-20
10.7.3. Inputting a Program -----	10-21
10.7.4. Sample Program -----	10-22
 11. Command and Parameter -----	 11-1
11.1. Command and Parameter List -----	11-1
11.2. Detail of Command and Parameter -----	11-5
<i>AB</i> : I/O polarity -----	11-5
<i>AD</i> : Absolute Positioning, Degree -----	11-6
<i>AN</i> : Axis Number -----	11-6
<i>AR</i> : Absolute Positioning, Resolver -----	11-7
<i>AS</i> : Ask Daisy-Chain Status -----	11-7
<i>AT</i> : Automatic Tuning -----	11-7
<i>AX</i> : Axis Select -----	11-8
<i>AZ</i> : Absolute Zero Position Set -----	11-8
<i>BM</i> : Backspace Mode -----	11-8
<i>CA</i> : Channel Acceleration -----	11-9
<i>CC</i> : Clear Channel -----	11-9
<i>CH</i> : Channel Select -----	11-9
<i>CL</i> : Clear Alarm -----	11-9
<i>CM</i> : Communication Mode -----	11-10
<i>CO</i> : Position Error Counter Over Limit -----	11-10
<i>CR</i> : Circular Resolution -----	11-10

<i>CV</i> : Channel Velocity -----	11-11
<i>DBP</i> : Dead Band -----	11-11
<i>DI</i> : Direction Inversion -----	11-11
<i>FC</i> : Friction Compensation -----	11-12
<i>FD</i> : Feed Back Direction Mode -----	11-12
<i>FF</i> : Feed Forward Gain -----	11-12
<i>FO</i> : Low-pass Filter OFF Velocity -----	11-13
<i>FP</i> : Low-pass Filter, Primary -----	11-13
<i>FR</i> : Feed Back Signal Resolution -----	11-14
<i>FS</i> : Low-pass Filter, Secondary -----	11-14
<i>FW</i> : FIN Width -----	11-15
<i>FZ</i> : Feedback Phase Z Configuration -----	11-15
<i>HA</i> : Home Return Acceleration -----	11-15
<i>HD</i> : Home Return Direction -----	11-16
<i>HO</i> : Home Offset -----	11-16
<i>HS</i> : Home Return Start -----	11-16
<i>HV</i> : Home Return Velocity -----	11-16
<i>HZ</i> : Home Return Near-Zero Velocity -----	11-17
<i>ID</i> : Incremental Positioning, Degree -----	11-17
<i>ILV</i> : Integration Limit -----	11-17
<i>IN</i> : In-position -----	11-17
<i>IO</i> : Input/Output Monitor -----	11-18
<i>IR</i> : Incremental Positioning, Resolver -----	11-18
<i>IS</i> : In-position Stability Timer -----	11-19
<i>JA</i> : Jog Acceleration -----	11-19
<i>JP</i> : Jump -----	11-19
<i>JV</i> : Jog Velocity -----	11-20
<i>LG</i> : Lower Gain -----	11-20
<i>LO</i> : Load Inertia -----	11-20
<i>LR</i> : Low Torque Ripple -----	11-20
<i>MA</i> : Move Acceleration -----	11-21
<i>MI</i> : Read Motor ID -----	11-21
<i>MM</i> : Multi-line Mode -----	11-21
<i>MO</i> : Motor Off -----	11-21
<i>MS</i> : Motor Stop -----	11-22
<i>MT</i> : Factory Use Only -----	11-22
<i>MV</i> : Move Velocity -----	11-22
<i>NP</i> : Notch Filter, Primary (primary notch filter frequency) -----	11-22
<i>NW</i> : Neglect Width -----	11-23
<i>OE</i> : Sequence Option Edit -----	11-23
<i>OG</i> : Origin Set -----	11-23
<i>OL</i> : Overload Limit -----	11-23
<i>OS</i> : Origin Setting Mode -----	11-24
<i>OTP / OTM</i> : Overtravel Limit Switch Position ----	11-24

<i>PA</i> : Phase Adjust -----	11-24	13. Alarms -----	13-1
<i>PC</i> : Pulse Command -----	11-25	13.1. Identifying Alarms -----	13-1
<i>PG</i> : Position Gain -----	11-25	13.1.1. Using LED -----	13-1
<i>PH</i> : Program Home Return -----	11-25	13.1.2. Using TA Command -----	13-2
<i>PS</i> : Position Scale -----	11-26	13.1.3. Alarm List -----	13-3
<i>RC</i> : Rated Current (Software Thermal) -----	11-26	13.2. Detail of Alarm -----	13-4
<i>RI</i> : Factory Use Only -----	11-26	13.2.1. Normal State -----	13-4
<i>RR</i> : Resolver Resolution -----	11-26	13.2.2. Alarms Related to Power Amplifier -----	13-4
<i>SG</i> : Servo Gain -----	11-27	13.2.2.1. Heat Sink Over Temperature -----	13-4
<i>SI</i> : Set Initial Parameters -----	11-27	13.2.2.2. Abnormal Main AC Line Voltage ----	13-5
<i>SM</i> : Servo On Mode -----	11-27	13.2.2.3. Over Current -----	13-5
<i>SP</i> : Start Program -----	11-28	13.2.2.4. Control AC Line Under-Voltage ----	13-6
<i>SV</i> : Servo-on -----	11-28	13.2.3. Alarms Related to Motor -----	13-7
<i>TA</i> : Tell Alarm Status -----	11-28	13.2.3.1. Resolver Circuit Error -----	13-7
<i>TC</i> : Tell Channel Program -----	11-28	13.2.3.2. Software Thermal Sensor -----	13-8
<i>TE</i> : Tell Position Error Counter -----	11-28	13.2.4. Alarms Related to Control -----	13-9
<i>TL</i> : Torque Limit Rate -----	11-29	13.2.4.1. Memory Error -----	13-9
<i>TP</i> : Tell Position -----	11-29	13.2.4.2. EEPROM Error -----	13-9
<i>TR</i> : Tell RDC Position Data -----	11-29	13.2.4.3. CPU Error -----	13-9
<i>TS</i> : Tell Settings -----	11-30	13.2.4.4. Excess Position Error -----	13-10
<i>TY</i> : I/O Type -----	11-30	13.2.4.5. Software Over Travel Limit -----	13-10
<i>VG</i> : Velocity Gain -----	11-31	13.2.4.6. Hardware Over Travel Limit -----	13-11
<i>VI</i> : Velocity Integrator Frequency -----	11-31	13.2.4.7. Emergency Stop -----	13-11
<i>VM</i> : Velocity Integrator Mode -----	11-31	13.2.4.8. Program Error -----	13-11
<i>ZP</i> : Factory Use Only -----	11-31	13.2.4.9. Automatic Tuning Error -----	13-12
<i>ZV</i> : Factory Use Only -----	11-31	14. Troubleshooting -----	14-1
12. Maintenance -----	12-1	14.1. Identifying Problem -----	14-1
12.1. Precautions -----	12-1	14.2. Troubleshooting -----	14-2
12.2. Maintenance Check -----	12-2	14.2.1. Power Trouble -----	14-3
12.2.1. Motor -----	12-2	14.2.2. Motor Trouble -----	14-4
12.2.2. Driver Unit and Cable Set -----	12-2	14.2.3. Command Trouble -----	14-6
12.3. Periodical Replacement of Parts -----	12-3	14.2.4. Terminal Trouble -----	14-10
12.3.1. Motor -----	12-3	Appendix	
12.3.2. Driver Unit -----	12-3	Appendix 1 : Verify Input/Output Signal -----	A-1
12.4. Storing -----	12-3	Appendix 2 : How to Check Motor Condition -----	A-3
12.5. Limited Warranty -----	12-3	Appendix 3 : Initializing Driver Unit -----	A-7
		Appendix 4 : How to replace ESA23 Driver Unit -----	A-9
		Appendix 5 : Regeneration Resistor -----	A-16
		Parameter • Program Setting List -----	A-18

1. Introduction

- This section is to introduce the Megatorque Motor System in general. Some part of explanations are not applicable to all Driver Unit and/or Motors. Refer to respective specifications when ordering.

1.1. Overview

- The Megatorque Motor System is a unique actuator with special capabilities. The System consists of almost all elements that are needed for a complete closed loop servo motor system. With conventional technology these parts must be purchased and installed separately, but the Megatorque Motor System incorporates them all into two units; the Motor and the Driver Unit.

Motor

- The Motor consists of a high torque brushless actuator, a high resolution brushless resolver, and a heavy duty precision NSK bearing. The high torque actuator eliminates the need for gear reduction, while the built-in resolver usually makes feedback components, such as encoders or tachometers unnecessary. Finally the heavy duty bearing eliminates the need for separate mechanical support since the Motor case can very often support the load directly in most applications.

Driver Unit

- The Driver Unit consists of a power amplifier, resolver interface, and digital motor control circuits. The Driver Unit provides everything that is needed to control the Motor's torque, velocity, or position; for interface to any standard motor position controller or to act as a stand-alone digital motion control system with its built-in zero backlash position control capability.

High Speed

- The Driver Unit features higher speeds than ever before... with less torque drop-off at the intermediate speeds. As a result, smaller Motors may be used for high speed indexing applications when the torque requirement is primarily for acceleration.

Ease of Use

- The digital control makes the System easy to use, for more than one reason :
 - The circuit parameters can be changed by an RS-232C command, rather than by attempting to adjust a multi-turn pot or changing capacitor values. The parameter changes are not only a breeze to make, but they are measurable and repeatable, so that every System behaves the same way, every time.
 - The versatile design means that significant changes in the Driver Unit function can be made with little or no hardware changes. Numerous options are available at little or no extra cost.
 - Stand-alone capability means that the Megatorque Motor System can be operated in position control mode without the need for a separate CNC or position controller. Built-in software for flexible motion control means that the complexity of the electronic system can be cut in half. This reduction of the controls circuitry to one component saves time and money.

Universal Interface

- Because of the extreme versatility of the Driver Unit design, a wide variety of interface methods are possible. The Megatorque Motor System can be interfaced to virtually any control system. It is very easy to control the Megatorque Motor System with a CNC, a servo motor controller, a robot controller, or an indexing controller. You can operate the Megatorque Motor System with a stepper motor controller or with a personal computer or dumb terminal. Versatile position control can even be implemented with a single switch!

High Repeatability

- With zero backlash, direct drive and a 614 400count/rev resolver, the Megatorque Motor System offers repeatability as high as approximately 2.1", or approximately 0.00058°. With no mechanical contact or moving parts other than the bearing, this repeatability will never degrade.

Easy to Maintain

- With all adjustments, indicators, and test points accessible by the front panel, service or maintenance is easy. LED (light-emitting diode) and logic diagnostic outputs identify the nature of any error condition quickly and accurately.
- Together, the Motor and the Driver Unit provide the ultimate in simplicity for precise and reliable motion control.

Single Component Servo System

- A conventional brushless servo system requires at least several separate components which must be selected and packaged together, often at great expense. Furthermore, many of these components introduce problems of their own to degrade the entire system's performance. Gears and flexible couplings, for example, introduce mechanical irregularities such as windup, backlash, and mechanical inaccuracy. The same functions can be accomplished with just two components using the Megatorque Motor System; all of the circuits needed to implement a position or velocity control servo loop (digital motion controller, servo compensation, brushless commutation logic, power amplifier) are included in the Driver Unit, and all of the mechanical components that were required (motor, couplings, gears, bearings, tachometer and encoder) are either replaced or made unnecessary by the Motor.

Gearless Advantage

- There are many advantages to the gearless servo system. One advantage is to eliminate backlash, the angular play due to looseness of fit between two mating gears. The direct drive inherently eliminates backlash, so that repeatability is limited only by the resolution of the position sensor. The direct drive permits direct coupling of the Motor and the load, so that troublesome flexible couplings are not required. This permits tighter, more direct control of the load. The Megatorque Motor System has a very high torque to inertia ratio, so that very high acceleration rates can be achieved. When the load inertia is low, the Motor can accelerate a load as much as 10 times faster than comparable high performance servo systems using gears. The performance advantages of the Megatorque Motor System are demonstrated by many of the new class of the direct drive robots which have established repeatability and speed records in the robot industry and are the performance standards against which other robot systems are compared.

1.2. Functional Principle

1.2.1. Motor

- By virtue of its unique design, the Megatorque Motor System is capable of producing extremely high torque at low speeds suitable for direct drive applications. Furthermore, it can produce these torque levels without using an undue amount of power, so it can sustain these torque levels indefinitely under most conditions without overheating.

Motor Construction

- This Motor is of dual stator construction with rotor between them. Each stator is constructed of laminated iron sheets with eighteen poles stamped into the laminations. Each pole has one set of copper windings around it which provide the magnetic field. The windings are wired in series so that there are three sets of windings seen by the power amplifier, each winding consisting of six (four for 0408 type Motor) pole pieces. The face of each pole piece has many teeth, resembling a stepping motor (in appearance, not in function). The teeth serve to focus the magnetic energy into a series of discrete points along the pole face. In total there are hundreds of these points around the full turn of the Motor. (The number depends upon the Motor size.) The rotor is a thin cylindrical ring, constructed of the same iron laminations and with the same tooth structure, but without windings or pole pieces. The rotor serves to conduct the magnetic field from the inner stator across the rotor to the adjacent pole piece on the outer stator, and back again. The rotor teeth also serve to focus the magnetic field into discrete points around the circumference of the rotor, and the combined effect of these points of focused magnetic field around both the stators and the rotor act like electronic gear reduction, multiplying the torque hundreds of times while reducing the speed by the same amount.

Brushless Microprocessor Commutation

- For each full electrical cycle of commutation, the Motor rotates through one magnetic cycle which is the angular distance between adjacent teeth. In most Motor sizes, there are 150 electrical cycles per Motor revolution; some smaller sizes such as 0408 type have 100 cycles per revolution. The commutation of the Motor phases is performed without brushes by direct control of a high speed microprocessor in the Driver Unit, and it is the phase relationship of the three Motor phases, not current polarity, that determine the direction of rotation.

Why No Magnets?

- No magnets are used in the Motor, since the Motor uses the teeth to focus the magnetic field. This contributes to the robustness of the Motor and to the high torque levels which are produced. Since demagnetization is not a worry, it is possible to develop high magnetic flux densities within the Motor which would weaken permanent magnets. Unlike motors which use permanent magnets, the Megatorque Motors do not weaken with age.

1.2.2. Driver Unit

- All of the circuits that are needed to operate the Megatorque Motor System in position, velocity or torque control modes are contained in the Driver Unit. These circuit functions are :
 - Digital microprocessor
 - Power amplifier
 - Resolver interface
- The resolver interface and the digital microprocessor are on the control board, a single printed circuit board which is accessible to you on the right side of the Driver Unit.

Digital Microprocessor Subsystem

- The digital microprocessor subsystem is a part of the control board. All analog signals are converted to digital form, and the 16-bit microprocessor on the control board handles all Motor control functions in the digital domain. Since analog circuits are eliminated, there are no pots to adjust, no operational amplifier circuits to tweak, and no soldering or component changes are required. The digital microprocessor receives commands from the outside world in either analog or digital form, depending upon the selected interface option. The command parameter can be position, velocity, or torque. The digital microprocessor compares the commanded variable with the actual measured value of the controlled variable, and makes small corrections continuously so that the Motor always obeys the command. The digital microprocessor receives its feedback information from the Motor's built-in resolver via the resolver interface circuit subsystem. Digital filters may be applied which alter Motor behavior to improve the repeatability, or to eliminate mechanical resonances :
 - A digital integrating function may be selected which improves the repeatability of the Motor by making it respond to very small command signals. With the integrator, the Motor can provide zero position error even under full load torque.
 - A digital notch filter may be employed to cut out certain frequencies from the Motor response so that mechanical resonances will not cause the Motor to oscillate. If the Motor is attached to a load which has a strong natural frequency of oscillation, the Motor can be made insensitive to it merely by setting the notch frequency to the same frequency. A 100Hz resonance can be eliminated, for instance, simply by initializing the Driver Unit with the RS-232C command "NP100." Up to two independent digital notch filters can be employed.
 - A digital low-pass filter may be employed to modify Motor frequency response and make the Motor smooth and quiet. Again, the low-pass filter is implemented digitally, and setting up the filter frequency is as simple as asking for it. There are two independent low-pass filters available.

Brushless Microprocessor Commutation

- The digital microprocessor uses the digitized position information obtained from the resolver interface to determine when to apply current to the Motor phases, and how much. The amount of current applied to each Motor phase is determined by a mathematical function that takes into account the torque command level, the Motor position, and the Motor velocity. These factors are taken into account to compensate for the Motor non-linearities and to produce a smooth output torque.

Power Amplifier Subsystem

- The Motor windings are driven by a current regulated unipolar switching power amplifier that delivers the current designated by the commutation logic circuits to each of the Motor phases. The power amplifier monitors its internal voltages to protect itself from damage. If the AC line is too high or too low, the power amplifier will disable itself and activate alarm indicators. If the amplifier's internal DC bus voltage is too high as a result of Motor regeneration, the monitor circuits will switch on a power resistor to dissipate some of that excess energy. If the power amplifier temperature is too high, it will activate an alarm signal. For any of the alarm conditions, the type of the alarm is communicated back to the digital microprocessor, which activates the alarm condition indicators to identify the specific nature of the alarm condition.

Resolver Interface Subsystem

- Position and velocity feedback signals are provided by the resolver interface circuit. This circuit provides the excitation signal to the resolver, and receives the three phase resolver analog signals. These signals are decoded by the resolver-to-digital converter (RDC) to produce digital cyclic absolute position and velocity feedback signals. The cyclic absolute position data is used by the commutation circuits and is used internally to maintain absolute position data.

2. Notes to Users

- This manual describes the interface, function and operation of ESA23 Driver Unit .
- Especially when you use Megatorque Motor System for the first time, please read thoroughly this manual.
- For the explanations of Motor , only standard series (YS and JS Motor) are described in this manual. If your Motor is not one of these, please refer to respective specifications or applicable document.
- Special-order ESA23 Driver Units are made in compliance with this manual. When the Unit design is prescribed separately in another specification document, priority is given to the specification.
- Following notice is added to the clause of safety precautions to get your attention.
 - Danger** : Might cause serious injuries.
 - Warning** : Might result in injurie.
 - Caution** : Might damage the equipment (machine) and/or the load (work).

2.1. Operational Remarks

- Pay special attention to the following precautions when installing, adjusting, checking and trouble-shooting Megatorque Motor System.

Caution : *Make sure that Motor size and maximum torque number of Motor and Driver Unit are the same. Refer to “3.2. Reference Number Configuration” for the details.*

- *Parameters of Driver Unit are set to Motor size and maximum torque before shipped.*
- *If the numbers are different, the system does not operate properly.*


Caution : *Do not make Cable Set shorter or longer. Changing the length may worsen Motor and Driver Unit performance.*

Caution : *Do not disassemble the Motor since it is precisely adjusted and assembled. If disassembled, it may cause abnormalities such as deterioration in accuracy and rigidity as well as noise.*

Caution : *Do not touch Driver Unit. Touching the Driver Unit just after the power is turned off may cause electric shock.*

- *Driver Unit has high capacity conductors in its internal circuits and there is high residual voltage for few minutes after the power is turned off.*
- *Do not detach Driver Unit cover unless it is necessary. When the cover has to be removed, follow procedures described bellow.*
 - ① *Turn off the control and main power. If only main power has been turned on, turn the control power on for more than 5 seconds, then turn off both powers. Neglecting this procedure is very dangerous. The procedure is to reduce residual voltage of capacitors.*
 - ② *Wait for 5 minutes or more, then remove the cover.*

Figure 2-1



Caution : Using an optional regenerative dump resistor shall be considered for heavy duty operation .

- When Motor is decelerating, rotational energy is dissipated by internal dump resistor. Excessive rotational energy causes very high regeneration of Motor, the dump resistor is overheated, then the alarms goes off and Motor stops.
- Gentler deceleration rate or decreasing duty cycle prevents overheating of the dump resistor.
- If heavy duty operation is still needed, installation of optional "Regenerative Dump Resistor" is recommended. Refer to "Appendix 5" for the details.

Danger : Never apply any water or oil to Driver Unit. Take appropriate measures to protect Driver Unit from water, oil, slag , dust and corrosive gas.


Warning : Do not conduct an "Isolation test" or "Megger test" on Driver Unit. It may damage the internal circuit.

Caution : Be sure to adjust the servo parameters according to conditions of actual use. In most cases, the Direct Drive Motor System cannot exhibit its full performance unless the shipping set of these parameters are not altered. Refer to "8. Trial Running and Adjustment" for the details about parameter setting.

3. System Outline

3.1. System Configuration

Figure 3-1




Components Supplied by NSK

- NSK can supply the ESA23 Driver Unit, Megatorque Motor, Cable Set (resolver cable and Motor cable) and Handy Terminal. Users are requested to acquire other equipment and wiring from other sources.

3.2. Reference Number Configuration


3.2.1. Motor

Figure 3-2




3.2.2. Driver Unit

Figure 3-3




3.2.3. Cable Set

Figure 3-4



3.2.4. Handy Terminal

Figure 3-5



3.3. Standard Combination

- This section describes “Standard Combination” in which the Motor and ESA23 Driver Unit are interchangeable.
- Make sure to select right combination of each parts when ordering.

3.3.1. YS Series Motor

3.3.1.1. Motor and Driver Unit

Table 3-1

Motor Reference No.	ESA Driver Unit Reference No.	Power Supply Voltage
M-YS2005FN001	M-ESA-Y2005C23	AC100V
	M-ESA-Y2005A23	AC200V
M-YS2020FN001	M-ESA-Y2020C23	AC100V
	M-ESA-Y2020A23	AC200V
M-YS3008FN001	M-ESA-Y3008C23	AC100V
	M-ESA-Y3008A23	AC200V
M-YS3040FN501	M-ESA-Y3040C23	AC100V
	M-ESA-Y3040A23	AC200V
M-YS4080FN001	M-ESA-Y4080C23	AC100V
	M-ESA-Y4080A23	AC200V
M-YS5120FN001	M-ESA-Y5120C23	AC100V
	M-ESA-Y5120A23	AC200V
M-YS5240FN001	M-ESA-Y5240A23	AC200V

3.3.1.2. Cable Set

Table 3-2

Reference No.	Length
M-C002SS31	2m
M-C004SS31	4m
M-C008SS31	8m
M-C015SS31	15m
M-C030SS31	30m

3.3.2. JS Motor Series

3.3.2.1. Motor and Driver Unit

Table 3-3

Motor Reference No.	ESA Driver Unit Reference No.	Power Supply Voltage
M-JS0002FN001	M-ESA-J0002C23	AC100V
	M-ESA-J0002A23	AC200V
M-JS1003FN001	M-ESA-J1003C23	AC100V
	M-ESA-J1003A23	AC200V
M-JS2006FN001	M-ESA-J2006C23	AC100V
	M-ESA-J2006A23	AC200V
M-JS2014FN001	M-ESA-J2014C23	AC100V
	M-ESA-J2014A23	AC200V

3.3.2.2. Cable Set

Table 3-4

Reference No.	Length
M-C002SS26	2m
M-C004SS26	4m
M-C008SS26	8m
M-C015SS26	15m
M-C030SS26	30m


4. Specifications

4.1. Motor Specifications

4.1.1. YS Series Motor

4.1.1.1. Name of Each Parts

Figure 4-1



4.1.1.2. Specifications

Table 4-1 : YS Motor Specifications

Items		Motor				
		M-YS2020FN001	M-YS3040FN501	M-YS4080FN001	M-YS5120FN001	M-YS5240FN001
Maximum torque	(N•m)	20	40	80	120	240
Maximum current/phase	(A)	6				
Allowable Axial load	(N)	3700	4500	9500	19600	19600
Allowable moment load	(N•m)	60	80	160	400	400
Axial rigidity	(mm/N)	4.0×10^{-6}	3.0×10^{-6}	1.4×10^{-6}	1.0×10^{-6}	1.0×10^{-6}
Moment rigidity ^(Note a)	(rad/N•m)	3.5×10^{-6}	2.5×10^{-6}	1.5×10^{-6}	3.0×10^{-7}	3.0×10^{-7}
Maximum stall torque	(N•m)	15	35	70	105	198
Rotor moment of inertia	(kg•m ²)	0.0070	0.020	0.065	0.212	0.255
Mass	(kg)	10	16	29	55	95
Operating conditions		Temperature: 0 ~ 40°C; Humidity: 20 ~ 80% Use indoors in a dust-free location.				
Maximum speed	[s ⁻¹ (r.p.s.)]	3				
Resolver resolution	(p/rev)	614400				
Resolver accuracy	(sec)	±75 ^(Note b)				
Resolver repeatability	(sec)	±2.1				
Compatible Driver Units	200VAC	M-ESA-Y2020T23	M-ESA-Y3040T23	M-ESA-Y4080T23	M-ESA-Y5120T23	M-ESA-Y5240T23
	100VAC	M-ESA-Y2020V23	M-ESA-Y3040V23	M-ESA-Y4080V23	M-ESA-Y5120V23	-

Note a: These values assume that the Motor is mounted on a rigid base.

Note b: When used with as ESA23 Driver Unit (interchangeable).

- YS Series Megatorque Motors can be run on either 100V/110V or 200V/220V AC.

- SI unit System :
 $1 \text{ N} = 0.102 \text{ kgf} = 0.225 \text{ l b}$
 $1 \text{ N}\cdot\text{m} = 0.102 \text{ kgf}\cdot\text{m} = 0.738 \text{ ft}\cdot\text{l b}$

Table 4-2 : YS Flat Type Motor Specifications

Motor		M-YS2005FN001	M-YS3008FN001
Item			
Maximum torque	(N·m)	5	8
Maximum current/phase	(A)	1.5	
Allowable axial load	(N)	3700	4500
Allowable moment load	(N·m)	60	80
Axial rigidity	(mm/N)	4.0×10^{-6}	3.0×10^{-6}
Moment rigidity ^(Note a)	(rad/N·m)	3.5×10^{-6}	2.5×10^{-6}
Maximum stall torque	(N·m)	4	5
Rotor moment of inertia	(Kg·m ²)	0.003	0.006
Mass	(Kg)	4	6
Operating condition		Temperature: 0~40°C, Humidity: 20~80 % , Use indoors in a dust-free condition.	
Maximum speed	[S ⁻¹ (rps)]	3	2/3 ^(Note b)
Resolver resolution	(p/rev)	614400	
Positioning accuracy	(sec)	150	
Resolver repeatability	(sec)	± 2.1	
Compatible Driver Unit	200VAC	M-ESA-Y2005T23	M-ESA-Y3008T23
	100VAC	M-ESA-Y2005V23	M-ESA-Y3008V23

Note a : These values assume that the Motor is mounted on a rigid base.

Note b : Varies with power supply. 2 : 100VAC, 3 : 200VAC


● **How to Calculate Axial and Moment Load**

Caution : ● Do not apply excessive load to the Motor.

An excessive load more than specified in Table 4-1 may result in premature Motor failure.

● Followings show how to calculate the loads.

Figure 4-2 : How to calculate loads



4.1.1.3. Dimensions

Figure 4-3 : M-YS2020FN001




Figure 4-4 : M-YS3040FN501




Figure 4-5 : M-YS4080FN001




Figure 4-6 : M-YS5120FN001




Figure 4-7 : M-YS5240FN001




Figure 4-8: M-YS2005FN001






Figure 4-9 : M-YS3008FN001



4.1.2. JS Series Motor

4.1.2.1. Name of Each Parts

Figure 4-10



4.1.2.2. Specifications

Table 4-3 : JS Series Specifications

Motor		M-JS0002FN001	M-JS1003FN001	M-JS2006FN001	M-JS2014FN001
Items					
Motor Out Side Diameter	(mm)	75	100	130	
Maximum torque	(N•m)	2	3	6	14
Maximum current/phase	(A)	1.5		3	
Allowable Axial load	(N)	950	1960	3700	
Allowable moment load	(N•m)	10	40	60	
Axial rigidity	(mm/N)	1.6×10^{-5}	1.4×10^{-5}	7.4×10^{-6}	
Moment rigidity ^(Note a)	(rad/N•m)	2.8×10^{-5}	1.4×10^{-5}	4.8×10^{-6}	
Maximum stall torque	(N•m)	1.4	2.1	4.2	9.8
Rotor moment of inertia	(kg•m ²)	0.002	0.00375	0.00525	0.0095
Mass	(kg)	2.4	3.2	4.8	5.5
Operating conditions		Temperature: 0 ~ 40°C; Humidity: 20 ~ 80% Indoor use in a dust-free condition.			
Maximum speed	[S ⁻¹ (r.p.s.)]	4.5	3		
Resolver resolution	(p/rev)	409600	614400		
Resolver accuracy ^(Note b)	(sec)	±150	±75		
Resolver repeatability	(sec)	±3.2	±2.1		
Compatible Driver Units		M-ESA-J0002xxx	M-ESA-JS1003xxx	M-ESA-J2006xxx	M-ESA-J2014xxx

Note a: These values assume that the Motor is mounted on a rigid base.

Note b: When used with as ESA Driver Unit (interchangeable).

- JS Series Megatorque Motors can be run on either 100V/110V or 200V/220V AC.


- SI unit System :
 $1 \text{ N} = 0.102 \text{ kgf} = 0.225 \text{ l b}$
 $1 \text{ N}\cdot\text{m} = 0.102 \text{ kgf}\cdot\text{m} = 0.738 \text{ ft}\cdot\text{l b}$

● **How to Calculate Axial and Moment Load**

Caution : ● Do not apply excessive load to the Motor.
An excessive load more than specified in Table 4-3 may result in premature Motor failure.

● Followings show how to calculate the loads.

Figure 4-11



4.1.2.3. Dimensions

- NSK Ltd. supplies mounting brackets to allow JS Motors to be mounted by the top or side.

Figure 4-12: M-JS0002FN001




Figure 4-13: M-JS1003FN001




Figure 4-14: M-JS2006FN001






Figure 4-15: M-JS2014FN001



4.2. Driver Unit

4.2.1. Name of Each Parts

Figure 4-16



4.2.2. Specifications

4.2.2.1. General Specifications

● Control mode

- Fully closed loop, P · PI position control

● Operation mode

- Pulse train position command
- Programmable control
- RS-232C communication command
- Return Home Position
- Jog

● Power supply

(1) **AC200V/220V±10%**

Table 4-4 : Power supply capacity

Driver Unit Reference No.	Max. Capacity (Except surge current)	
	Main power	Control power
M-ESA-Y2005A23	0.5 kVA	50 VA
M-ESA-Y2020A23	1.0 kVA	
M-ESA-Y3008A23	0.6 kVA	
M-ESA-Y3040A23	1.2 kVA	
M-ESA-Y4080A23	1.4 kVA	
M-ESA-Y5120A23	1.5 kVA	
M-ESA-Y5240A23	2 kVA	
M-ESA-J0002A23	0.7 kVA	
M-ESA-J1003A23	0.7 kVA	
M-ESA-J2006A23	0.9 kVA	
M-ESA-J2014A23	1.0 kVA	

* For the power supply capacities of the RS and SS series Motors, refer to their specification documents.

Table 4-5

		Main power (TYP)	Control power (TYP)
Surge current		140A	14A
Leakage current	(40 ^{HZ} ~ 1 ^{KHZ})	5 mA r.m.s	
	(~ 1 ^{MHZ})	35 mA r.m.s	

(2) **AC100V/110V±10%**

Table 4-6 : Power supply capacity

Driver Unit Reference No.	Max. Capacity (Except surge current)	
	Main power	Control power
M-ESA-Y2005C23	0.3 kVA	50 VA
M-ESA-Y2020C23	0.7 kVA	
M-ESA-Y3008C23	0.3 kVA	
M-ESA-Y3040C23	0.9 kVA	
M-ESA-Y4080C23	1.0 kVA	
M-ESA-Y5120C23	1.0 kVA	
M-ESA-J0002C23	0.4 kVA	
M-ESA-J1003C23	0.4 kVA	
M-ESA-J2006C23	0.7 kVA	
M-ESA-J2014C23	0.7 kVA	

* For the power supply capacities of the RS and SS series Motors, refer to their specification documents.

Table 4-7

		Main power (TYP)	Control power (TYP)
Surge current		14A	7A
Leakage current	(40 ^{Hz} ~ 1 ^{KHz})	3 mA r.m.s	
	(~ 1 ^{MHz})	20 mA r.m.s	

● **Specification**

Table 4-8

Vibration resistance		0.5 G (Conform to JIS-C0911)
Line noise resistance		1500 V 1 μS (By noise simulator)
Mass		2.5kg
Environmental condition	In operation	Temperature 0~50 °C, Humidity 20~90% (no condensation)
	In storage	Temperature -20~70 °C, Indoor condition

4.2.2.2. Functional Specification

● **Position control specification**

- Maximum input pulse frequency : 614.4 kpps
- Input pulse format: CW & CCW, step & direction, øA and øB quadrature pulse
- The input pulse format can be selected by the parameter “PC”.

● **Resolver resolution**

Table 4-9

Resolver resolution Motor type	Automatic resolution switching or 12-bit setting	10-bit setting
YS, JS1, JS2, RS	614400 pulses/rev.	153600 pulses/rev.
SS	491520 pulses/rev.	122880 pulses/rev.
AS, BS, JS0	409600 pulses/rev.	102400 pulses/rev.

* Automatic resolution switching, 12-bit setting and 10-bit setting can be selected by the parameter “RP”.

● Maximum velocity

Table 4-10

Resolver resolution Motor type	12 bit setting	Automatic resolution switching or 10 bit setting
YS, JS1, JS2, RS	1 r.p.s.	3 r.p.s.
SS	1.25 r.p.s.	3.75 r.p.s.
AS, BS, JS0	1.5 r.p.s.	4.5 r.p.s.

* Automatic resolution switching, 12-bit setting and 10-bit setting can be selected by the parameter “RR”.

● Position feedback output θA , θB , θZ (MSB)

- Output signal format: Line driver

Table 4-11 : Resolution

Resolver resolution Motor type	θA , θB		θZ (MSB)
	12-bit setting	10-bit setting	
YS, JS1, JS2, RS	153600 pulses/rev.	38400 pulses/rev.	150 pulses/rev.
SS	122880 pulses/rev.	30720 pulses/rev.	120 pulses/rev.
AS, BS, JS0	102400 pulses/rev.	21600 pulses/rev.	100 pulses/rev.

* 12-bit setting and 10-bit setting are selected by the RR parameter.

● Control I/O

Table 4-12

Input signals	<ul style="list-style-type: none"> ● Emergency stop ● Run move 	<ul style="list-style-type: none"> ● Servo-on ● Programmable indexer channel switching (max. 16 channels) *1 	<ul style="list-style-type: none"> ● Home limit switch
Output signals	<ul style="list-style-type: none"> ● Driver Unit Ready 	<ul style="list-style-type: none"> ● in-position 	<ul style="list-style-type: none"> ● brake*2

*1: Some of the signals used for channel switching can be changed to the Jog operation or overtravel limit signals by setting the TY parameter. In this case, however, maximum of 4 channels are allowed for the programmable indexer channel switching signals.

*2: The brake output signal is for controlling the brake. It cannot be used to supply power to an electromagnetic brake.

● Alarms

- Excess position error
- Control circuit error
- Heat sink over-temperature
- Control power line under-voltage
- Software thermal limit
- Resolver circuit error
- Main AC line under/over-voltage
- Overtravel limit
- Over-current

● Monitor outputs

- Analog velocity monitor
- RS-232C communication monitor : Present position, Alarm status, Servo parameters, etc.

● Communication


- Asynchronous RS-232C communication, Baud rate: 9600 b.p.s.

● Data back up

- Backed up by EEPROM
- 100000 times for resetting / deleting parameters.

4.2.2.3. Driver Unit Dimensions

Figure 4-17




4.3. Cable Set

- This section shows Cable Set for YS and JS series Motor.


4.3.1. Cable Set for YS Motor

Figure 4-18



4.3.2. Cable Set for JS Motor

Figure 4-19




- Refer to the respective specifications for SS, RS series Motors.
- Refer to “3.3. Standard Combination” for the reference number and cable length.

4.4. Handy Terminals

- FHT11 Handy Terminal is an easy to use hand held terminal with an RS-232C communication interface for Megatorque Motor System Driver Unit. FHT11 terminal connects directly to the CN1 connector on the ESA23 Driver Unit.

4.4.1. Name of Each Part and Dimensions

Figure 4-20



Note (1) SHIFT: Press the code key while holding "SHIFT" key. (Small characters)

(2) BS : When correcting logged-in mistakes, press "BS" key.

(3) SP : Press "SP" key to have space between characters

(4) ENT : Press "ENT" key at the end of the command or the parameter setting.

4.4.2. Specifications

Table 4-13

Item	Specification	
Power source voltage	DC 5V \pm 5%	
Power consumption	200 mW	
Environment	Temperature	<ul style="list-style-type: none"> ● Operating : 0~50°C ● Storage : -10~+65°C
	Humidity	35~85% (Non condensing)
RS-232C Interface	Data code	ASCII code
	Communication speed	9600 b.p.s
	Data bit	8 bit
	Stop bit	2 bit
	Start bit	1 bit
	Parity check	None
Mass	250g (exclude cable)	

5. Connector Specifications

5.1. CN1 : RS-232C Serial Communication Connector

- NSK’s Handy Terminal FHT11 (sold separately) can be used as an RS-232C terminal.
- If another RS-232C terminal is used, refer to “Chapter 5.2” for the wiring.


Table 5-1

Driver Unit connector	Japan Aviation Electronics Industry, Limited DELC-J9SAF-13L6
Mating connector type (user device side)	Japan Aviation Electronics Industry, Limited DE-9P-N (to be prepared by the user)*
Mating connector shell type (user device side)	Japan Aviation Electronics Industry, Limited DE-C1-J6 (to be prepared by the user)*

* These connectors are not necessary if NSK Handy Terminal FHT11 is used.

5.1.1. CN1 Pin-Out

Figure 5-1 : CN1 Pin-out



5.1.2. CN1 Signal List

Table 5-2 : CN1 Signal List

Pin	Signal Name	I/O	Function
1	TXD	Output	Transmit data
2	CTS	Input	Clear to send
3	RXD	Input	Receive data
4	DSR	Input	Data set ready
5	DTR	Output	Data terminal ready
6	SG	–	Digital signal ground
7	RTS	Output	Ready to send
8	+5V	Output	Never connect
9	FG	–	Frame ground (shield)

5.1.3. RS-232C Communication Specifications

Table 5-3 : RS-232C Communication Specification


Item	Specification
Transmission	Asynchronous, full duplex
Communication speed	9600 b.p.s.
Word length	8 bit
Stop bit	2 bit
Parity	No
Character code	ASCII code
Communication procedure	<ul style="list-style-type: none"> ● X-On/Off Protocol: No ● RTS/CTS Control: Yes

5.1.4. Sample Wiring Diagram

- Connect the ESA23 Driver Unit with the controller (e.g., personal computer) in accordance with its RS-232C control signal specification.

● RTS Control / CTS Monitoring Active (standard wiring)


Figure 5-2



● **RTS Control / CTS Monitoring Inactive**

Important : When wired as shown below, always confirm the echo-back from Driver Unit or send the data slowly. With this wiring, Driver Unit may not accept the whole data when data is sent at high speed and large amount.

Figure 5-3



5.2. CN2 : Control I/O Connector

- The table below shows connector types for the CN2.

Table 5-4

Connector type (Driver Unit side)	Japan Aviation Electronics Industry, Limited	DBLC-J25SAF-13L6
Mating connector type (user device side)	Japan Aviation Electronics Industry, Limited	DE-25P-N (supplied with the Driver Unit)
Mating connector shell type (user device side)	Japan Aviation Electronics Industry, Limited	DB-C2-J9 (supplied with the Driver Unit)

● **Wiring Precautions**

- Use the shielded cable for CN2 and a twisted pair cables for the pulse train input and position feedback signals.
- These cables should be laid in an independent duct separate from the power line.
- Connect one end of the cable shield to the frame ground (FG).

Caution : Check for wiring mistake of external power supply polarity and shorting between connector pins.

5.2.1. Setting I/O Type

- The Input / Output of the CN2 connector are 5 types as described below.
- The users can select one type by setting parameter “TY”.
- This parameter is set to Type 1 before shipped.


Table 5-5 : CN2

Type 1 (TY1)	• Pulse train input • 16 channels
Type 2 (TY2)	• Pulse train input • 4 channels • Jog
Type 3 (TY3)	• Pulse train input • 4 channels • Overtravel limit
Type 4 (TY4)	• Pulse train input • Clear input • Home return start • Overtravel limit
Type 7 (TY7)	• Pulse train input • Overtravel limit • Jog

- The password input is necessary when setting the I/O connector type.
- Inputting the parameter TY sets the polarity of all input ports to A contact. (When “TY” is the same as the previously set type, the polarity is not reset but maintained.)
- The change of the input polarity is allowed only with the four signals below.
 - EMST : Emergency stop
 - HLS : Home limit switch
 - OTP : + direction overtravel limit switch (CW direction)
 - OTM : – direction overtravel limit switch (CCW direction)
 - Refer to “Chapter 5.2.4” for the details.

● Setting Example

- Set the I/O signals of Connector CN2 to Type 2.




(Refer to “5.2.4. Setting the Polarity” for more details.)

5.2.2. CN2 Pin-Out

- The input /output signals of the CN2 connector are in the following 5 types, and the user can select one type by setting the TY parameter. This parameter is set to Type 1 before shipment.

Figure 5-4



5.2.3. CN2 Signal List

Table 5-6 : Type 1

Pin	Signal Name	I/O	Function
1	COM	Output	Output COMMON
2	DRDY-	Output	Driver Unit ready (-)
3	BRK	Output	Brake control signal (normally closed)
4	CHZ*	Output	Position feedback ϕZ /digital position data MSB*
5	CHB	Output	Position feedback ϕB
6	CHA	Output	Position feedback ϕA
7	CCWP+	Input	Counter clockwise pulse (+)
8	CWP+	Input	Clockwise pulse (+)
9	PRG0	Input	Programmable move bit 0
10	PRG2	Input	Programmable move bit 2
11	HLS	Input	Home limit switch
12	EMST	Input	Emergency stop
13	DC24	Input	24 VDC external supply
14	IPOS	Output	In-position
15	DRDY+	Output	Driver Unit ready (+)
16	SGND	—	Signal ground
17	$\overline{\text{CHZ}}^*$	Output	Position feedback $\overline{\phi Z}$ /digital position data *MSB*
18	$\overline{\text{CHB}}^*$	Output	Position feedback $\overline{\phi B}$
19	$\overline{\text{CHA}}^*$	Output	Position feedback $\overline{\phi A}$
20	CCWP-	Input	Counter clockwise pulse (-)
21	CWP-	Input	Clockwise pulse (-)
22	PRG1	Input	Programmable move bit 1
23	PRG3	Input	Programmable move bit 3
24	RUN	Input	Run move
25	SVON	Input	Servo-on

Table 5-7 : Type 2

Pin	Signal Name	I/O	Function
1	COM	Output	Output COMMON
2	DRDY-	Output	Driver Unit ready (-)
3	BRK	Output	Brake control signal (normally closed)
4	CHZ*	Output	Position feedback ϕZ /digital position data MSB*
5	CHB	Output	Position feedback ϕB
6	CHA	Output	Position feedback ϕA
7	CCWP+	Input	Counter clockwise pulse (+)
8	CWP+	Input	Clockwise pulse (+)
9	JOG	Input	Jog
10	PRG2	Input	Programmable move bit 2
11	HLS	Input	Home limit switch
12	EMST	Input	Emergency stop
13	DC24	Input	24 VDC external supply
14	IPOS	Output	In-position
15	DRDY+	Output	Driver Unit ready (+)
16	SGND	—	Signal ground
17	$\overline{\text{CHZ}}^*$	Output	Position feedback $\overline{\phi Z}$ /digital position data *MSB*
18	$\overline{\text{CHB}}^*$	Output	Position feedback $\overline{\phi B}$
19	$\overline{\text{CHA}}^*$	Output	Position feedback $\overline{\phi A}$
20	CCWP-	Input	Counter clockwise pulse (-)
21	CWP-	Input	Clockwise pulse (-)
22	DIR	Input	Direction
23	PRG3	Input	Programmable move bit 3
24	RUN	Input	Run move
25	SVON	Input	Servo-on

Table 5-8 : Type 3

Pin	Signal Name	I/O	Function
1	COM	Output	Output COMMON
2	DRDY-	Output	Driver Unit ready (-)
3	BRK	Output	Brake control signal (normally closed)
4	CHZ*	Output	Position feedback ϕZ /digital position data MSB*
5	CHB	Output	Position feedback ϕB
6	CHA	Output	Position feedback ϕA
7	CCWP+	Input	Counter clockwise pulse (+)
8	CWP+	Input	Clockwise pulse (+)
9	OTP	Input	+ direction overtravel limit switch (CW direction)
10	PRG2	Input	Programmable move bit 2
11	HLS	Input	Home limit switch
12	EMST	Input	Emergency stop
13	DC24	Input	24 VDC external supply
14	IPOS	Output	In-position
15	DRDY+	Output	Driver Unit ready (+)
16	SGND	—	Signal ground
17	$\overline{\text{CHZ}}^*$	Output	Position feedback $\overline{\phi Z}$ / digital position data *MSB*
18	$\overline{\text{CHB}}^*$	Output	Position feedback $\overline{\phi B}$
19	$\overline{\text{CHA}}^*$	Output	Position feedback $\overline{\phi A}$
20	CCWP-	Input	Counter clockwise pulse (-)
21	CWP-	Input	Clockwise pulse (-)
22	OTM	Input	- direction overtravel limit switch (CCW direction)
23	PRG3	Input	Programmable move bit 3
24	RUN	Input	Run move
25	SVON	Input	Servo-on

Table 5-9 : Type 4

Pin	Signal Name	I/O	Function
1	COM	Output	Output COMMON
2	DRDY-	Output	Driver Unit ready (-)
3	BRK	Output	Brake control signal (normally closed)
4	CHZ*	Output	Position feedback ϕZ /digital position data MSB*
5	CHB	Output	Position feedback ϕB
6	CHA	Output	Position feedback ϕA
7	CCWP+	Input	Counter clockwise pulse (+)
8	CWP+	Input	Clockwise pulse (+)
9	OTP	Input	+ direction overtravel limit switch (CW direction)
10	CLR	Input	Clear
11	HLS	Input	Home limit switch
12	EMST	Input	Emergency stop
13	DC24	Input	24 VDC external supply
14	IPOS	Output	In-position
15	DRDY+	Output	Driver Unit ready (+)
16	SGND	—	Signal ground
17	$\overline{\text{CHZ}}^*$	Output	Position feedback $\overline{\phi Z}$ /digital position data *MSB*
18	$\overline{\text{CHB}}^*$	Output	Position feedback $\overline{\phi B}$
19	$\overline{\text{CHA}}^*$	Output	Position feedback $\overline{\phi A}$
20	CCWP-	Input	Counter clockwise pulse (-)
21	CWP-	Input	Clockwise pulse (-)
22	OTM	Input	- direction overtravel limit switch (CCW direction)
23	HOS	Input	Home return start
24	RUN	Input	Positioning start
25	SVON	Input	Servo-on

Table 5-10 : Type 7 (TY7)

Pin	Signal Name	I/O	Function
1	COM	Output	Output COMMON
2	DRDY-	Output	Driver Unit ready (-)
3	BRK	Output	Brake control signal (normally closed)
4	CHZ*	Output	Position feedback ϕZ /digital position data MSB*
5	CHB	Output	Position feedback ϕB
6	CHA	Output	Position feedback ϕA
7	CCWP+	Input	Counter clockwise pulse (+)
8	CWP+	Input	Clockwise pulse (+)
9	OTP	Input	+ direction overtravel limit switch (CW direction)
10	JOG	Input	Jog
11	HLS	Input	Home limit switch
12	EMST	Input	Emergency stop
13	DC24	Input	24 VDC external supply
14	IPOS	Output	In-position
15	DRDY+	Output	Driver Unit ready (+)
16	SGND	—	Signal ground
17	$\overline{\text{CHZ}}^*$	Output	Position feedback $\overline{\phi Z}$ /digital position data *MSB*
18	$\overline{\text{CHB}}^*$	Output	Position feedback $\overline{\phi B}$
19	$\overline{\text{CHA}}^*$	Output	Position feedback $\overline{\phi A}$
20	CCWP-	Input	Counter clockwise pulse (-)
21	CWP-	Input	Clockwise pulse (-)
22	OTM	Input	- direction overtravel limit switch (CCW direction)
23	DIR	Input	Jog direction select
24	RUN	Input	Positioning start
25	SVON	Input	Servo-on

* The FZ parameter (RS232C communication) is used to select between the position feedback signal ϕZ and the digital position signal MSB.

Caution : For the Input / Output signals of a special-order Driver Unit, refer to its specification document.

5.2.4. Setting the Polarity (A contact or B contact) of the Input Ports

● Setting Example

- Set the polarity of the EMST (emergency stop) input port to B contact.

(1) **SHIFT** **0 ?**
 Press the code key while holding down the SHIFT key.

(2) **A** **B** **ENT**
 Input the command to read the setting of the AB parameter. Check the present polarity setting (in this example, all the input ports are set to A contact).

(3) **/** **N** **S** **K** **SP**
O **N** **ENT**
 Input the password.
 The password acknowledgment message appears on the display.

(4) **A** **B** **X** **1 #** **X** **X**
X **X** **X** **X** **ENT**
 The second bit following AB represents EMST. Set this bit to "1", and the other bits to "X" (no change).

The diagram illustrates the process of setting the polarity of the EMST input port to B contact through four steps. Each step shows the keys pressed and the resulting display output. Step 1: Pressing SHIFT and 0 with a question mark results in a display showing a question mark. Step 2: Pressing A, B, and ENT results in a display showing the current setting ABX0X0XXXX. Step 3: Pressing /, N, S, K, SP, O, N, and ENT results in a display showing the password acknowledgment message /NSK ON NSK ON. Step 4: Pressing A, B, X, 1 with a hash, X, X, X, X, and ENT results in a display showing the updated setting ABX1XXXXXX.

Refer to "Explanation" in page 5-10 for the meaning of display.

● **Explanation**

- Set the polarity of the input port with the AB parameter.
- The password is necessary before inputting the AB parameter.
- The change of the input port polarity is allowed only with the EMST, HLS, OTP and OTM signals.
- Data is in the bit map format. Refer to Table 5-11 for the correspondence between bits and signals.
(EMST is the second bit from the left, HLS the fourth bit from the left, OTM the seventh bit from the left and OTP the eighth bit from the left.)

Table 5-11

Pin No.	25	12	24	11	23	10	22	09
Bit No.	7	6	5	4	3	2	1	0
TY1	SVON	EMST	RUN	HLS	PRG3	PRG2	PRG1	PRG0
TY2	SVON	EMST	RUN	HLS	PRG3	PRG2	DIR	JOG
TY3	SVON	EMST	RUN	HLS	PRG3	PRG2	OTM	OTP
TY4	SVON	EMST	RUN	HLS	HOS	CLR	OTM	OTP
TY7	SVON	EMST	RUN	HLS	DIR	JOG	OTM	OTP

- Meaning of data
 - 0 = A Contact setting (normally open)
 - 1 = B Contact setting (normally close)
 - X = During input : Indicates no change.
 - On display (data read command) : Indicates that change of polarity is inhibited (the port is set to A contact).
- All the bits of the AB parameter are set to A contact before shipment.

5.2.5. Changing I/O Type and Contact Polarity at Once

● Setting Example

- Set the I/O type to TY3 (SVON, EMST, RUN, HLS, PRG3, PRG2, OTP, OTM). Set EMST, OTP and OTM to B contact, and the rest to A contact.

(1)

Input the password.
The password acknowledgment message appears on the display.

➔

```

:
:/NSK ON
NSK ON
:
_
    
```

(2)

Input the IF command to display the present I/O type and the polarity of the input ports.
Then the data input prompt appears to wait for the input.

➔

```

:IF
TY1
ABX0X0XXXX
?
_
    
```

(3)

Set the I/O type to type 3 (TY3).
The message indicates that the polarity of all the input ports is set to A contact.

➔

```

ABX0X0XXXX
?TY3
ABX0X0XX00
?
_
    
```

(4)

Set EMST (second bit following AB), OTM (seventh bit), and OTP (eighth bit) to "1" and the remaining bits to "X" (no change).

➔

```

?TY3
ABX0X0XX00
?ABX1XXXX11
:
_
    
```

● Explanation

- The IF command is the auxiliary command used to set the TY and AB parameters at once.
- The password is necessary before inputting the IF command.

5.2.6. CN2 Electrical Specifications


5.2.6.1. General Input Signal

Applied Inputs : SVON, EMST, PRG0~3, RUN, HOS, HLS, JOG, DIR, OTP, OTM, CLR

Table 5-12

Item	Specification
Input voltage	24 VDC \pm 10%
Input impedance	3.3 k Ω
Maximum current	10 mA (per input)

Figure 5-5



* The polarity of DC24V external supply may be reversed.


5.2.6.2. Pulse Train Input

Applied Inputs : CWP+, CWP-, CCW+, CCW-

Table 5-13

Item	Specification
Input voltage	5 VDC \pm 10%
Input impedance	240 Ω
Maximum current	25 mA

Figure 5-6




5.2.6.3. General Output Signal

Applied Outputs : BRK, IPOS

Table 5-14

Item	Specification
Maximum load capacity	24 VDC/100 mA
Maximum saturated voltage	2 V

Figure 5-7




5.2.6.4. Control Output Signal

Applied Outputs : DRDY+, DRDY-

Table 5-15

Item	Specification
Maximum load capacity	24 VDC/100 mA
Maximum saturated voltage	2 V

Figure 5-8




5.2.6.5. Position Feedback Output Signal

Applied Outputs : CHA, CHB, CHZ, *CHA, *CHB, *CHZ

Table 5-16

Item	Specification	
Output format	Line driver (CHA, CHB, *CHA, *CHB) Line driver or open collector (CHZ, *CHZ) (Can be selected by Jumper 1. Refer to next page for the setting.)	
Output device	Texas instruments AM26LS31	
Recommended receiving device	Texas instruments AM26L32 or equivalent	
Maximum collector current	100mA	For open collector
Maximum open collector voltage	24V	
Saturated voltage	1V or less	

Figure 5-9



● **How to Set Jumper (JP1)**

- Jumper (JP1) is for selecting output format of θZ position feedback signal.
- Jumper is inside of the Driver Unit. When setting Jumper, remove the side cover of the Driver Unit. Follow the procedure in Appendix 4 : How to replace ESA23 Driver Unit.
- Figure 5-10 indicates the Jumper location.

Figure 5-10





Table 5-17 : Jumper setting.

Setting	θZ output format
LD-Out short	Line driver (Shipping set)
OC-Out short	Open collector

5.2.7. Wiring Diagram (CN2)

● Wiring Example 1 : Type 1.


Figure 5-11 : 16 channels selection



- Note :
- (1) Home Return
 - For example, program the HS command in CH0.
 - Immediately after turning on the power, select CH0 and turn on the RUN input to execute the home return operation.
 - (2) Pulse train operation
 - Add the connections of the CWP_{\pm} and $CCWP_{\pm}$ signals if you want to use the pulse train operation.
- Caution** : (3) When using an inductive switch (e.g., relay), be sure to insert a surge killer circuit.
- (4) When the user installs a sensor as the home limit switch, connect its output directly with the input port of the Driver Unit, not via the controller.

● **Connection Example 2 : Type 2.**


Figure 5-12 : Jog operation and 4 channels selection



- Note :
- (1) Home Return
 - For example, program the HS command in CH0.
 - Immediately after turning on the power, select CH0 and turn on the RUN input to execute the home return operation.
 - (2) Pulse train operation
 - Add the connections of the CWP± and CCWP± signals if you want to use the pulse train operation.
- Caution** : (3) When using an inductive switch (e.g., relay), be sure to insert a surge killer circuit.
- (4) When the user installs a sensor as the home limit switch, connect its output directly with the input port of the Driver Unit, not via the controller.

● **Connection Example 3 : Type 3.**

Figure 5-13 : Rotation limit range setting and 4 channels selection



Note :

(1) Home Return

- For example, program the HS command in CH0.
- Immediately after turning on the power, select CH0 and turn on the RUN input to execute the home return operation.

(2) Pulse train operation


- Add the connections of the CWP± and CCWP± signals if you want to use the pulse train operation.

Caution : (3) When using an inductive switch (e.g., relay), be sure to insert a surge killer circuit.

(4) When the user installs sensors as the home limit switch, + direction overtravel limit switch and - direction overtravel limit switch, connect sensor outputs directly with the input ports of the Driver Unit, not via the controller.

● **Connection Example 4 : Type 4.**

Figure 5-14 : Pulse train, rotation limit and home return start clear input




Caution : (1) When using an inductive switch (e.g., relay), be sure to insert a surge killer circuit.

(2) When the user installs sensors as the home limit switch, + direction overtravel limit switch and - direction overtravel limit switch, connect sensor outputs directly with the input ports of the Driver Unit, not via the controller.

● **Wiring Example 5 : Type 7.**

Figure 5-15 : Pulse train, rotation limit and home return start clear input



- Note :
- (1) Home Return
 - For example, program the HS command in CH0.
 - Immediately after turning on the power, select CH0 and turn on the RUN input to execute the home return operation.
 - (2) Pulse train operation
 - Add the connections of the CWP± and CCWP± signals if you want to use the pulse train operation.

Caution : (3) When using an inductive switch (e.g., relay), be sure to insert a surge killer circuit.

(4) When the user installs a sensor as the home limit switch, connect its output directly with the input port of the Driver Unit, not via the controller.

5.3. CN3 : Resolver Cable Connector

- Since the resolver cable supplied with the Megatorque Motor System should always be used, you need only plug the resolver cable connector into CN3. Knowledge of the pin assignment or signal names is not necessary. This section is offered for reference.

Caution : • Do not change the length of the cable.

- Do not use other connector between the Resolver cable and CN3.

Danger : • Never connect pins not listed below.


- Insert the connector being careful of its orientation. Tighten the screws for fastening the connector so that it will not be loosened by shock.
- Never insert/remove the CN3 connector with the Driver Unit power turned on.

Table 5-18

Driver Unit connector	Japan Aviation Electronics Industry, Limited DALC-J15SAF-13L9
Mating connector type	Japan Aviation Electronics Industry, Limited DA-15P-N
Mating connector shell type	Japan Aviation Electronics Industry, Limited DA-C1-J10

5.3.1. CN3 Pin-out

Figure 5-16 : CN3 Pin-out



5.3.2. CN3 Signal List

Table 5-19 : CN3 Signal List

Pin	Signal Name	Function
8	RE A	Resolver signal phase A
7	RE B	Resolver signal phase B
15	RE C	Resolver signal phase C
4	COMMON	Common
10	FG	Frame ground

5.4. CN4 : Motor Cable Connector

- Since the Motor cable supplied with the Megatorque Motor System should always be used, you need only plug the Motor cable connector into CN4. Knowledge of the pin assignment or signal name is not necessary. This section is offered for reference.

Caution : • Do not change the cable length.

- Do not use other connector between the Motor cable and CN4.

Danger : • Insert the connector being careful of its orientation. The connector is of a self-locking type. Insert the connector until it bottoms; otherwise, it will not lock.


- Never insert/remove the CN4 connector with the Driver Unit power turned on.
- A high voltage is applied to this connector after the power is turned on. Be very careful not to cause short-circuit.

Table 5-20

Driver Unit connector	AMP 172039-1
Mating connector type (user device side)	AMP 172495-1 (to be prepared by the user)
Mating connector shell type (user device side)	AMP 172774-1 (to be prepared by the user)

5.4.1. CN4 Pin-out

Figure 5-17 : CN4 Pin-out



5.4.2. CN4 Signal List

Table 5-21 : Signal Name and Function

Pin	Signal Name	Function
1	A+	Motor winding phase A (+)
2	A-	Motor winding phase A (-)
3	B+	Motor winding phase B (+)
4	B-	Motor winding phase B (-)
5	C+	Motor winding phase C (+)
6	C-	Motor winding phase C (-)
7	E	Motor grounding wire

5.5. TB : Terminal Block for Power Supply


5.5.1. Terminal List

Table 5-22 : Terminal Labels and Functions

Terminal Label	Function
CONT	Control power input
MAIN	Main power input
FGND	Frame ground

5.5.2. Wiring Diagram (TB)

Figure 5-18 : Wiring diagram (TB)




- Refer to “6.4.1. Connecting Power” for the wiring precautions.
- For the power supply cable, use a heat-resistant vinyl cable of 2 mm² or more thick.
- Wire the power supply cables separately from the signal cables. Never bind them together or route them in the same duct.
- To prevent external noise, insert an isolation transformer and a noise filter between the power supply and the Driver Unit.

Additional Notes

- When the power is turned on, an inrush current will occur because the capacitive load is connected to the power supply. If circuit breaker and fuse are affected by the inrush current, install the inrush current control circuit to the power supply circuit as shown in the figures below.
- The inrush current varies with the source impedance. When an inrush current is over 300A, the Driver Unit may be damaged. We recommend to install the circuit to protect the Driver Unit.
- When the power is turned on in the inrush current control circuit, the current is being charged initially to a capacitor of the Driver Unit through R1 and R2 resistors for 9 ~ 20 msec, which is required time to close the contact of magnetic switch, and thus, the inrush current is reduced.
- When a magnet switch CR1 is failed (failed to contact), the resistor R1 may overheat and result in a fire. We recommend to take the countermeasures by installing the thermal sensor circuit to turn main power off.
- Example of circuit to reduce inrush current

Figure 5-19



- Resistor R1 • R2 : Cement resistor 15 ~ 20W 10Ω
or ceramic resistor (Koa Ltd. HPC5 or equivalent)
- Magnetic switch CR1 : Contact point capacity 200V 20A or more
(SC-03 type or equivalent , recommended manufacturer; Fuji Electric)


- The optional “inrush current control circuit” is available. (Reference number M-FZ077)

[Checking Inrush Current]

Follow the instructions below to check the maximum inrush current.

- (1) Set the current probe to phase S of the Driver Unit power supply.
(Response frequency of the monitor shall be 10 K Hz or more.)
- (2) Inrush current shall be checked at the timing of A or B of the voltage wave form between phase R and S of power supply.
- (3) The maximum current reading of phase R just after the power supply is turned on is the inrush current.

Figure 5-20



- When the dump resistor overheat alarm (Overheat 3: OH3) is detected, make sure to turn off the main power to protect the internal dump resistor from burning due to the defective Driver Unit or abnormal source voltage.

6. Installation

6.1. Unpacking and Inspection

- Make sure that you have received following units.
 - ① Megatorque Motor
 - ② Driver Unit (CN2 mating connector and 2 fuse holders are included)
 - ③ Cable Set (Motor and Resolver cable unit)
- Inspect shipping containers for damage as an indication that the System might have been mishandled in transit.
- When unpacking the System, save all packing materials for reuse in the event that the System needs to be shipped or require service.

Danger : *Inspect the Motor and the Driver Unit very closely for damage which might have occurred in shipment. The Driver Unit is particularly fragile and should be inspected for warped or bent sheet metal, broken standoffs, and loose or damage electric components.*

- Rotate Motor's rotor by hand, without AC power. The rotation should be smooth.
- If you suspect damage, do not apply power to the System, since this can cause immediate catastrophic damage to the Driver Unit. Furthermore, a damaged system could be a potential electric shock hazard. Notify the carrier immediately, and call your NSK representative.


6.2. Motor and Driver Unit Combination

Caution : Make sure that the combination of Motor and Driver Unit conforms to your requirements.

Check and record the Motor and Driver Unit reference number and serial number.

- Standard Combination
 - The Motor series, size and maximum torque numbers in both Motor and Driver Unit reference number must be same.
- Special-order Combination
 - Refer to the respective specification document.
- Even when the Motor and Driver Unit are in an interchangeable combination, check reference number in same manner as Standard combination. If the combination is not interchangeable, serial numbers of Motor and Driver Unit must be same.
- A nameplate is attached to individual Motor and Driver Unit. Configuration of each plates are shown in Figure 6-1. Refer to “3.2. Reference Number Configuration” for the more details.

Figure 6-1



6.3. Motor Mounting


- The high acceleration/deceleration characteristic of a direct drive mechanism requires the system to have high mechanical rigidity. Therefore, it is essential to maximize rigidity of the Motor and the load system.
- The Motor will work best if all of the elements have a natural frequency between them of at least 100 Hz, and preferably more than 200 Hz.

Warning : • Fully fasten all the mounting holes (mounting tap holes) of the Motor.

- Fasten a load using all of the tapped holes of the rotor.
- Eliminate play between the load and the rotor.
- Eliminate play in the mechanism as much as possible.
- Tightening torque of the fixing bolts are specified as follow.

Warning : The flatness of the surface where the Motor is mounted affects Motor operation. About less than 0.02 mm flatness is needed for smooth operation. When mounting, minimize the looseness between Motor and the mounting surface.

Figure 6-2 : Motor Mounting



6.3.1. Bearing Load

6.3.1.1. Attaching the Load

- The load must be attached to the rotor flange using the threaded mounting holes in the rotor. All of the bolts should be used, and they should all be tightened to prevent slippage.

6.3.1.2. Bearing Load

- The Motor uses a heavy duty bearing that can support most loads directly.

Table 6-1 : Maximum Bearing Load (YS Series)

	YS2	YS3	YS4	YS5
Axial Load Capacity (N)	3700	4500	9500	19600
Moment Load Capacity (N•m)	60	80	160	400
Distance between Rotor Surface and Bearing Center* (mm)	46.5	52.5	54.0	58.5

* Use these values when calculating the moment load.

Refer to “4.1. Motor Specifications” for the details.

Caution : When vibratory axial load is applied, the equivalent allowable load of the Motor shall be less than 2 ~ 3 times of the vibratory load.

Table 6-2 : Maximum Bearing Load (JS Series)

	JS0	JS1	JS2
Axial Load Capacity (N)	950	1960	3700
Moment Load Capacity (N•m)	10	40	60
Distance between Rotor Surface and Bearing Center* (mm)	31	32	30

* Use these values when calculating the moment load.


Refer to “4.1. Motor Specifications” for the details.

6.3.2. Using a “Dummy” Load

- When you have to drive the Motor with a low-stiffness load, you may not be able to avail of the merits of the Megatorque Motor System. In some cases, a little rearrangement of mechanical design may help. Try to add some load (“dummy” inertia) to the rotor directly.


● **Example 1 : Load is connected using keyway.**

Figure 6-3 : Using Keyway




● **Example 2 : Load is directly attached but the shaft diameter is too small. (Torsional vibration may occur.)**

Figure 6-4 : Using Small-Diameter Shaft




● **Example 3 : Driving ball screw. (Inertia of the whole mechanism is very small.)**

Figure 6-5 : Driving Ball Screw



● **Example 4 : Load is connected using sprocket chain or gear mechanism. (There may be backlash.)**

Figure 6-6 : Using Sprocket Chain Or Gear Mechanism



(1) For smooth drive, the inertia of directly attached load should be :

$$J_d = J_i \times 0.2$$

where

J_d : inertia of directly attached load

J_i : inertia of indirectly attached load

Example:

- When the inertia of indirectly attached load (J_i) is $0.5 \text{ kg}\cdot\text{m}^2$, the inertia of directly attached load (J_d) shall be:

$$\begin{aligned} J_d &= 0.5 \times 0.2 \\ &= 0.1 \text{ kg}\cdot\text{m}^2 \end{aligned}$$

(2) When driving a speed reduction;

$$\frac{J_i}{r^2 \times J_d} \leq 5$$

where

J_d = inertia of directly attached load

J_i = inertia of indirectly attached load

r = speed reduction ratio

Example:

- When

inertia of indirectly attached load J_i : $20 \text{ kg}\cdot\text{m}^2$

speed reduction ratio r : $1 : 3$

the inertia of directly attached load (J_d) shall be:

$$\begin{aligned} J_d &\geq \frac{J_i}{r^2 \times 5} \\ &\geq \frac{J_i}{3^2 \times 5} \\ &\geq 0.556 \text{ kg}\cdot\text{m}^2 \end{aligned}$$

6.3.3. Load Inertia

- Generally, the load inertia is much bigger than the rotor inertia of the Motor. The following table shows the approximate inertia capacity. (Inertia is shown as J in kg·m².)

Table 6-3 : Inertia Capacity

(Unit: kgm²)

	High speed positioning	General use	Large inertia (Low speed positioning)
YS2005	0.006 ~ 0.25	0.25 ~ 0.5	–
YS2020	0.025 ~ 1	1 ~ 2	–
YS3008	0.01 ~ 0.4	0.4 ~ 0.8	–
YS3040	0.05 ~ 2	2 ~ 4	–
YS4080	0.1 ~ 4	4 ~ 8	–
YS5120	0.15 ~ 6	6 ~ 12	12 ~ 30
YS5240	0.3 ~ 12	12 ~ 24	24 ~ 125
JS0002	0.003 ~ 0.1	0.1 ~ 0.2	–
JS1003	0.004 ~ 0.15	0.15 ~ 0.3	–
JS2006	0.008 ~ 0.3	0.3 ~ 0.6	–
JS2014	0.018 ~ 0.7	0.7 ~ 1.4	–

6.3.4. Fluctuating Load Inertia

- Changes in the inertia load directly influence the performance and stability of direct drive motors. In the case of large changes in the load inertia it may be necessary to change the servo loop gain. To minimize the effect of load inertia fluctuations, the ratio of inertia fluctuation should be kept as small as possible, preferably less than 1 :

$$R_i = \frac{J_{\max} - J_{\min}}{J_{\text{rotor}} + J_{\min}}$$

(Where Ri = ratio of inertia fluctuation, Jmax = load inertia at maximum, Jmin = load inertia at minimum, Jrotor = rotor inertia)

6.3.5. Motor Operating Condition

- Ambient Temperature : 0 ~ 40°C.
- Relative Humidity : 20 ~ 80 % (Non-condensing)
- Indoor use only
- The area where the Motor is mounted must be free of corrosive gas, dirt, dust and any other contamination.
- YS and JS Motor series are not water-tight. If the Motor is to be used where smaller particles and/or water may be present, it must be protected by another cover or enclosure.
- Do not apply any machining, such as drilling or cutting.

6.4. Driver Unit Mounting

- The ESA23 Driver Unit may be mounted by the holes in brackets.


Caution : For proper air circulation, clearance is required above, below, and at the back of the unit (see Figure 6-7).

- When installing the Driver Unit in the control panel, keep the panel internal temperature within the range from 0 °C to 50 °C. If the heat sink overheat alarm (see “13. Alarms”) arises frequently, cool the heat sink using a fan, etc.

Caution : When installing two or more Driver Units for multi-axis combinations, give a space of about 10 cm between adjacent Driver Units.

- ESA23 Driver Unit has brackets for easy fixing to the control box or enclosure.

Figure 6-7



- The area where the Driver Unit is mounted must be free of water, corrosive gas, dirt, dust and any other contamination.

6.4.1. Connecting Power

- The main power AC line input supplies the power to the high voltage supply for driving the Motor.
- The voltage supplied to the Motor may be three phase or single phase. If the application involves low speeds less than 0.5 r.p.s., then single phase power will be adequate. If the application requires high torque and speeds greater than 0.5 r.p.s., then the best Motor torque/speed performance is obtained by supplying three phase power at a higher voltage.
- The control power AC line input supplies power to the internal low voltage switching power supply for the logic and signal circuits. The internal switching power supply will operate from any single phase AC voltage from 90 up to 240 volts.
- The AC power for the control power input may be obtained from the same supply that is connected to the main power AC line input.
- The AC line power consumption varies with the Motor size, the Driver Unit type and the load. The Megatorque Motor System requires very little power when it is moving at zero or low speed, even at maximum torque output. The power consumption is highest when the Motor is producing significant amounts of torque at elevated speed, more than 20% of the maximum rated speed.
- Use 2.0 mm² (14AWG) or larger wire with heat-proof vinyl for power line.
- The electrical noise from outside sources and from the System itself can interfere with proper operation. The protection from electrical noise must be designed into the installation. Use a line noise filter on the AC supply. A suitable noise filter may be obtained from NSK. If you supply your own, it should meet these requirements in Table 6-4.

Table 6-4 : Noise Filter Requirement

Driver Unit AC Line	Noise Filter Voltage Rating	Current Rating
220VAC, 3 ϕ	250V AC/DC	15A AC/DC
220VAC, 1 ϕ		
110VAC, 1 ϕ		
Control Power	250V AC/DC	5A AC/DC

- Do not tie wrap the input and output sides of the AC line filter together, or place them in close proximity. Do not tie wrap the ground wires with signal wires.
- The noise filter must be installed on control power AC line, separately from the main power line.
- An isolation transformer must also be used to prevent electrical shock. Contact NSK if you need information about isolation transformers. If you supply your own, the transformer must have enough capacity for the Motor power consumption. Refer to “4.2.2.1. General Specifications” for the required power of the Motor.
- Do not place the main power AC line input supplies and signal wires in close proximity. Do not tie wrap them and not put in the same duct.
- The Driver Unit and the noise filters must be close to each other and wiring must be of minimal length. Do not insert contacts like a magnetic switch or a relay between them.
- Install a circuit breaker on the main power AC line. When the power is turned “ON”, an inrush current to the circuit will occur because of the capacitive load connected to the main power supply circuit.

- When inserting contacts into the power supply circuit, the specification of the contact should be greater or equal to ones in the following table :

Table 6-5 : Contact Requirements

Contacts	For ESA23 Type
No-Fuse Breaker	Current Rating 15A
Short-Circuit Breaker	Contact Capacity 15A Sensitivity 15mA
Magnetic Switch	Contact Capacity 30A

Table 6-6 : Inrush Current

Item	Inrush Current (TYP)	
	AC100V	AC200V
Control Power	7A	14A
Main Power	80A	140A

- Install a surge killer circuit for magnet switches, relays and solenoids.
- When replacing the fuse F1 or F2 of the Driver Unit, use the fuse packed with the Driver Unit when it is shipped.

Caution : ● Use the R-S terminals when connecting single-phase 200 VAC for the main power supply. Surge current becomes larger when the R-T terminals are in use.

- During wiring, be careful not to loose terminal block screws, etc.

Danger : Install the plastic protection on TB Terminal Block after wiring. The terminals on TB will be at high voltage when power is turned on. Removing the protection and touching terminals may cause extreme electrical shock.

Note : Refer to “5. Connector Specifications” for the connector wiring.

6.4.2. Ground Connection and Wiring


- For grounding Driver Unit, use heavy gage cable as possible, such as a flat braided copper cable or a wire 3.5mm² (AWG 10) or larger.

Caution : • All the ground lines must be connected at one point and the grinding resistance must be under or equal to 100Ω.

- Connect the shield of the signal shielded cable (CN2) to the FG terminals (or SG terminals) of the user's controller. If runaways are caused by noise, connect the shield to the FG terminal of the Driver Unit.
- If the Motor is isolated from the mother machine, then ground the Motor separately.

- Figure 6-8 shows the wiring example. (This is provided as an example, not the instruction.)

Figure 6-8 : Wiring Example



6.5. Connecting Motor and Driver Unit

- User must specify the Cable Set length when ordering.

Caution : • Do not make the Cable Set length longer or shorter. Changing cable length may worsen Motor and Driver Unit performances, typically resolver and resolver repeatability. When changing the length, the Motor and the Driver Unit must be returned to the manufacturer. Contact your local NSK representative.

- Do not place the power lines (AC power supply and Motor cable) and the signal lines (CN2 and Resolver cable) in close proximity. Do not tie wrap them and not put in the same duct.

- Connect the Cable Set to Motor connector and Driver Unit connectors CN3 and CN4 as shown in Figure 6-9 and 6-10.

Figure 6-9 : YS Motor





Figure 6-10 : JS Motor



6.6. Power On and Servo On

6.6.1. Precautions

Caution : Before tun on the main power, check the following.

- (1) Wiring of connectors
- (2) Connecting Cable of Motor and Driver unit.
- (3) Safety

Danger : Always stay in a safe place.


Waring : Confirm that the Motor is securely fixed to the mounting base and the load is fixed to the Motor. Fully fasten all the mounting bolts.

Danger : If the Motor is fitted with an arm or a work, make sure that no obstacles are around in the operating area.

6.6.2. Turning Power On


- (1) Turn on the power
- (2) Make sure that the LED of the Driver Unit and the Handy Terminal display are indicating that the system is ready for operation.
 - ① Normal state
 - Figure 6-11 shows the LED indicator in normal condition.

Figure 6-11




- ② Abnormal

Figure 6-12



- Refer to “13. Alarms” for more details.
- ③ Handy Terminal display
 - If a message “NSK MEGA...” is displayed on the Handy Terminal, the system is ready for operation. A colon (:) indicates that a command be entered.

Figure 6-13 : Handy Terminal display (In normal state)



(3) If the system is normal, input SVON signal.

Caution : Turn on the main power supply first, then the SVON input, when turn off the main power supply, turn off SVON first. If the main power supply is turned off in the servo-on state, the Driver Unit outputs the AC Line under-voltage alarm. Once this alarm occurs it will not recover unless the power is turned on again.

○ Figure 6-14 and 15 show timing of power “ON” and SVON.

Figure 6-14 : Power “ON” sequence





Figure 6-15 : Power ON / SVON timing



7. Handy Terminal Communication

- Setting of various parameters, trial running, and adjustment are enabled by issuing commands to the Driver Units through NSK Handy Terminal FHT11. (i.e., communication through the RS-232C interface).
- The Driver Unit has CN1 as the Input/Output ports for RS-232C communication.
- FHT11 Terminal can be a daisy chain communication terminal. Refer to “9.3.3. Daisy Chain Communication” for details.


Caution : Always turn off the Driver Unit when plugging on/off the CN1 connector.

- Turn off the Driver Unit, if it has been turned on.
- Connect FHT11 and the Driver Unit at connector CN1.
- The communication will automatically begin when you turn on the control power of the Driver Unit.

7.1. When Power is Turned ON

- If the terminal (NSK Handy Terminal FHT11) is connected to CN1 and the Driver Unit power is turned on, the message shown below is displayed.
- The contents (and the number of characters) of this message may differ with Driver Unit setting and system versions.
- When the Driver Units are initialized, a colon (:) is displayed and the system waits for a command to be entered. The colon (:) is called a prompt. If the colon (:) is not displayed, press **ENT** key.

Figure 7-1 : Power-On Message



7.2. Command Entry


- Communication command shall consist of “a command (character string) + data (if necessary) + **ENT**”
- If the velocity gain is to be set to 0.5, for example, “VG0.5” should be entered by adding data of 0.5G to a VG command.
- Every time a character is input, the Driver Unit echoes the character back to the terminal. (The Driver Unit returns same character it receives.)
- When **ENT** code is input, the Driver Unit decodes a character string which it has received (VG0.5 in the example above) and executes it. Therefore, a command is not executed unless it ends with **ENT**.

Caution : When turn off the Driver Unit power, make sure that a colon (:) is displayed. If not, an alarm “Memory error” might be detected when you turn on the power next time.

7.3. Password

- Among the communication commands used for this System, some special commands (such as AB, PA, SI, etc.) require password entry for preventing erroneous entries. These commands cannot be entered in the same manner as other commands.
- The password is /NSK ON (a space between K and O) as shown below. If the Driver Unit accepts it, it returns an “NSK ON” message. Refer to “11. Command and Parameter” for details.
- A command requiring password entry may only be executed immediately after the password is entered.


Figure 7-2 : Password Input



7.4. Cancelling Command

- To cancel a command which has been entered halfway, enter a backspace code.
- For example, when the backspace code is input following VG0.5, the cursor moves one space back to the position where 5 was input and thereby deletes 5.

Figure 7-3 : Canceling Example




7.5. Error

- Note that an error occurs in any of the following cases :
 - (1) If a nonexistent command (i.e., character string) is entered (If an entered character string cannot be decoded).
 - (2) If data or subscript out of the allowable range is entered.
 - (3) If a command requiring the password is entered without the password.
- In any of these cases, the entered character string with a '?' mark is returned as an error message.

For example,

Figure 7-4 : Input Error Example 1




7.6. Readout Command

- If a command for reading initial setting or current state is entered, the Driver Unit returns data.
- The following is an example for checking “JOG Velocity JV” set value.


(1) TS command for reading set value

① Refer to “11. Command and Parameter” “TS”

② “JV” command is in the group of TS7, input



③ Press **[SP]** key to scroll display to find out JV value.



④ When finishing the readout,

(i) Keep pressing **[SP]** key until display stops scrolling.

or


(ii) Press **[BS]** key.

⑤ The colon (:) is displayed to indicate the system is waiting for next command.

(2) If the set value reading function “?” is used

① Enter “?” before inputting JV.

Display shows the value of “JV”.




② A colon (:) is displayed.

Caution : When reading out set value, using TS command is recommended. When using “?” command make sure to input “?” before parameter characters. If not, and pressing **[ENT]** key after the characters may change the set value.

8. Trial Running and Adjustment

8.1. Adjustment Sequence

Figure 8-1 : Adjustment Sequence



8.2. Automatic Tuning (Adjustment Level 1)

Caution : Automatic tuning cannot be performed if the following conditions are not met.


- The load inertia must be under the limit of the Motor. (Refer to “4.1. Motor Specifications”)
- The motor axis must be vertical. (The load conditions to the Motor must not be affected by the gravity.)
- Mechanical rigidity of the Motor mounting base and attached load is sufficient enough.
- There must be no backlash or play caused by gears and couplings.
- Frictional load to the Motor shall be minimal.

8.2.1. Precautions

- Danger** :
- Wire “EMST” (Emergency Stop, CN2) signal to stop the Motor immediately when an accident is foreseen.
 - If the Motor rotation range is restricted, set overtravel limits (OTP, OTM).
 - The Motor rotates $\pm 20^\circ$ (degree) when executing automatic tuning. Always stay in safe position.

Caution : If mechanical rigidity of the load (work) is not sufficient enough, the Motor may vibrate. Turn “SVON” signal off or turn off the power when the Motor starts to vibrate. Execute manual adjustment in chapter 8.3 or increase the rigidity of the load.

Figure 8-2 : Example of Automatic Tuning Preparation



8.2.2. Initialize Servo Parameters

(1) Turn off the servo-on (SVON, CN2) signal.

(2) Enter **T S 1 # ENT** and **T S 2 \$ ENT**

to check the parameter settings. Note down all values.

(3) Log in the password.

/ N S K SP
O N ENT



:/NSK ON
NSK ON
:_

Display indicates the confirmation.

(4) Log in SI (Set Initial Parameters) command.

S I ENT



:SI
INITIALIZE
:_

“INITIALIZE” is displayed as the confirmation, and the initializing parameter begins. It takes few seconds and a colon “:” is displayed for next command.

Caution : When “SVON” signal (CN2) is “ON” and “SI” command is input, Driver Unit rejects to execute the command. “SI INHIBITED” message will appear in the display.



:SI
SI INHIBITED
:_

Table 8-1 : Servo Parameter List

Parameter	TS1 Reading		Parameter	TS2 Reading	
	Initial Setting	Set Value		Initial Setting	Set Value
PG	0.100		FO*	0.000	
VG	1.0		FP	0	
VI	1.00		FS	0	
VM	1		NP	0	
LG*	50		DBP*	0	
TL*	100		ILV*	100	
			FF*	0.000	
			FC*	0	

* These parameters are not necessary to adjust in Level 1 and 2 adjustment.

8.2.3. Execute Automatic Tuning (Adjustment Level 1)

Caution : Make sure the work (or Motor) does not hit any obstacle when the Motor makes a full turn. Always stay in safe position.


- The Motor needs to rotate at least $\pm 20^\circ$ when executing the automatic tuning. If the application restricts the Motor rotation, keep room for $\pm 20^\circ$ Motor rotation. The overtravel limits (OTP, OTM) must be used to restrict the Motor rotation range.

(1) Turn SVON (CN2) signal “ON” and inputting “SV” command makes the Motor in servo-on states.

S
V
ENT

➔

```
:SV
:_
```

(2) Confirm that Driver Unit’s “LED” is indicating “” for normal condition.

(3) Input “Automatic Tuning” command.

A
T
ENT

➔

```
:AT
AT ready OK
?_
```

If a message is different from the display shown right, try procedures (1) and (2) again.

(4) Confirm the message “AT ready OK” then input “OK”.

O
K
ENT

➔

```
:AT
AT ready OK
?OK
...
```

The Motor rotates 10~20° back and forth to estimate the load inertia. When executing estimation, a dot (.) keeps appearing in the display till the Motor stops.

(5) After the estimation of load inertia, the display indicates the inertia value “LO”.

➔

```
?OK
.....
LO****
:_
```

Load inertia estimation.

Caution : When executing the automatic tuning, if an error message is “ON” refer to “13. Alarms” and take a proper remedy. Driver Unit’s LED indicates “F8” for “AT” error.

➔

```
?OK
.....
AT Error1*
:_
```

Error number

8.2.4. Trial Running (Adjustment Level 1)

Danger : Confirm that the work (or Motor) does not hit any obstacle when the Motor makes a full turn. Always stay in safe position.


- For this adjustment, ESA23 Driver Unit's demonstration program is used as an example. The program is originally set before it is shipped.

- (1) Turn SVON (CN2) signal "ON" and inputting "SV" command makes the Motor in servo-on states.

S **V** **ENT**



```
:SV
:_
```

- (2) Confirm that Driver Unit's "LED" is indicating "" for normal condition.

- (3) Confirm an emergency stop (ESTM) and over travel limits (OTP, OTM) are "OFF".

- (4) After the automatic tuning the rotational speed "MV" has been initialized to 1 rps. Change "MV" to 0.1 rps for trial running.

M **V** **0** **?** **.** **=** **1** **#** **ENT**



```
:MV0.1
:_
```

Note : After the adjustment, change "MV" to the actual use.

- (5) Display the demonstration program.

S **P** **/** **A** **J** **ENT**



```
:SP/AJ
IN100,IS0.0,FW1.0
ID9000/OK
?_
```

- The message indicates the conditions of positioning and rotation angle.

IN: In-position, IS: In-position stability timer.

FW: FIN Width.

ID: Incremental Positioning, Degree.

(Refer to "11. Command and Parameter")

- (6) To make the adjustment simple, set IN "10" (pulse) and IS "50" (m sec).

I **N** **1** **#** **0** **?** **ENT**

I **S** **0** **?** **.** **=** **5** **%** **ENT**



```
?IS0.5
IN10,IS0.5,FW1.0
ID9000/OK
?_
```

Check the display for confirmation.

- (7) When rotational angle (ID) 9000 (90 degrees) is feasible, input "OK".



```
IN10,IS0.5,FW1.0
ID9000/OK
?OK
:_
```

The motor starts the cycles as soon as "OK" is logged in.
(Firstly the Motor rotates clockwise (CW).)

- For changing rotational angle (ID) while "?" prompt is displayed, input desired ID, then input "OK".
 - Example for rotational angle: 30° (degree)



```
?ID3000
IN10,IS0.5,FW1.0
ID3000/OK
?_
```

- (8) When the trial running is completed, type



```
:MS
:_
```

to stop the Motor.

- If the Motor is operating satisfactorily, complete the trial running.
- When the Motor operation is not stable, try further adjustment in chapter 8.2.5 and 8.3.
- If you want to get out from the demonstration program, press the enter key after "?".

8.2.5. Minor Servo Gain Adjustment (Adjustment Level 2)


Danger : Confirm that the work (or Motor) does not hit any obstacle when the Motor makes a full turn. Always stay in safe position.

- This section describes minor servo-gain adjustment as the next step when the Motor operation is not satisfactory with the automatic tuning.
- Servo-gain can be adjusted by the parameter “SG”.
 - Setting higher “SG” value improves response to the programmed motion profile. However, if “SG” is too high, the Motor starts to vibrate.
- The same demonstration program in chapter 8.2.4 is used as the example for adjusting “SG” value. (Execute same procedure (1) ~ (7) in chapter 8.2.4 and keep operate the Motor.)

(1) Start “SG” adjusting program.



The message is displayed as shown below. Press plus (+) or minus (key) to change “SG” value. (The display shown below is an example. Those values shall be set to the conditions for actual use.)



● Explanation of the messages

① Key function

SHIFT and **- +** : Pressing key one time increases 1 resolution of “SG”.

- + : Pressing key one time decreases 1 resolution of “SG”.

ENT : Store “SG” value to the memory.

② Indicates present “SG” value.

③ Indicates “SG” value changed by pressing plus (+) or minus (-) key.

④ Response index number: The lower numbers denotes better response.

⑤ Positioning index number: The lower number denotes quicker response.

Note : Do not use space key or back space key. When it is used, the “SG” changing resolution (②) may be altered.

- (2) Observing the Motor operation, press the plus (+) key several times.

Pressing ,   ...

As the response index decreases, the movement of the Motor is getting crisply.



```
[+],[-],[ENT]
333( 222)
STEP1
_SG13
```

- (3) Keep pressing the plus (+) key, eventually the Motor starts hunting and stops.

Pressing ,   ...



```
[+],[-],[ENT]
233( 123)
STEP1
_SG18
```

- (4) Keep pressing the minus (-) key until the Motor stops hunting and starts moving.

  ...



```
[+],[-],[ENT]
253( 145)
STEP1
_SG16
```

- (5) Set “SG” value 80% of “SG” value at when the Motor stopped hunting. The Motor operates stable in any position.



```
[+],[-],[ENT]
263( 156)
STEP1
_SG13
```

- (6) Type the enter key to complete the adjustment.





```
263( 156)
STEP1
SG13
:_
```


8.3. Manual Adjustment

Danger : Confirm that the work (or Motor) does not hit any obstacle when the Motor makes a full turn. Always stay in safe position.


- Manual adjustment is needed when the automatic tuning did not work.

8.3.1. Precautions

- ① Initialize servo parameters. Follow procedures in “8.2.2. Initialize Servo Parameters”.
- ② Execute the demonstration program referring to “8.2.4. Trial Running (Adjustment Level 1)”. At the beginning, Motor operation is unstable due to insufficient adjustment.

8.3.2. Adjustment of the Velocity Gain (VG)

- (1) Start “VG” adjusting program.



- The display shows the message as shown on the left.

- Explanation of the messages

- ① Key function

SHIFT and **- +** : Pressing key one time increases 1 resolution of “VG”.

- + : Pressing key one time decreases 1 resolution of “VG”.

ENT : Store “VG” value in the memory and completes the adjustment..

- ② Indicates present “VG” value.
- ③ Indicates “VG” value changed by pressing plus (+) or minus (-) key.
- ④ Response index number: The lower number denotes better response.
- ⑤ Positioning index number: The lower number denotes quicker positioning.

Note : Changing “VG” step (③).

If you want to change the resolution of step, press space key or back space key.

Space key : Changes the step to 1/10 of present resolution.
(Pressing twice makes 1/100.)

Back space key : Changes the step to 10 times of present resolution.
(Pressing twice makes 100 times.)

- (2) Observing the Motor operation, press the plus (+) key several times.

Pressing ,  +  ...

As the response index decreases, the movement of the Motor is getting crisper.



```
[+],[-],[ENT]
333( 222)
STEP1
_VG3
```

- (3) Keep pressing the plus (+) key, eventually the Motor starts hunting and stops.

Pressing ,  +  ...



```
[+],[-],[ENT]
233( 123)
STEP1
_VG5
```

- (4) Keep pressing the minus (-) key until the Motor stops hunting and starts moving.

 +  ...



```
[+],[-],[ENT]
253( 145)
STEP0.1
_VG4
```

- (5) Set the “VG” value to 80% of displayed “VG” when a hunting is stopped.
 $4 \times 0.8 = 3.2$



- (6) Press the space key to change the resolution of “VG” setting value from 1.0 to 0.1.





```
[+],[-],[ENT]
263( 156)
STEP0.1
_VG4
```

- (7) Press the minus key till “VG” value reaches to 3.2.

 +  ...



```
[+],[-],[ENT]
263( 156)
STEP0.1
_VG4
```

- (8) Press the enter key to store the “VG” value.






```
263( 156)
STEP0.1
VG3.2
:_
```

A colon (:) will appear to confirm the input.

8.3.3. Adjustment of Velocity Integrator Frequency

- The adjustment of velocity integrator frequency (VI) shall be conducted after the velocity gain (VG) is adjusted.

(1) Start “VI” adjusting program.



- The messages are shown on the left.
- Inputting the plus (+) or minus (-) key changes “VI” value
(The “VI” value varies with an actual load inertia and revolution speed.)

- Explanation of the messages

① Key function

SHIFT and **- +** : Pressing key one time increases 1 resolution of “VI”.

- + : Pressing key one time decreases 1 resolution of “VI”.

ENT : Store “VI” value in the memory and completes the adjustment.

② Indicates present “VI” value.

③ Indicates “VI” value changed by pressing plus (+) or minus (-) key.

④ Response index number: The lower number denotes better response.

⑤ Positioning index number: The lower number denotes quicker positioning.

Note : Changing “VI” step (③).

If you want to change the resolution of step, press space key or back space key.

Space key : Changes the step to 1/10 of present resolution.
(Pressing twice makes 1/100.)

Back space key : Changes the step to 10 times of present resolution.
(Pressing twice makes 100 times.)

- (2) Observing the Motor operation, press the plus (+) key several times.

Pressing ,  +  ...

As the response index decreases, the movement of the Motor is getting crisply.

[+],[-],[ENT]
333(222)
STEP1
_VI3

- (3) Keep pressing the plus (+) key, till the Motor starts hunting and stops.

Pressing ,  +  ...

[+],[-],[ENT]
233(123)
STEP1
_VI5

- (4) Keep pressing the minus (-) key until the Motor stops hunting and starts moving.

 +  ...

[+],[-],[ENT]
253(145)
STEP0.1
_VI4

- (5) Set the "VI" value to 80% of displayed "VI" when a hunting us stopped.
 $4 \times 0.8 = 3.2$

Input the space key to change the resolution of "VI" setting value from 1.0 to 0.1.

- (6)



[+],[-],[ENT]
263(156)
STEP0.1
_VI4

Press the minus key till "VI" value reaches to 3.2.

- (7)

 +  ...

[+],[-],[ENT]
263(156)
STEP0.1
_VI3.2

Input the enter key to store the "VI" value.

- (8)



A colon (:) will appear to confirm the input.

263(156)
STEP0.1
VI3.2
:_


8.4. Setting Filters (Adjustment Level 2)

- When positioning, the Motor may resonate mechanically and generate a noise of certain frequency. Using Megatorque Motor's software "low-pass filters" (Parameter FP and FS), the noise can be reduced.
The unit of parameters of FP and FS is cycles / second (HZ).
 - If low frequency less than 100Hz is set to parameters "FP" and "FS", hunting or unstable positioning may occur.
- Before using filters, make sure that all adjustments of gain (VG) and integrator frequency (VI) are completed.
- Use same demonstration program (SA/AJ) for adjusting filters. Follow the procedures (1) ~ (7) in "8.2.4. Trial Running (Adjustment Level 1)".

(1) Start "FP" adjusting program.



The message is displayed as shown below. Press plus (+) or minus (key) to change "FP" value. (The display shown below is an example. Those values shall be set to the conditions for actual use.)



- Explanation of the messages

① Key function



: Pressing key one time increases 10 resolution of "FP".



: Pressing key one time decreases 10 resolution of "FP".



: Store "FP" value in the memory and completes the adjustment..

② Indicates present "FP" value.

③ Indicates "FP" value changed by pressing plus (+) or minus (-) key.

④ Response index number: The lower number denotes better response.

⑤ Positioning index number: The lower number denotes quicker positioning.

Note : Changing "FP" step (③).

If you want to change the resolution of step, press space key or back space key.

Space key : Changes the step to 1/10 of present resolution.
(Pressing twice makes 1/100.)

Back space key : Changes the step to 10 times of present resolution.
(Pressing twice makes 100 times.)

- (2) Decrease low-pass filter frequency (FP) to lower noise level by typing minus (-) key several times.

...



```
[+],[-],[ENT]
333( 222)
STEP10
FP500
```

- (3) If the Motor starts to work unstably, increase "FP" value by typing plus (+) key several times.

Pressing , ...



```
[+],[-],[ENT]
233( 123)
STEP1
FP120
```

- (4) Type the enter key to complete the adjustment.



```
233( 123)
STEP1
FP120
:_
```

Note : To deactivate the filter, input the filter command with "0" data. For example type as:



```
:FP0
:_
```

Note : Setting "Notch Filter"


- When setting notch filter, you can connect the oscilloscope to monitor pins on Driver Unit front panel to know the resonance frequency.

• Example

- ① Check the resonance frequency as shown in Figure 8-3.
- ② If the resonance frequency is 200Hz, input

to set notch filter frequency.

Figure 8-3




9. Operational Function

9.1. General Operation and Function

9.1.1. Servo “ON”


- After the Driver Unit power is turned on and its DRDY output circuit becomes closed, making SVON input ON should make motor servo-on.
- The position error counter will be cleared when SVON input is OFF.
- When SVON input is ON, the MO command results in servo-off.
- The SV or MS command will cancel this MO command effect.

Figure 9-1



- Take the following precaution when turning ON/OFF the main power supply and the control power supply separately :
 - When turning on the main power supply with the control power supply turned on : Turn on the main power supply first, then the SVON input.
 - When turning off the main power supply with the control power supply turned on : Turn off the SVON input first, then the main power supply.
 - * When the main power supply is turned off in the servo-on state, the Driver Unit outputs the AC Line under-voltage alarm. (Once this alarm occurs, it will not recover unless the power is turned on again.)


Figure 9-2



9.1.2. Emergency Stop

- Turning on the EMST input stops the position loop control function and stops the Motor in the servo-lock state* under velocity loop control.
 - No motion commands will be accepted while EMST input is on.
 - In the EMST state, the LED on the front panel indicates “F4”. The DRDY output remains unchanged (closed).
- * The polarity of the EMST signal input port is set to A contact before shipment, but it can be changed to B contact (refer to the AB parameter).
- * Position loop control is not performed this time. If the possibility exists of an external force being applied to the Motor in this state, use a mechanical brake. When the SVON input is OFF after EMST input is ON, the Motor remains servo-on for one second after the EMST input went on. If the EMST input is ON when the SVON input off, motor will be servo-off.

Figure 9-3




- The Driver Unit may not accept EMST input unless it stays on for 10 ms or longer.

9.1.3. Position Error Counter Clear Input

- If the CLR input is on, position loop error will be cleared.
 - When the excess position error alarm occurs, turning on the CLR input clears the position error counter and recovers from the alarm state.
- * The Driver Unit detects the rising edge of the CLR input pulse and clears the position error counter to zero. Then, the counter continues its operation regardless of the state of the CLR input (even when it remains on).

Figure 9-4




- * Software thermal and program error alarms can be cleared by inputting “CLR” on. (Other alarms cannot be cleared using “CLR”.)

9.1.4. Overtravel Limit

9.1.4.1. Hardware Overtravel Limit

- Hardware overtravel limit is effective when I/O type is set to TY3, TY4 or TY7.
- Use the OTP and OTM inputs to restrict the range of Motor rotation.
- If the OTP input is activated, the Motor motion will stop immediately and remain in servo-on. The Motor can be rotated counter clockwise only.
- If the OTM input is activated, the Motor motion will stop immediately and remain in servo-on. The Motor can be rotated clockwise only.
- * The polarity of the OTP and OTM input ports is set to A contact before shipment. It can be changed to B contact (refer to the section on the AB parameter).
- * Besides the OTP and OTM inputs, the Motor rotation can also be limited by software (software overtravel limit function) in the Driver Unit. Refer to “9.1.4.2. Software Overtravel Limit”.
 - When the overtravel error occurs, the DRDY output will be open and displays the following on the front panel.
OTP or OTM limit : F3
Software overtravel limit : F2

Figure 9-5



- * When the OTP or OTM input works in the middle of the home return operation, the Motor completes the home return operation after performing the following :

(1) When the Motor is turning CCW

- Caution** :
- The OTP input is invalid (the Motor continues rotation).
 - Turning on the OTM input makes the Motor decelerate, then rotate in reverse.

(2) When the Motor is turning CW

- Caution** :
- Turning on the OTP input makes the Motor decelerate, then rotate in reverse.
 - The OTM input is invalid (the Motor continues rotation).

9.1.4.2. Software Overtravel Limit

Notes to be taken in overtravel limit setting

- Caution** :
- The overtravel area should be 1000 [pulses] or wider. When the overtravel area is too narrow the Motor may turn through the prohibited area.
 - Set the overtravel limits with ample margin, giving consideration to the overshoot of the mechanism controlled by the Motor.
 - When the movement by direction to minimize rotation angle is specified in the single-rotation position scale, the Motor takes the shortest route regardless of the overtravel limit setting.
- This function becomes valid after the origin is determined by home return or AZ command.
 - Use the OTP and OTM commands to set the overtravel limit values.

<Operation> Setting by teaching

- (1) Turn off the Motor servo.

M O ENT



```
:MO
:_
```

- (2) Move the Motor's rotor manually to a point to be the overtravel limit on the plus side.

- (3) Input the password.

/ N S K SP
O N ENT



```
:MO
:/NSK ON
NSK ON
:_
```

- (4) Register the present position as the overtravel limit on the plus side. The registered overtravel limit value appears on the display.

O T P / S T
ENT



```
:OTP/ST
OTP123456
OTM0
:_
```

- (5) Move the Motor's rotor manually to a point to be the overtravel limit on the minus side.

- (6) Input the password.

/ N S K SP
O N ENT



```
:MO
:/NSK ON
NSK ON
:_
```

- (7) Register the present position as the overtravel limit on the minus side. The registered overtravel limit value appears on the display.

O T M / S T
ENT



```
:OTM/ST
OTP123456
OTM456789
:_
```

- (8) Move the Motor's rotor into the overtravel area. Check that the Driver Unit outputs the F2 alarm (check the alarm indicated on the LED or input the TA command).

- After the home return is completed, take the following steps :
- If the F2 alarm is not output this time, check the following :
 - Is the position scale home position located between OTP and OTM?
 - In the single rotation position scale : is $OTP < OTM$?
 - In the Linear position scale : Is OTP a positive value, and OTM a negative value?


Setting by position scale data

- When the overtravel limit values are already known, users can directly set these values in the OTP and OTM command parameters.

9.1.5. Alarm Output

- After the power is on and “CPU” is initialized, “DRDY” output is closed when alarms are not detected.
- The “DRDY” output opens when the alarm is detected.
- Alarm signal shall be connected to “alarm input” of user’s controller.


Figure 9-6



9.1.6. Brake Signal Output

- The BRK output circuit opens in the following states :
 - ① SVON input : off
 - ② Occurrence of an alarm which causes the Motor servo to turn off (example : memory error, etc.).
 - ③ During system initialization after the power is turned on
 - ④ EMST input : on

Figure 9-7



* This signal can be used to control negative (normally on) brake, which activates the external brake when the Motor servo goes off or the EMST is input.


9.1.7. In-Position Output

- In-Position output condition is determined by the following parameters.

Table 9-1

Parameter	Function (Name)	Shipping set
FW	IPOS outputting time range (Output mode)	FW1
IN	In-Position limit value	IN100
IS	In-Position stability timer	ISO

Figure 9-8



9.1.7.1. Output Signal Format

- The output signal format --- either IPOS format or FIN format --- can be selected by setting the FW parameter.
 - FW data : FIN format is selected when data $\neq 0$ (shipping set : FW1)
 - FW0 : IPOS format

(1) When data of parameter “FW” is not “0” (Zero) (FIN format)

- “IPOS” output indicates that the positioning has completed.
- IPOS will be output for every positioning start command such as **RUN** and **HOS**.
- Out put format
 - IPOS output is always open and it closes only for the moment set by “FW” when completion of positioning. (Closing time unit in “FW” is 100m sec. Shipping set FW1 : 100m sec.)
- Recommendation

We recommend to use FIN format when you use the programmable indexer in the Driver Unit.
- “IPOS” will not be output for pulse train operation and jogging operation.
- When the positioning is stopped in the middle of operation by the emergency stop or overtravel limit, “IPOS” will not be output.

(2) When “data” of parameter “FW” is 0 (Zero) (IPOS format)

- The format is to indicate if there is an error between position command and present position.
- Basically “IPOS” output will be closed only when residual pulses in the position error counter is within the range set by “IN” parameter. In other state, it is open.
- However, even residual pulses in the position error counter is within the “I” value, output is forced to open during pulses are generated internally when executing programmable indexer, home return, jogging and operations via RS-232C.

(Executing programmable indexer, home return, jogging and operation through RS-232C.)
- Recommendation

Select “IPOS” format for pulse train operation or RS-232C operation.
- When the positioning is stopped in the middle of the operation by emergency stop or overtravel limit signal, IPOS output will stay closed if residual pulses of position error counter are within the “IN” value.
- When executing pulse train input operation, even pulses are being input, IPOS output is closed if residual pulses in the position error counter are within “IN” value.

[This state tends to occur when executing low speed operation or feed forward compensation is applied (“FF” parameter).]

9.1.7.2. Parameter “IN”

- Parameter “IN” is to decide positioning accuracy.
- “IPOS” output will be closed when residual pulses of position error counter are within the range of “IN” parameter.
- The unit of parameter “IN” value is the maximum resolution (pulses) of the motion detector (resolver).

Table 9-2

Motor series	Resolution (pulses/revolution)
YS, JS1, JS2, RS	614400
SS	491520
AS, BS, JS0	409600

● Example (YS series)

Desired positioning accuracy (repeatability) : ± 100 sec.

$$\begin{aligned} \text{“IN” set value} &= \frac{\text{resolver resolution}}{360} \times \text{repeatability (degree)} \\ &= \frac{614400}{360} \times \frac{100}{3600} \\ &= 47 \text{ pulses} \end{aligned}$$

9.1.7.3. Parameter “IS”

- “IS” is to confirm the stability of the positioning. When the in-position output signal is IPOS format, if the parameter “IN” value is smaller (roughly less than FN10), “IPOS” output will be instable in the moment of positioning settling, even all servo gains are adjusted properly.
- “IS” parameter should be set to eliminate above instability.
- When “IPOS” output is in “FIN” format, “IS” parameter prevents to output IPOS signal before the Motor complete the positioning.
- “IS” parameter is not effective for pulse train input operation and jogging operation.

9.1.7.4. "IPOS" Output for Special Occasion

(1) When 0 (Zero) moment operation is executed.

● Example

When [AD0] or [AR0] is executed even the Motor is in the home position, movement of the Motor is 0 (Zero). Followings show "IPOS" output states.

① "IPOS" format IS = 0

- There is no internal pulse output and "IPOS" output remains close if residual pulse of position error counter are within "IN" value.

② "IPOS" format IS ≠ 0

- Even no pulse is internally generated, "IPOS" output will be opened for the moment set by "IS" value to check positioning stability.

③ "FIN" format

- Even no pulse is generated internally, "IPOS" output signal shall always be returned for positioning start command.

(2) Sequential operation (BCD mode) for Programmable Indexer.

① "IPOS" format

- After the positioning is completed, execute next channel program, while "IPOS" output remains close.

② "FIN" format

- After the positioning is completed, "IPOS" output closes for the moment which is set by the parameter "FW", then execute the next channel's program after "IPOS" output is opened again.

9.1.8. Position Feedback Signal

- Resolution

Set the $\phi A/\phi B$ resolution using the FR parameter (via RS-232C).

Table 9-3


Feedback signal		$\phi A, \phi B$		ϕZ
		FR1	FR0	
YS, JS1, JS2, RS		153600	38400	150
SS		122880	30720	120
AS, BS, JS0		102400	25600	100

Unit: pulses/rotation

* When the resolver resolution is set to the automatic resolution switching or 10-bit setting, set the FR parameter to FR0. When it is set to FR1, $\phi A/\phi B$ will not be output.

- Output timing

Figure 9-9



* The phase can be reversed by the FD parameter (set via RS-232C).

FD0 : Standard; at CW rotation, ϕA becomes ON before ϕB

FD1 : Reverse; at CW rotation, ϕB becomes ON before ϕA

* The output specification of the CHZ signal--whether to output ϕZ or MSB--is selected by the FZ parameter (set via RS-232C).

FZ0 : ϕZ

FZ1 : MSB

9.1.9. Monitor Functions

- The Motor operation can be monitored by using the analog velocity monitor pins, which are provided in the front panel of Driver Unit, and RS-232C communication.

Table 9-4

Item	RS-232C communication command	Monitor output	Description
Velocity	—	VELOCITY check pin on the front panel	<ul style="list-style-type: none"> • Monitors the Motor velocity in forms of analog voltage output.
Position error	TE	CN1 via RS-232C terminal	<ul style="list-style-type: none"> • Monitors value of the position error counter. • For the details, refer to “11. Command and Parameter.”
Input/output	IO		<ul style="list-style-type: none"> • Monitors the input/output status (on/off) of CN2. • For the details, refer to “11. Command and Parameter.”
Present position	TP		<ul style="list-style-type: none"> • Monitors the present position in the position scale. • For the details, refer to “11. Command and Parameter.”
Parameter value	TS		<ul style="list-style-type: none"> • Monitors the set values of parameters. • For the details, refer to “11. Command and Parameter.”
Alarm	TA		<ul style="list-style-type: none"> • Monitors the alarm status. • For the details, refer to “13.1.2. Using TA Command.”
Channel program	TC		<ul style="list-style-type: none"> • Monitors the program stored in the channels. • For the details, refer to “11. Command and Parameter.”


9.1.9.1. Velocity Monitor

- The user can monitor the velocity of the Motor by measuring the voltage between VELOCITY and GND check pins on the front panel.

● When the resolver is set to 12-bit resolution

Note : ± 10 V is only a typical value; actual values vary slightly. The voltage is not a precise representation of the velocity.

Figure 9-10



● When the resolver is set to 10-bit resolution or automatic resolution switching

Note : ± 7.5 V is only a typical value; actual values vary slightly. The voltage is not a precise representation of the velocity.

Figure 9-11





Table 9-5 : Maximum velocity

Resolver resolution Motor series	12-bit setting	Automatic resolution switching or 10-bit setting
YS, JS1, JS2, RS	1 r.p.s.	3 r.p.s.
SS	1.25 r.p.s.	3.75 r.p.s.
AS, BS, JS0	1.5 r.p.s.	4.5 r.p.s.

- Automatic resolution switching, 12-bit setting and 10-bit setting are selected by the RR parameter.

9.1.9.3. Reading the Present Position

(1) Reading the position scale live value in the units of pulse




The position scale value is displayed continuously in the units of pulse. Moving the Motor's rotor changes the value on the display.



Press the BS key to end the display.

(2) Reading the position scale live value in the units of 1/100 degree



The position scale value is displayed continuously in the units of 1/100 degree. Moving the Motor's rotor changes the value on the display.



Press the BS key to end the display.

9.2. To Have More Advanced Operation

9.2.1. Position Scale

- The ESA23 Driver Unit has a position scale for positioning and overtravel limit.

9.2.1.1. Resolution

- The Motor resolver has teeth for detecting its position, and each tooth is digitally divided into 4096. In other words, the resolution of Motor position detection is $4096 \times$ number of teeth per turn.
- Table 9-7 lists Motor series and the resolution.

Table 9-7

Motor series	Number of teeth	Resolution [pulses / rotation]
YS, JS1, JS2, RS	150	614400
SS type	120	491520
AS, BS, JS0	100	409600

9.2.1.2. Direction of Position Scale

Caution : For your safety, the direction of the hardware overtravel limits are fixed to the following regardless of the DI setting :

OTP : CW direction

OTM : CCW direction

- The direction of position scale counting can be switched by the DI command.

Table 9-8

DI setting	CW direction	CCW direction
DI0*	Plus direction	Minus direction
DI1	Minus direction	Plus direction

* : Shipping set

- When the position scale direction is set, the directions of operations performed by the following functions are also determined.
 - Pulse train operation
 - Positioning via communication (IR, ID, AR, AD, HS)
 - Programmable indexer
 - Home return
 - Jog
 - Software overtravel limit

9.2.1.3. Position Scale Types

- Three types of position scale are available for the user to select the appropriate type for each purpose. Position scale type can be switched by setting the PS command.

Table 9-9


PS setting	Type of position scale	Application
PS0	Linear position scale	Ball screw driving, with overtravel limit control, etc.
PS1*	Single-rotation position scale	General indexer, etc.
PS2-99	Multi-rotation position scale	Chain driving, etc.

* : Shipping set

(1) Linear Position Scale

- This position scale extends linearly from the origin in both plus and minus directions.
- Scale values range from $-2,147,483,648$ [pulses] to $+2,147,483,647$ [pulses] with the origin at 0. The coordinate value increases in the plus direction. When it exceeds $+2,147,483,647$ [pulses], the value returns to $-2,147,483,648$ [pulses]. Falling below $-2,147,483,648$ [pulses], the value returns to $+2,147,483,647$ [pulses].


Figure 9-14 : Linear position scale



(2) **Rotation Position Scale**

- Scale starts from the home position (origin) and extends only in the plus direction. The coordinate value returns to 0 after a 360° turn.
 - Motor Series : YS, JS1, JS2 and RS
Coordinate values from 0 ~ 614399 [pulses]
 - Motor Series : SS
Coordinate values from 0 ~ 491519 [pulses]
 - Motor Series : AS, BS and JS0
Coordinate values from 0 ~ 409599 [pulses]


Figure 9-15 : Single-rotation position scale



(3) Multi-Rotation Position Scale

- Scale starts from the home position (origin) and extends only in the plus direction. The value returns to 0 after making the number of revolutions set by “PS” command.
 - Motor Series : YS, JS1, JS2 and RS
 - Coordinate values range from 0 to $\{614400 \times (\text{PS data}) - 1\}$
 - Motor Series : SS
 - Coordinate values range from 0 to $\{491520 \times (\text{PS data}) - 1\}$
 - Motor Series : AS, BS and JS0
 - Coordinates values range from 0 to $\{409600 \times (\text{PS data}_- - 1)\}$

Figure 9-16 : Multi-rotation position scale



9.2.1.4. Position Scale Reset

- Caution** :
- The position scale value is not decided immediately after the power is turned on. Be sure to reset the position scale before positioning.
 - The position scale value is reset to 0 by the following operations.
 - Home return finish
 - AZ command input

9.2.1.5. Position Scale Setting Example

(1) Set the CCW direction of the position scale as the plus direction.

①

/	N	S	K	SP
O	N	ENT		

Input the password.
The password acknowledgment message appears on the display.

➔

```

:
:/NSK ON
NSK ON
:_

```

②

D	I	1 #	ENT
---	---	-----	-----

Input the DI command to determine the position scale direction.

➔

```

:/NSK ON
NSK ON
:DI1
:_

```

(2) Setting the linear position scale

①

/	N	S	K	SP
O	N	ENT		

Input the password.
The password acknowledgment message appears on the display.

➔

```

:
:/NSK ON
NSK ON
:_

```

②

P	S	0 ?	ENT
---	---	-----	-----

Input the PS command to determine the type of position scale.

➔

```

:/NSK ON
NSK ON
:PS0
:_

```

(3) Resetting the position scale value

①

/	N	S	K	SP
O	N	ENT		

Input the password.
The password acknowledgment message appears on the display.

➔

```

:
:/NSK ON
NSK ON
:_

```

②

A	Z	ENT
---	---	-----

Input the AZ command to reset the position scale value.

➔

```

:/NSK ON
NSK ON
:AZ
:_

```

9.2.2. Digital Filter

Caution : • Inserting multiple filters may cause phase inversion in some systems, resulting in unstable operation.

- Do not insert more than two filters. Setting a filter frequency too low may cause hunting, etc.; set the frequency to 100 Hz or above.

Parameters for digital filter setting


- Parameters : FP, FS, NP
 - Sets filter frequency in the velocity loop.
 - The filters are useful for eliminating audible noise and vibration due to mechanical resonances.

Table 9-10 : Parameter function

Parameter	Function	Shipping set
FP	Sets the primary low-pass filter frequency	FP0
FS	Sets the secondary low-pass filter frequency	FS0
NP	Sets the primary notch filter frequency	NP0

- Refer to Chapter 12 “Command and Parameter” for more details.


Figure 9-17 : Digital filter block diagram



9.2.3. Feed Forward Compensation

- Parameter “FF” sets feed forward compensation gain. The password is necessary when setting.
- Shipping set of “FF” is FF0.
- The feed forward compensation function generates a velocity command by differentiating the position command, then adds it to the velocity loop in the forward direction.
- Feed forward compensation improves follow-up delay during acceleration/deceleration.
- Setting the FF parameter to a higher value improves follow-up delay, but overshoot becomes more likely to occur. It is generally recommended that the parameter be set to 0.5 or below.

Figure 9-18 : Feed Forward Compensation Block Diagram



9.2.4. Integrator Limiter : ILV

- Parameter “ILV” sets the upper limit to the velocity gain. Shipping set is ILV100.
- The password is necessary when setting “ILV”.
- Integrator limiter reduces overshoot caused by the integrator during high acceleration / deceleration.
- The integrator is indispensable for high-precision positioning. However, when a high-speed acceleration/ deceleration is specified, errors are likely to accumulate so that integration often results in an overshoot. To prevent this, an integrator limiter is provided to restrict an excessive integration.

* For more details about the parameter, refer to “11. Command and Parameter.”

Figure 9-19 : Integrator limiter block diagram






Figure 9-20



9.2.5. Dead Band Setting : DBP

- The DBP parameter sets a dead band, centered at “0” to error in the position loop. When the position error value is below the specified dead band value, the position command is set to 0.
- In some systems, microvibrations may be caused by a slight error in positioning. In this case, microvibrations can be prevented by setting a dead band.
- Setting a dead band reduces microvibrations but lowers repeatability by the set value.
- The dead band is set in the units of pulse (equivalent to the resolver resolution with 12-bit specification : refer to “4.2.2.2. Function Specifications, resolver resolution.”) When the resolver resolution setting is 10-bit, set the dead band value by a multiple of 4.

Figure 9-21 : Dead Band Setting Block Diagram



9.3. RS-232C Communication

9.3.1. Communication Specification

- Setting of various parameters, trial running, and adjustment are enabled by issuing commands to the Driver Units through serial communication (i.e., communication through the RS-232C interface).
- The Driver Unit has CN1 as the input/output ports for RS-232C communication.
- When the Handy Terminal (FHT11) is not in use, set the MM parameter to 0.
 - MM1 : Standard setting (for the Handy Terminal)
 - MM0 : For connection with a personal computer

Table 9-11 : RS-232C communication specification


Item	Specification
Transmission	Asynchronous, full duplex
Communication speed	9600 b.p.s.
Word length	8 bit
Stop bit	2 bit
Parity	No
Character code	ASCII code
Communication procedure	<ul style="list-style-type: none">● X-On/Off Protocol: No● RTS/CTS Control: Yes

9.3.2. Communication Procedure

9.3.2.1. When Power is Turned ON

- If a terminal (such as NSK Handy Terminal FHT11) is connected to CN1 and the Driver Unit power is turned on, the message shown below is displayed.
- The contents (and the number of characters) of this message may differ with Driver Unit setting and system versions.
- When the Driver Units are initialized, a colon (:) is displayed and the system waits for a command to be entered. The colon (:) is called a prompt.


Figure 9-22 : Power-on message



9.3.2.2. Command Entry


- A communication command shall consist of “a command (character string) + data (if necessary) + carriage return code (0DH).”
- If the velocity gain is to be set to 0.5, for example, “VG0.5” should be entered by adding data of 0.5 to a VG command. The characters of this command with data are transmitted to the Driver Unit as shown below :

Figure 9-23 : Example Of VG0.5



- Every time a character is input, the Driver Unit echoes the character back to the terminal. (The Driver Unit returns the same character that it receives.)
- However, the Driver Unit converts carriage return code to “carriage return code (0DH) + line feed code (0AH),” then returns it to the terminal.
- When a carriage return code is input, the Driver Unit decodes a character string which it has received (VG0.5 in the example above) and executes it. Therefore, a command is not executed unless it ends with a carriage return code.
- If the Driver Unit can decode an entered command, it returns “:” immediately after the line feed code. If it receives a internal data read command, etc., it returns the data before “:”.


Figure 9-24 : Successful input example



9.3.2.3. Password

- Among the communication commands used for this System, some special commands (such as AB, PA, SI, etc.) require password entry for preventing erroneous entries. These commands cannot be entered in the same manner as other commands.
- The password is /NSK ON (a space between K and O) as shown below. If the Driver Unit accepts it, it returns an “NSK ON” message.
- A command requiring password entry may only be executed immediately after the password is entered.

Figure 9-25 : Password Example



9.3.2.4. Cancelling Command

- A command which has been entered halfway, entering a backspace code (08H) can cancel a character or a entered full character string. Parameter “backspace mode” (BM) sets the cancelling method.

BM0 : a backspace code cancels an entered character string.


BM1 : a backspace code cancels a character.

[When the Handy Terminal FHT11 is used, press the backspace (BS) key.]

(1) Parameter “BM1” (Shipping set)

- For example, when the backspace code is input following VG0.5, the cursor moves one space back to the position where 5 was input and thereby deletes 5.


Figure 9-26 : Cancelling example (BM1)



(2) Parameter “BM0”

- For example, when the backspace code is input following VG0.5, a message “VG0.5?” and a colon “:” are displayed and there by delete “VG0.5”.

Figure 9-27 : Cancelling example (BM0)




9.3.2.5. Error

- Note that an error occurs in any of the following cases :
 - (1) If a nonexistent command (i.e., character string) is entered (If an entered character string cannot be decoded).
 - (2) If data or subscript out of the allowable range is entered.
 - (3) If a command requiring the password is entered without the password.
- In any of these cases, the entered character string with a ‘?’ mark is returned as an error message.

● **For example,**


Figure 9-28 : Input error example 1



- (4) If the input condition is not met when entering a command.
 - In this case, the entered character string with “INHIBITED” is returned.

● **For Example,**

Figure 9-29 : Input error example 2




9.3.2.6. Readout Command

- If a command for reading the internal state (i.e., parameter set values, current position, etc.) of the Driver Unit among the communication commands of this system is entered, the Driver Unit returns data, etc.
- Returned data consists of “space code (20H) + read value, data + carriage return (0DH) + line feed code (0AH)”.

● **For example,**


(1) TS command for reading set value

Figure 9-30 : TS command example




(2) If set value reading function ? is used

Figure 9-31 : “?” function example



(3) TP command for reading current position data


Figure 9-32 : TP command example



9.3.3. Daisy-Chain Communication


- Daisy-chain communication allows multiple Driver Units (up to 16 units) to be connected with a single RS-232C terminal.

Figure 9-33 : Daisy chain communication overview



9.3.3.1. Procedure to Set Daisy-chain Communication

Figure 9-34 : Daisy-chain communication setting procedure



9.3.3.2. Initial Setting

- The password is necessary for inputting initial setting parameters.
- The initial setting values become valid when the power is turned on next time.
- Perform initial setting before making multi-axis connection.

Table 9-12 : Initial setting


Item	RS-232C parameter	Data range	Shipping set	Function
Daisy-chain communication, axis number setting	AN data	0~15	0	The set data becomes the axis number of multi-axis communication.
Daisy-chain communication mode selection	CM data	0, 1	0	CM0: standard (single driver) communication, CM1: daisy-chain communication

9.3.3.3. Interfacing

(1) Connecting data communication lines

- Connect data communication lines sequentially : First connect the output of the terminal with the input of axis 0, then connect the output of axis 0 with the input of axis 1 and so forth. (See Figure 9-35.)
- Connect the output of the final axis with the input of the terminal.


Figure 9-35 : Data line connection



(2) **Connecting data transmission request lines**

- Connect data transmission request lines sequentially : First connect the input of the terminal with the output of axis 0, then connect the input of axis 0 with the output of axis 1 and so forth. (See Figure 9-36.)
- Connect the input of the final axis with the output of the terminal.


Figure 9-36 : Request-to-send Line Connection



Actual Connection Example

- When NSK's Handy Terminal is in use, connect the lines as shown in Figure 9-37.
- Refer to "5.1. CN1 : RS-232C Serial Communication Connector" for the specification of CN1.

Figure 9-37 : Handy Terminal Connection Example



* : The communication signal name on the Handy Terminal is opposite to that on the Driver Unit (e.g. RXD—TXD).


9.3.3.4. Power On

Caution : • If the Handy Terminal is not used, turn on power in the order of the RS-232C terminal and Driver Units.

• Turn on the power for all Drivers simultaneously (if all the axes cannot be turned on at once, be sure to design the system so that the power of the Driver Unit axis No. 0 turns on at the end.)


- When the Driver Unit of axis No.0 is turned on, an AS command is executed to check for connection.
- If all the terminal and units are connected properly, the following message is displayed (the following examples shows a 3-axis configuration)

Figure 9-38



- If connection is improper, the following message may be displayed.
- The following message example shows a case where axis No.1 and axis No.2 are connected improperly.

Figure 9-39



- If the proper message is not displayed, check for connection order, initial settings (AN parameter, CM parameter), and cable connection.


9.3.3.5. Operation

Selection of Driver Unit to Communication

- In daisy-chain mode, the RS-232C terminal is capable of communication through a single driver unit.
- Use an AX command to select one of the Driver Units connected for daisy-chain communication.


Caution : Do not select any unit that is not connected. Otherwise, operation may hang up. To return to the normal state, press the BS key, then select the number of a connected driver unit.

Figure 9-40




- An axis selected for communication may be checked by issuing a ?AX command. The axis is displayed in the same manner as it is selected.

Figure 9-41



Example of Daisy-chain Communication

Figure 9-42: Example of Daisy-chain Communication



10. Positioning

10.1. Preparation

10.1.1. Wiring Check


Caution : Before operation, check the followings.

Table 10-1 : Check list

	Check item	Confirmation
1	Connection of Main power and Input/Output cables	<ul style="list-style-type: none"> • All wiring is properly arranged and completed. • Terminal block screws are securely fastened. • All connectors are connected and locked properly.
2	Cable Set	<ul style="list-style-type: none"> • Cable Set (Motor and Resolver cables) is connected and locked properly.
3	Handy Terminal	<ul style="list-style-type: none"> • Handy Terminal (FHT11) is connected and locked to CN1 connector.

10.1.2. Procedure

Figure 10-1




10.2. Home Return

- Be sure to perform the home return at all times except when user's controller is performing coordinate system control. The origin cannot be determined unless the home return is performed.
- The positioning and software overtravel limits are set in the position scale determined by the home return operation.
- The origin of the position scale is set at the point at which the home return completes.

Caution : Position data disappears after the power is turned off, so perform the home return each time you turn on the Driver Unit power.

Figure 10-2 : Home Return sequence



- Make the Motor Servo-on. (SVON input on)
- Turning the HOS input ON will start the home return. (①)
- The Motor turns CCW*. When it enters HLS (Origin proximity) area (②), it decelerates and stops momentarily, then reverses its rotational direction. (③) The Motor goes out HLS range once, then reverses again and enters HLS area at the origin search velocity. (④) It moves to the first point where the resolver value becomes 0 (= rising edge of the øZ) and completes the home return.

* The direction of rotation can be changed with the parameter HD (Home return direction).


HD0 : CW

HD1 : CCW (Shipping set)

- If the home offset value HO is set, the Motor moves farther past the resolver 0 point by the offset value, then completes the home return operation.
- Home return can be also executed with the following ways.
 - Select the channel where HS command is set and input RUN command.
 - Execute RS command through RS-232 communication.

- The home return movement differs as shown in Figure 10-3 according to the starting point of home return.

Figure 10-3



*: When the home return direction is reversed by the HD parameter, CW and CCW as well as OTP and OTM are reversed as follows : CW → CCW, OTP → OTM.

10.2.1. Home Return Parameter List

Table 10-2 : Motor series : YS, JS1, JS2 and RS

Parameter function	RS-232C Parameter	Unit	Data input range	Shipping set
Home Return Acceleration	HA	r.p.s./s	0.01~40.00	1.00
Home Return Velocity	HV	r.p.s.	0.01~3.00	0.2
Home Position Offset	HO	pulse	0~610304	0
Home Return Direction	HD	—	0: CW, 1: CCW	1
Home Return Near-Zero Velocity	HZ	r.p.s.	0.01~0.20	0.01

Table 10-3 : Motor series : SS

Parameter function	RS-232C Parameter	Unit	Data input range	Shipping set
Home Return Acceleration	HA	r.p.s./s	0.01~50.00	1.00
Home Return Velocity	HV	r.p.s.	0.01~3.75	0.2
Home Position Offset	HO	pulse	0~487424	0
Home Return Direction	HD	—	0: CW, 1: CCW	1
Home Return Near-Zero Velocity	HZ	r.p.s.	0.01~0.25	0.01

Table 10-4 : Motor series : AS, BS and JS0


Parameter function	RS-232C Parameter	Unit	Data input range	Shipping set
Home Return Acceleration	HA	r.p.s./s	0.01~60.00	1.00
Home Return Velocity	HV	r.p.s.	0.01~4.50	0.2
Home Position Offset	HO	pulse	0~405504	0
Home Return Direction	HD	—	0: CW, 1: CCW	1
Home Return Near-Zero Velocity	HZ	r.p.s.	0.01~0.30	0.01

10.2.2. Adjusting the Home Limit Switch and Home Offset Value

- To accurately perform the home return, the home position sensor (sensor and dog) must be adjusted properly.
- The resolver has teeth for detecting its position and the rising edge of HLS is to define a teeth. To make precise detection of ϕZ , the home limit switch position must be adjusted so that the HLS input goes high when the switch is at the middle center of the tooth width. Design the home limit switch so that it can be adjusted $\pm 1.2^\circ$ or more in relation to the tooth width.
- Take the following steps to adjust the position of the home limit switch.

<Operation> Adjusting the home limit switch position

- (1) Loosely mount the HLS sensor (home limit switch) slightly preceding a point to be the origin.
- (2) Check the wiring of the HLS sensor. Execute the IO command and check if the ESA23 Driver Unit is reading the HLS input correctly.
- (3) Adjust the position of the home position sensor. First, make the Motor servo-on, then execute the HS/LS command. At this time, be careful that the Motor starts the home return operation and thereby rotates. By using Handy Terminal, take the following steps :




Press the ENT key to start Motor rotation.
The Motor stops as soon as the HLS sensor goes on.
The Handy Terminal displays the TR value (i.e., number of pulses from the closest ϕZ rising edge) of the Motor's present position.


Check that this value is in the following range: between 1000 and 3000

If the TR value is not in this range, loosen the HLS sensor and move it CW or CCW direction.
Repeat steps ① and ② until the TR value is within the above range.

Note : When installing the HLS sensor, be sure to adjust its position as mentioned above. Otherwise, positioning may not be performed correctly.



Input the MO command (servo-off command).



Press the ENT key to execute the command and thereby turn off the Motor servo.
At this time, the Motor can be turned easily by hand. Turn the Motor to the desired position.
Do not give the Motor more than one turn.

- ⑤ Input the password.
- / N S K SP
O N
- ⑥ ENT
- ⑦ H O / S T
Input the HO/ST command.
- ⑧ ENT
Press the ENT key to execute the command. When the “:_” prompt appears on the display, Home offset HO value is automatically calculated and set.
- ⑨ Input the SV command (servo-on command.)
S V
- ⑩ Press the ENT key to execute the command and there by turn on the Motor servo.
ENT
The “:_” prompt appears when the Driver Unit is ready to accept another input.
- ⑪ Input the HS command (home return start command).
H S
- ⑫ Press the ENT key to execute the command and there by start the home return operation.
ENT
Check that the Motor stops at the desired origin point.
- TR2003
OK
:MO
:/NSK ON_
- :MO
:/NSK ON
NSK A command can be
:_ entered only on this line
- :MO
:/NSK ON
NSK ON
:HO/ST_
- NSK ON
:HO/ST
HO1234
:_
- NSK ON
:HO/ST
HO1234
:SV_
- :HO/ST
HO1234
:SV
:_
- :HO/ST
HO1234
:SV
:HS_
- HO1234
:SV
:HS
:_

10.2.3. Programming the Home Return Operation (example)

(1) Programming the home return command in channel 0 (CH0)

- When the I/O type is not TY4, there is no home return start (HOS) input in the CN2 connector. In this case, program the home return command in a Programmable Indexer channel. Then, start the operation by activating the channel (i.e., RUN input ON).

- ① Input the CH0 channel select command.

C **H** **0 ?** **ENT**

The “?” prompt appears to wait for data input. If data is already programmed in CH0, the registered data appears on the display.

⤵

```

:
:
:CH0
?_
    
```

- ② Enter the home return start command.

H **S** **ENT**

⤵

```

:
:CH0
?HS
?_
    
```

- ③ When the “?” prompt appears again, press the **ENT** key.

ENT

This completes the programming in CH0.

⤵

```

:CH0
?HS
?
:_
    
```

(2) Home return trial operation

- Set the home return acceleration HA, home return velocity HV or home return offset HO.
- Then take the following steps to perform the trial operation.

- ① Make the Motor servo-on.

- ② Following the prompt “:” input the programmable indexer channel indexer execution command.

S **P** **0** **ENT**

The Motor starts the home return operation.

⤵

```

:
:
:SP0
:_
    
```

10.3. Programmable Indexer


- Positioning command can be stored to the channel of the Driver Unit. Programmable Indexer is to execute the stored positioning program by selecting the channel via PRG0 ~ PRG3 input and RUN command.
- Set the system to servo-on. (SVON input ON)
- Select the channel (Input PRG0 ~ PRG3, CN2 signal)
- By inputting RUN command ON, the Motor execute stored positioning program while IPOS output is closed. (When FW=0)
- While the Motor is performing the positioning operation, the RUN input is ignored.
- Input the command “SP” to execute the Programmable Indexer. (Same function as inputting RUN command ON.)

Type



To execute the channel “m” program. (m : channel number)

Figure 10-4 : Programmable indexer command timing



- When a non-programmed channel is selected, the program error alarm will be ON. (Refer to “13. Alarms”)

10.3.1. Programmable Indexer Channel Switching

(1) I/O type : TY1

- The channel to be executed is selected by combining the on and off states of the PRG0 to PRG3 inputs.

Table 10-5 : 16-Channel selection

PRG3 input	PRG2 input	PRG1 input	PRG0 input	Selected channel No.
off	off	off	off	CH0
off	off	off	on	CH1
off	off	on	off	CH2
off	off	on	on	CH3
off	on	off	off	CH4
off	on	off	on	CH5
off	on	on	off	CH6
off	on	on	on	CH7
on	off	off	off	CH8
on	off	off	on	CH9
on	off	on	off	CH10
on	off	on	on	CH11
on	on	off	off	CH12
on	on	off	on	CH13
on	on	on	off	CH14
on	on	on	on	CH15

(2) I/O type : TY2 and TY3

- The channel to be executed is selected by combining the on and off states of the PRG2 and PRG3.

Table 10-6 : 4-Channel selection

PRG3 input	PRG2 input	PRG1 input	PRG0 input	Select channel No.
off	off	(Always off)		CH0
off	on			CH4
on	off			CH8
on	on			CH12

- The channels other than CH0, 4, 8 and 12 remain in the program area. These channels can be used for channel step function (&) and jump command (JP).

(3) I/O type : TY4 and TY7

- Only channel CH0 is available for storing positioning program.
- The channel other than CH0 remain in the program area. These channels can be used for channel step function (&) and jump command (JP).

10.4. Pulse Train Command

10.4.1. Pulse Train Signal Format

- Input a pulse train from CWP and CCWP of CN2 signal.
- Set the pulse train input signal format with the PC parameter (via RS-232C communication). (The password must be input prior to the PC parameter setting.)


Table 10-7 : Signal format

PC Parameter	CWP input	CCWP input	Function
PC0 (shipping set)	• Input CW pulse.	• Input CCW pulse.	CW & CCW format
PC1	• Input the direction. ON : CCW OFF : CW	• Input pulse train	Pulse & direction format
PC2	• Input ϕB	• Input ϕA	$\phi A/\phi B$ format ($\times 1$)
PC3			$\phi A/\phi B$ format ($\times 2$)
PC4			$\phi A/\phi B$ format ($\times 4$)

10.4.2. Pulse Train Resolution

- Set the resolution of the pulse train with the CR parameter (via RS-232C).
- In the case of $\phi A/\phi B$ input, the pulse train resolution is multiplied by the PC parameter value, then by the CR parameter value.
- Refer to Table 10-5, 6 and 7 for the concrete data of resolution.

Figure 10-5 : Pulse train resolution setting



(1) **YS, JS1, JS2 and RS Motor series**

Table 10-8 : Pulse train resolution (YS, JS1, JS2 and RS Motor series)

CR Parameter	Resolver resolution	Resolution (pulses/360°) = number of pulses necessary for giving the Motor one turn		
		CW & CCW format, Step & Direction format	$\phi A/\phi B$ format	
CR × 1 (Shipping set)	12-bit or 12-bit/10-bit automatic resolution switching	614400	× 1	614400
			× 2	307200
			× 4	153600
	10bit	153600	× 1	153600
			× 2	76800
			× 4	38400
CR × 2	12-bit or 12-bit/10-bit automatic resolution switching	307200	× 1	307200
			× 2	153600
			× 4	76800
	10bit	76800	× 1	76800
			× 2	38400
			× 4	19200
CR × 4	12-bit or 12-bit/10-bit automatic resolution switching	153600	× 1	153600
			× 2	76800
			× 4	38400
	10bit	38400	× 1	38400
			× 2	19200
			× 4	9600
CR360000	12-bit/10-bit automatic resolution switching	360000	× 1	360000
			× 2	180000
			× 4	90000
CR36000	12-bit/10-bit automatic resolution switching	36000	× 1	36000
			× 2	18000
			× 4	9000
CR3600	12-bit/10-bit automatic resolution switching	3600	× 1	3600
			× 2	1800
			× 4	900

(2) **SS Motor series**

Table 10-9 : Pulse train resolution

CR Parameter	Resolver resolution	Resolution (pulses/360°) = number of pulses necessary for giving the Motor one turn		
		CW & CCW format, Step & Direction format	øA/øB format	
CR × 1 (Shipping set)	12-bit or 12-bit/10-bit automatic resolution switching	491520	× 1	491520
			× 2	245760
			× 4	122880
	10bit	122880	× 1	122880
			× 2	61440
			× 4	30720
CR × 2	12-bit or 12-bit/10-bit automatic resolution switching	245760	× 1	245760
			× 2	122880
			× 4	61440
	10bit	61440	× 1	61440
			× 2	30720
			× 4	15360
CR × 4	12-bit or 12-bit/10-bit automatic resolution switching	122880	× 1	122880
			× 2	61440
			× 4	30720
	10bit	30720	× 1	30720
			× 2	15360
			× 4	7680
CR360000	12-bit/10-bit automatic resolution switching	360000	× 1	360000
			× 2	180000
			× 4	90000
CR36000	12-bit/10-bit automatic resolution switching	36000	× 1	36000
			× 2	18000
			× 4	9000
CR3600	12-bit/10-bit automatic resolution switching	3600	× 1	3600
			× 2	1800
			× 4	900


(3) **AS, BS and JS0 Motor series**

Table 10-10 : Pulse train resolution

CR Parameter	Resolver resolution	Resolution (pulses/360°) = number of pulses necessary for giving the Motor one turn		
		CW & CCW format, Step & Direction format	øA/øB format	
CR × 1 (Shipping set)	12-bit or 12-bit/10-bit automatic resolution switching	409600	× 1	409600
			× 2	204800
			× 4	102400
	10bit	102400	× 1	102400
			× 2	51200
			× 4	25600
CR × 2	12-bit or 12-bit/10-bit automatic resolution switching	204800	× 1	204800
			× 2	102400
			× 4	51200
	10bit	51200	× 1	51200
			× 2	25600
			× 4	12800
CR × 4	12-bit or 12-bit/10-bit automatic resolution switching	102400	× 1	102400
			× 2	51200
			× 4	25600
	10bit	25600	× 1	25600
			× 2	12800
			× 4	6400
CR360000	12-bit/10-bit automatic resolution switching	360000	× 1	360000
			× 2	180000
			× 4	90000
CR36000	12-bit/10-bit automatic resolution switching	36000	× 1	36000
			× 2	18000
			× 4	9000
CR3600	12-bit/10-bit automatic resolution switching	3600	× 1	3600
			× 2	1800
			× 4	900

Note : ● In the øA/øB format, one cycle of either øA or øB is defined as “one pulse”.

Figure 10-6




- The resolver resolution is set by the RR parameter (via RS-232C).

10.4.3. Input Timing

Caution : The following specifies the conditions of pulse acceptance timing. Besides these conditions, the Motor operation is restricted by the maximum velocity. Do not input pulses faster than Motor's maximum velocity.


(1) When PC is set to "0" (PC0)

Figure 10-7




(2) When PC is set to 1 (PC1)

Figure 10-8



(3) When PC is set to 2~4 (PC2 ~ PC4)

Figure 10-9



10.5. RS-232C Position Commands

- You can execute indexing using RS-232C commands. The commands/parameters are shown below. Refer to “11. Command and Parameter” for more details.

Table 10-11

Command/parameter	Function
ID command	Sets the amount and executes rotation (incremental/in the units of degree)
IR command	Sets the amount and executes rotation (incremental/in the units of pulse)*
AD command	Sets the target and executes rotation (absolute/in the units of degree)
AR command	Sets the target and executes rotation (absolute/in the units of pulse)*
HS command	Starts the home return.
HV parameter	Sets the home return velocity.
HA parameter	Sets the home return acceleration.
HO parameter	Sets the home offset value.
HD parameter	Specifies the home return direction.
MA parameter	Sets the acceleration, for indexing.
MV parameter	Sets the velocity, for indexing.


* : The table below lists the number of pulses per rotation of the IR command.

Table 10-12: Motor type and resolution

Motor series	Resolution [pulses/rotation]
YS, JS1, JS2, RS	614400
SS	491520
AS, BS, JS0	409600

- Indexing Timing

Figure 10-10: Indexing timing




* : CR stands for the carriage return code (0DH).

- Under SVON state, as soon as the command is input, the Motor starts indexing. The acceleration and velocity follow the settings of parameters “MA” and “MV”.
- If the position error counter value is within the in-position limit (set by IN parameter) after indexing, the IPOS output should be closed.

10.6. Jog Operation

- Jog operation is available when the Driver Unit is set to TYP2 or TYP7.
- Connector CN2 pin arrangement of JOG input and DIR (Jog direction) are not same for type2 and type7 setting. (Refer to “5.2. CN2 : Control I/O connector” for more detail.)
- Set system to servo-on. (SVON input ON)
- Turning on the Jog input makes the Motor start acceleration and rotation. The Motor keeps rotating while the Jog input remains on. When the Jog input is off, the Motor starts decelerating, then stops.
- When the DIR input is off, the Motor turns CW. When the DIR input is on, it turns CCW.
- Jog operation parameter
 - JA : Jog acceleration
 - JV : Jog velocity

Figure 10-11 : Jog operation timing



Note : When the DIR input is switched during Motor rotation as shown in the above chart, the Motor decelerates, then reverses the direction of rotation.

10.7. Programming

- The Driver Unit can store indexing profiles in its memory. To index along the stored indexing motion profile, external input (CN2 connector signal) is used. This function is called “Programmable Indexer”.
- The program of an indexing motion profile can be done via RS-232C communication. (Handy Terminal FHT11 or a personal computer.) The programming can be input only when the Motor is not indexing.
- The program area is shown in Figure 10-12. There are 16 channels ranging from channel 0 to 15.

Figure 10-12

Channel 0	CH0
Channel 1	CH1
⋮	⋮
Channel 15	CH15

10.7.1. Commands and Parameters

● Home return

Command : HS
 Condition setting : None

- Program the home return operation.
- Command format HS seq
 seq: sequence code (*, &)
- The Motor rotates according to the values set by the home return velocity HV, home return acceleration HA, home return near-zero velocity HZ, and to the direction set by home return direction HD.

* Program example
 : CH0
 HS

● Positioning

Command : AD, AR, ID, IR,
 Condition setting : CV, CA, Can be omitted

- Program the Indexing motion profile.


Table 10-13

Command format	Outline	Option
AD d1 d3 seq	<ul style="list-style-type: none"> ● Absolute indexing, in the units of degree. ● The Motor turns to reach the d1 [$\times 0.01^\circ$] position of position scale. 	Option code d3 /PL: CW direction /MI: CCW direction
AR d1 d3 seq	<ul style="list-style-type: none"> ● Absolute indexing in the units of pulse. ● The Motor turns to reach the d1 [pulse] position of position scale. 	<ul style="list-style-type: none"> ● When d3 is omitted, the Motor turns in the shortest-distance direction to reach the d1 position.
ID d1 d2 seq	<ul style="list-style-type: none"> ● Incremental indexing, in the units of degree. ● The Motor makes a d1 [$\times 0.01^\circ$] turn from the present position. 	Option code d2 /n: (n \leq 99)
IR d1 d2 seq	<ul style="list-style-type: none"> ● Incremental indexing in the units of pulse ● The Motor makes a d1 [pulse] turn from the present position. 	<ul style="list-style-type: none"> ● When d2 is specified, the d1 value is equally divided by n. Single RUN input will make motor rotate by the divided amount. ● When d2 is omitted, the d1 value will not be divided.

- seq stands for the sequence code (*, &), which sets the execution condition of the next channel in the sequence.
- Velocity CV and acceleration CA can be set in the same channel. When CV and CA are omitted, the Motor operates according to the values set by MV and MA, respectively.

Figure 10-13

*Program example
 : CH0
 ID9000/2
 CV1.5
 CA5




● Jump

Command : JP
 Condition setting : None

- Unconditional jump command
- Control jumps to the specified channel, and its program will be executed continuously.
- Command format JPm
 m: Jump destination channel No. (default: 0).

Figure 10-14

*Program example
 :CH0
 IR1000&
 :CH1
 IR2000&
 :CH2
 JP0



● Sequence Code

Command : (HS), (AD), (AR), (ID), (IR)
 Condition setting : *, &


- Add a sequence code to the command to continuously execute the next channel. In this case, you do not have to externally select a channel.

Table 10-14

Sequence code	IPOS output	Execution of the next channel
* : asterisk	Yes	Executes next program continuously after positioning is over.
& : ampersand	Yes	Stops after indexing, then waits for RUN command.

Figure 10-15

* Program example
 :CH0
 IR500*
 :CH1
 IR1000&



● Change Sequence code

Condition setting : OE

- OEseq changes the presently set sequence code.

* Program example

:CH0 ①

AR9000&

CV0.5

?OE* ②

?

① Declare the channel whose sequence code is to be changed.

② Input.



:TC0 ③

AR9000* ④

CV0.5

:

③ Check the new data programmed in this channel.

④ The sequence code has changed from "&" to "*".

10.7.2. Program Editing Command

Table 10-15 : Program editing command

Editing	Command	Function
Change program settings	CH	<ul style="list-style-type: none"> • Typing C H m ENT declares the channel to be changed. (m: desired channel number) • The display shows the present program and waits for the changes. (The prompt is in “?” state.) • The last input program or data always becomes valid.
Display program	TC	<ul style="list-style-type: none"> • Typing T C m ENT displays the program in desired channel. (m: desired channel number) • When checking the program in all channels, type T C / A L ENT. • Type [SP] key to scroll to next channel.
Deleting program	CC	<ul style="list-style-type: none"> • Typing T C m ENT deletes the program in the desired channel. (m: desired channel number)

10.7.3. Inputting a Program

Table 10-16 : Inputting a program

Item	Method	Operation example	Display
Programming	<p>① Select a channel to be programmed.</p> <ul style="list-style-type: none"> ○ When a channel is selected, the motion profile presently programmed in the channel appears on the display. ○ Then prompt “?” appears to wait for an input. <p>② Program a command.</p> <p>③ Set conditions according to the command.</p> <p>④ Enter “0” to cancel the input condition.</p> <ul style="list-style-type: none"> ○ (When incorrect data is input, re-enter the correct data. When the same command with different data is input twice, the last input data becomes valid.) <p>⑤ Pressing only <input type="button" value="ENT"/> displays the “:” prompt and ends program setting.</p>	<p><input type="button" value="C"/> <input type="button" value="H"/> <input type="button" value="1 #"/> <input type="button" value="0 ?"/> <input type="button" value="ENT"/></p> <p><input type="button" value="I"/> <input type="button" value="R"/> <input type="button" value="9)"/> <input type="button" value="0 ?"/> <input type="button" value="0 ?"/></p> <p><input type="button" value="0 ?"/> <input type="button" value="/"/> <input type="button" value="1 #"/> <input type="button" value="0 ?"/> <input type="button" value="ENT"/></p> <p><input type="button" value="C"/> <input type="button" value="V"/> <input type="button" value="0 ?"/> <input type="button" value=". ="/> <input type="button" value="5 %"/></p> <p><input type="button" value="ENT"/></p> <p><input type="button" value="C"/> <input type="button" value="A"/> <input type="button" value="0 ?"/> <input type="button" value="ENT"/></p> <p><input type="button" value="ENT"/></p>	<p>:CH10 AR18000 CV0.9 CA2</p> <p>?IR9000/10</p> <p>?CV0.5</p> <p>?CV0</p> <p>? :</p>
Reading data	<p>① Declare the channel to be read.</p> <ul style="list-style-type: none"> ○ Selecting a channel displays the motion profile programmed in the channel. 	<p><input type="button" value="T"/> <input type="button" value="C"/> <input type="button" value="1 #"/> <input type="button" value="0 ?"/> <input type="button" value="ENT"/></p>	<p>:TC10 IR9000/10 CV0.5</p>
Deleting	<p>① Declare the channel whose data is to be deleted.</p> <ul style="list-style-type: none"> ○ Pressing <input type="button" value="ENT"/> deletes the data programmed in the channel. 	<p><input type="button" value="C"/> <input type="button" value="C"/> <input type="button" value="1 #"/> <input type="button" value="0 ?"/> <input type="button" value="ENT"/></p>	<p>: :CC10 :</p>

* : To see the data programmed in all channels, input TC/AL . Press key to scroll to next channel.

10.7.4. Sample Program

- Write the following motion profile in Channel 5.
 - Travel angle 30.00 degrees in the CCW direction
 - Acceleration CA : 5 [r.p.s/s]
 - Velocity CV : 0.5 [r.p.s]

<p>(1) Check that the “:” prompt is displayed on the screen.</p>	➔	:_
<p>(2) C H 5 %</p>	➔	:CH5_
<p>(3) ENT</p> <p>After pressing the ENT key, the data presently programmed in Channel 5 will be shown on the display.</p>	➔	AD27000& CV1.00 CA20.00 ?_
<p>(4) I D - +</p> <p>3 < 0 ? 0 ? 0 ?</p>	➔	AD27000& CV1.00 CA20.00 ?ID-3000_
<p>(5) ENT</p> <p>Press the ENT key to input value, and the “?” prompt appears again.</p>	➔	CV1.00 CA20.00 ?ID-3000 ?_
<p>(6) C A 5 %</p>	➔	CV1.00 CA20.00 ?ID-3000 ?CA5_
<p>(7) ENT</p> <p>Press the ENT key to input value, and the “?” prompt appears again.</p>	➔	CA20.00 ?ID-3000 ?CA5 ?_
<p>(8) C V 0 ? . = 5 %</p>	➔	CA20.00 ?ID-3000 ?CA5 ?CV0.5_
<p>(9) ENT</p> <p>Press the ENT key to input value, and the “?” prompt appears again.</p>	➔	?ID-3000 ?CA5 ?CV0.5 ?_
<p>(10) ENT</p> <p>Press the ENT key again to escape programming. This completes programming.</p>	➔	?CA5 ?CV0.5 ? :_

11. Command and Parameter

11.1. Command and Parameter List

- Connect the Handy Terminal FHT11 to CN1 connector of the Driver Unit. When the display shows “NSK MEGA•••” the system is in the normal state.
- Some parameters shown in Tables 11-1, 11-2 and 11-3 shall be changed according to the actual operating condition from the shipping setting.
- Parameters in a parenthesis () are set at the factory before shipment and are normally fixed. If the setting is to be changed, contact NSK.

* Current Setting

- We recommend writing down the current settings for your future reference. You may need to refer to them when changing the operating conditions or readjusting the system. For your convenience, a parameter and program setting list provided in the last page of this manual.

**

- The setting value varies with the Motor size. These are set at the factory. Do not change the settings.

Table 11-1 : YS, JS1, JS2 and RS Motor standard setting

Parameter	Name	Password	Shipping set	Data range	Current setting *
PG	Position gain	×	0.1	0.010 ~ 1.000	
VG	Velocity gain	×	1.0	0.10 ~ 255.0	
VI	Velocity integrator frequency	×	1.0	0.10 ~ 63.00	
VM	Velocity integrator mode	○	1	0, 1	
LG	Low-velocity gain	×	50	10 ~ 100	
TL	Torque limit	○	100	0 ~ 100	
FO	Low-pass filter off velocity	×	0	0, 0.001 ~ 3.000	
FP	Low-pass filter, Primary	×	0	0, 10 ~ 500	
FS	Low-pass filter, Secondary	×	0	0, 10 ~ 500	
NP	Notch filter, Primary	×	0	0, 10 ~ 500	
DBP	Dead band	○	0	0, 1 ~ 4095	
ILV	Integration limit	○	100	0 ~ 100	
FF	Feed forward gain	○	0	0 ~ 1.0000	
FC	Friction compensation	○	0	0 ~ 2047	
CO	Position error counter over limit	×	50000	0, 1 ~ 99 999 999	
IN	In-position	×	100	0 ~ 99 999 999	
IS	In-position stability timer	×	0	0, 0.3 ~ 100	
FW	FIN width	×	1	0, 0.3 ~ 100	
CR	Circular resolution	○	×1	×1, ×2, ×4, 360000, 36000, 3600	
PC	Pulse command	○	0	0 ~ 4	
RR	Resolver resolution	○	-1	-1, 0, 1	
FD	Feedback direction mode	○	0	0, 1	
FZ	Feedback phase Z configuration	○	0	0, 1	
FR	Feedback signal resolution	○	0	0, 1	
PS	Position scale	○	1	0, 1, 2 ~ 99	
DI	Direction inversion	○	0	0, 1	
OTP	Overtravel limit switch position	○	0	-99999999 ~ 99999999	
OTM	Overtravel limit switch position	○	0	-99999999 ~ 99999999	
MV	Move velocity	×	1	0.01 ~ 3	
MA	Move acceleration	×	1	0.01 ~ 40	
JV	Jog velocity	×	0.10	0.01 ~ 3	
JA	Jog acceleration	×	1	0.01 ~ 40	
HV	Home return velocity	×	0.2	0.01 ~ 3	
HA	Home return acceleration	×	1	0.01 ~ 40	
HZ	Home return acceleration	×	0.01	0.01 ~ 0.2	
OS	Origin setting mode	○	4	1, 3, 4, 5	
HD	Home return direction	○	1	0, 1	
HO	Home offset	○	0	-610 304 ~ 610 304	
(PA)	Phase adjust	○	700	-	
(OL)	Overload limit	○	**	**	
(RC)	Rated current	○	**	**	
LR	Low torque ripple	○	0	0, 1	
TY	I/O type	○	1	1, 2, 3, 4, 7	
AB	I/O polarity	○	X0X0XX00	0, 1, X	
SM	[SVON] function switching	○	1	1, 2, 3	
NW	Neglect width	○	2	0 ~ 4	
MM	Multi-line Mode	○	1	0, 1	
BM	Backspace mode	○	1	0, 1	
CM	Communication mode	○	0	0, 1	
AN	Axis number	○	0	0 ~ 15	
LO	Load inertia	×	0	0.000 ~ 50.000	
SG	Servo gain	×	0	0 ~ 30	
(MT)	Factory use only	○	-	-	
(RI)	Factory use only	○	-	-	
(ZP)	Factory use only	○	1.00	-	
(ZV)	Factory use only	○	1.4	-	

Table 11-2 : SS Motor standard setting

Parameter	Name	Password	Shipping set	Data range	Current setting *
PG	Position gain	×	0.1	0.010 ~ 1.000	
VG	Velocity gain	×	1.0	0.10 ~ 255.0	
VI	Velocity integrator frequency	×	1.0	0.10 ~ 63.00	
VM	Velocity integrator mode	○	1	0, 1	
LG	Low-velocity gain	×	50	10 ~ 100	
TL	Torque limit	○	100	0 ~ 100	
FO	Low-pass filter off velocity	×	0	0, 0.001 ~ 3.000	
FP	Low-pass filter, Primary	×	0	0, 10 ~ 500	
FS	Low-pass filter, Secondary	×	0	0, 10 ~ 500	
NP	Notch filter, Primary	×	0	0, 10 ~ 500	
DBP	Dead band	○	0	0, 1 ~ 4095	
ILV	Integration limit	○	100	0 ~ 100	
FF	Feed forward gain	○	0	0 ~ 1.0000	
FC	Friction compensation	○	0	0 ~ 2047	
CO	Position error counter over limit	×	50000	0, 1 ~ 99 999 999	
IN	In-position	×	100	0 ~ 99 999 999	
IS	In-position stability timer	×	0	0, 0.3 ~ 100	
FW	FIN width	×	1	0, 0.3 ~ 100	
CR	Circular resolution	○	×1	×1, ×2, ×4, 360000, 36000, 3600	
PC	Pulse command	○	0	0 ~ 4	
RR	Resolver resolution	○	-1	-1, 0, 1	
FD	Feedback direction mode	○	0	0, 1	
FZ	Feedback phase Z configuration	○	0	0, 1	
FR	Feedback signal resolution	○	0	0, 1	
PS	Position scale	○	1	0, 1, 2 ~ 99	
DI	Direction inversion	○	0	0, 1	
OTP	Overtravel limit switch position	○	0	-99999999 ~ 99999999	
OTM	Overtravel limit switch position	○	0	-99999999 ~ 99999999	
MV	Move velocity	×	1	0.01 ~ 3.75	
MA	Move acceleration	×	1	0.01 ~ 50	
JV	Jog velocity	×	0.10	0.01 ~ 3.75	
JA	Jog acceleration	×	1	0.01 ~ 50	
HV	Home return velocity	×	0.2	0.01 ~ 3.75	
HA	Home return acceleration	×	1	0.01 ~ 50	
HZ	Home return acceleration	×	0.01	0.01 ~ 0.2	
OS	Origin setting mode	○	4	1, 3, 4, 5	
HD	Home return direction	○	1	0, 1	
HO	Home offset	○	0	-487 424 ~ 487 424	
(PA)	Phase adjust	○	700	-	
(OL)	Overload limit	○	**	**	
(RC)	Rated current	○	**	**	
LR	Low torque ripple	○	0	0, 1	
TY	I/O type	○	1	1, 2, 3, 4, 7	
AB	I/O polarity	○	X0X0XX00	0, 1, X	
SM	[SVON] function switching	○	1	1, 2, 3	
NW	Neglect width	○	2	0 ~ 4	
MM	Multi-line Mode	○	1	0, 1	
BM	Backspace mode	○	1	0, 1	
CM	Communication mode	○	0	0, 1	
AN	Axis number	○	0	0 ~ 15	
LO	Load inertia	×	0	0.000 ~ 50.000	
SG	Servo gain	×	0	0 ~ 30	
(MT)	Factory use only	○	-	-	
(RI)	Factory use only	○	-	-	
(ZP)	Factory use only	○	1.00	-	
(ZV)	Factory use only	○	1.4	-	

Table 11-3 : AS, BS and JSO Motor standard setting

Parameter	Name	Password	Shipping set	Data range	Current setting *
PG	Position gain	×	0.1	0.010 ~ 1.000	
VG	Velocity gain	×	1.0	0.10 ~ 255.0	
VI	Velocity integrator frequency	×	1.0	0.10 ~ 63.00	
VM	Velocity integrator mode	○	1	0, 1	
LG	Low-velocity gain	×	50	10 ~ 100	
TL	Torque limit	○	100	0 ~ 100	
FO	Low-pass filter off velocity	×	0	0, 0.001 ~ 3.000	
FP	Low-pass filter, Primary	×	0	0, 10 ~ 500	
FS	Low-pass filter, Secondary	×	0	0, 10 ~ 500	
NP	Notch filter, Primary	×	0	0, 10 ~ 500	
DBP	Dead band	○	0	0, 1 ~ 4095	
ILV	Integration limit	○	100	0 ~ 100	
FF	Feed forward gain	○	0	0 ~ 1.0000	
FC	Friction compensation	○	0	0 ~ 2047	
CO	Position error counter over limit	×	50000	0, 1 ~ 99 999 999	
IN	In-position	×	100	0 ~ 99 999 999	
IS	In-position stability timer	×	0	0, 0.3 ~ 100	
FW	FIN width	×	1	0, 0.3 ~ 100	
CR	Circular resolution	○	×1	×1, ×2, ×4, 360000, 36000, 3600	
PC	Pulse command	○	0	0 ~ 4	
RR	Resolver resolution	○	-1	-1, 0, 1	
FD	Feedback direction mode	○	0	0, 1	
FZ	Feedback phase Z configuration	○	0	0, 1	
FR	Feedback signal resolution	○	0	0, 1	
PS	Position scale	○	1	0, 1, 2 ~ 99	
DI	Direction inversion	○	0	0, 1	
OTP	Overtravel limit switch position	○	0	-99999999 ~ 99999999	
OTM	Overtravel limit switch position	○	0	-99999999 ~ 99999999	
MV	Move velocity	×	1	0.01 ~ 4.5	
MA	Move acceleration	×	1	0.01 ~ 60	
JV	Jog velocity	×	0.10	0.01 ~ 4.5	
JA	Jog acceleration	×	1	0.01 ~ 60	
HV	Home return velocity	×	0.2	0.01 ~ 4.5	
HA	Home return acceleration	×	1	0.01 ~ 60	
HZ	Home return acceleration	×	0.01	0.01 ~ 0.2	
OS	Origin setting mode	○	4	1, 3, 4, 5	
HD	Home return direction	○	1	0, 1	
HO	Home offset	○	0	-405 504 ~ 405 504	
(PA)	Phase adjust	○	700	-	
(OL)	Overload limit	○	**	**	
(RC)	Rated current	○	**	**	
LR	Low torque ripple	○	0	0, 1	
TY	I/O type	○	1	1, 2, 3, 4, 7	
AB	I/O polarity	○	X0X0XX00	0, 1, X	
SM	[SVON] function switching	○	1	1, 2, 3	
NW	Neglect width	○	2	0 ~ 4	
MM	Multi-line Mode	○	1	0, 1	
BM	Backspace mode	○	1	0, 1	
CM	Communication mode	○	0	0, 1	
AN	Axis number	○	0	0 ~ 15	
LO	Load inertia	×	0	0.000 ~ 50.000	
SG	Servo gain	×	0	0 ~ 30	
(MT)	Factory use only	○	-	-	
(RI)	Factory use only	○	-	-	
(ZP)	Factory use only	○	1.00	-	
(ZV)	Factory use only	○	1.4	-	

11.2. Detail of Command and Parameter

- “Shipping set” denotes a value which is set at the factory before shipment.
- “Default” denotes a value which is adopted by entering a command and parameter with no data.
- The password must be entered before inputting a command marked with ★. Refer to “9.3.2.3. Password” for more details.

★ **AB** : I/O polarity

Format	: AB n1 n2 n3 n4 n5 n6 n7 n8
Data	: nn=0 A contact (Normally open) nn=1 B contact (Normally closed) nn=X ○ At the time of input : The port set to X does not change polarity. ○ At the time of read-out : For the port which is shown as “X” the polarity can not be change. (A contact is fixed.)
Shipping set	: ABX0X0XX00 (all A contacts)
Default	: Not omissible (input all 8 digits)
Default	: Not omissible

- Set the polarity of input command port.
- The ports of which the polarity can be changed are EMDT, HLS, OTP and OTM. The other ports are fixed to A contact.
- Set “X” for the port of which polarity can not be changed. If “0” or “1” is input, the display shows “?” indicating the fault input.
- If the parameter “TY” is changed, all polarity settings return to the shipping set (all A contacts).
- Polarity setting can be read by “TS” or “?AB” command.
- The table below shows the data and port.

Data digit	n1	n2	n3	n4	n5	n6	n7	n8
CN2 pin No.	25	12	24	11	23	10	22	9
TY1	SVON	EMST	RUN	HLS	PRG3	PRG2	PRG1	PRG0
TY2	SVON	EMST	RUN	HLS	PRG3	PRG2	DIR	JOG
TY3	SVON	EMST	RUN	HLS	PRG3	PRG2	OTM	OTP
TY4	SVON	EMST	RUN	HLS	HOS	CLR	OTM	OTP
TY7	SVON	EMST	RUN	HLS	DIR	JOG	OTM	OTP

AD : Absolute Positioning, Degree

Format : AD data1/data2
Data1 : Differs with parameter "PS" [0.01°]
Default data1 : 0
Data2 : PL, MI
Default data2 : direction in which the move distance is shortest

- 'data1' indicates the position of the destination. This position complies with user absolute position scale (which may be read out by issuing TP5). Refer to "9.2.1. Position Scale" for more details.
- 'data1' range differs with "PS" setting

	Data range (data1)
PS0	-99 999 999 ~ +99 999 999
PSn	0 ~ (36000 × n) -1

n : n=1-99, Shipping set : n=1

- 'data2' indicates the rotational direction. When the parameter "PS" is set to "0" (PS0), "data2" setting is invalid.
 - ① PL : CW direction [When the parameter "DI" is set to "1" (DI1), the direction is reversed. (CCW)]
 - ② DI : CCW direction [When the parameter "DI" is set to "1" (DI1), the direction is reversed. (CW)]
 - ③ If the "data2" is omitted, the Motor moves to the direction in which the shortest distance to the destination. (If the present position and the destination is same, the movement is "0".)
- This command has two functions, which depend on the usage.
 - ① If it is entered in the normal standby condition (the prompt is "_"), it serves as a positioning command.
 - ② If it is entered under the condition where a channel to be programmed is selected with a CH command, the Driver Unit outputs "?," and the system waits for a command to be entered, it specifies the rotational amount of the Programmable Indexer channel.

★ **AN : Axis Number**

Format : AN data
Data range : 0 ~ 15
Shipping set : 0
Default : 0

- Sets the axis number in the daisy-chain communication mode.
- TS command or ?AN command reports the current setting.
- For more details, refer to "9.3.3. Daisy-chain Communication."

AR : Absolute Positioning, Resolver

Format : AR data1/data2
Data1 : Differs with the parameter "PS" setting.
Default data1 : 0
Data2 : PL, MI
Default data2 : Direction in which the move distance is shortest

- 'data1' indicates the position of the destination. This position complies with user absolute position scale (which may be read out by issuing "TP").
- Format of 'data1' differs with the parameter "PS" setting and the Motor series.

	Data format (data1)		
	YS, JS1, JS2, RS	SS	AS, BS, JS0
PS0	-99 999 999 ~ +99 999 999	-99 999 999 ~ +99 999 999	-99 999 999 ~ +99 999 999
PSn	0 ~ (614400 × n) -1	0 ~ (491520 × n) -1	0 ~ (409600 × n) -1

n=1 ~ 99, Shipping set : n=1

- 'data2' indicates the rotational direction.
PL : CW direction
MI : CCW direction
- If the current position is the same as the destination position and data2 is omitted, the Motor does not rotate. Otherwise, the Motor rotates 1 revolution in the direction specified in data2.
- This command has two functions, which depend on the usage.
 - ① If it is entered under the condition where a channel to be programmed is selected with a CH command, the Driver Unit outputs "?," and the system waits for a command to be entered, it specifies the rotational amount of the Programmable Indexer channel.
 - ② If it is entered in the normal standby condition, it serves as a positioning command.

AS : Ask Daisy-Chain Status

Format : AS

- When communication in daisy-chain style, AS reads out the status of each axis connected to Driver units.
- The AS command is executed automatically when power is turned on in the daisy-chain communication mode.
- After the AS0 command is executed, the Driver Unit of axis 0 is always selected.

AT : Automatic Tuning

Format : AT

- Execute "automatic tuning" to set proper servo parameters and acceleration.

AX : Axis Select

Format	: AX data
Data	: 0 ~ 15
Shipping set	: 0
Default	: 0

- When communicating in daisy-chain, AX selects the one of the Driver Unit. Selected Driver Unit sends a confirmation signal back to the RS-232C terminal.
- Confirmation message “ACC. AXn ” (n=selected Driver Unit number). The Driver Unit of axis 0 is always selected when power is turned on.
- Report command “TS” or “?AX” is valid when daisy-chain communication is active.
- If “AX” is input when daisy-chain is not active, an error message will be given back.
- Also if “TS” or “?AX” command is input when daisy-chain is not active, an error message will be given.

Caution : Do not select any unit that is not connected. Otherwise, operation may hang up. To return to the normal state, press the BS key first, then the number of a connected Driver Unit.

★ **AZ : Absolute Zero Position Set**

Format	: AZ
--------	------

- If the AZ command is executed with the Motor stationary at any position, the position is adopted as user absolute home position.

★ **BM : Backspace Mode**

Format	: BM data
Data	: 0 or 1
Shipping set	: 1
Default	: 0

- BM changes the function of the BS key.
 - BM0 : A press of the BS key cancels an entered character string.
 - BM1 : A press of the BS key deletes a character.
- TS or ?BM command reports the current setting.

CA : Channel Acceleration

Format	: CA data
Data	: Motor series
	YS, JS1, JS2, RS : 0, 0.01 ~ 40.00 [r.p.s/s]
	SS : 0, 0.01 ~ 50.00 [r.p.s/s]
	AS, BS, JS0 : 0, 0.01 ~ 60.00 [r.p.s/s]
Default	: 0

- This command is used to specify the rotational acceleration of a given channel of the Programmable Indexer.
- The CA command may be input under the condition where a channel to be programmed is selected with a CH command, the Driver Unit outputs “?”, and the system waits for a command to be entered. If it is entered in the normal stand-by state, an error occurs.
- If no setting is made in a channel (or 0 is specified), the rotational acceleration specified with an MA command is valid.

CC : Clear Channel

Format	: CC data1
Data1	: 0 ~ 15
Data1 default	: 0

- CC deletes the program data of a channel specified in ‘data.’

CH : Channel Select

Format	: CH data
Data1	: 0 ~ 15
Data1 default	: 0

- This command is to select the channel to be programmed.
- The input program can be read with “TC” command.

Caution : Input program when the system is servo-off state.

CL : Clear Alarm

Format	: CL
--------	------

- “CL” command clears “excess error”, “software thermal” and “program error” alarms. (Other alarms can not be cleared with “CL” command.)

★ CM : Communication Mode

Format : CM data
Data : 0 or 1
Shipping set : 0
Default : 0

- CM Selects the RS-232C communication mode.
CM0 : Standard
CM1 : Daisy-chain communication
- The CM parameter set at the time of power-on is valid.
- To change the communication mode, change the CM parameter, turn off the power, then turn it on again.
- “TS” or “?CM” command reports the current setting.

★ CO : Position Error Counter Over Limit

Format : CO data
Data : 0 or 1 ~ 99999999 [pulse]
Shipping set : 50000
Default : 0

- CO Sets the position error counter value at which the excess position error alarm is to be detected.
- When the position error counter exceeds the set value, the Driver Unit outputs the excess position error alarm and opens the DRDY output circuit.
- If 0 is specified, the excess position error alarm detection is invalidated invalid (i.e., no alarm function).
- “TS” or “?CO” command reports the current setting.

★ CR : Circular Resolution

Format : CR data
Data : X1, X2, X4, 360000, 36000, 3600
Shipping set : X1
Default : Not omissible

- Use to specify the pulse train resolution.
- For the details about the resolution, refer to “10.4. Pulse Train Command.”
- The resolution changes immediately after CR data is specified.
- “TS” or “?CR” command reports the current setting.

CV : Channel Velocity

Format	: CV data
Data	: Motor series
	YS, JS1, JS2, RS : 0, 0.01 ~ 3.00 [r.p.s]
	SS : 0, 0.01 ~ 3.75 [r.p.s]
	AS, BS, JS0 : 0, 0.01 ~ 4.50 [r.p.s]
Default	: 0

- This command is used to specify the rotational velocity of each channel of the Programmable Indexer.
- The “CV” command may be input under the condition where a channel to be programmed is selected with a CH command, the Driver Unit outputs “?” and the system waits for a command to be entered. If it is entered in the normal stand-by state, an error occurs. (normal stand-by state : when the colon “:” is displayed while waiting for input.)
- If no setting is made in a channel (or 0 is specified), the rotational velocity specified with an MV command is valid

★ **DBP : Dead Band**

Format	: DBP data
Data	: 0 or 1 ~ 4095
Shipping set	: 0
Default	: 0

- Sets a dead band for detecting errors in the position loop.
- For more details, refer to “9.2.5. Dead Band Setting : DBP.”
- “TS” or “?DBP” command reports the current setting.

★ **DI : Direction Inversion**

Format	: DI data
Data	: 0 or 1
Shipping set	: 0
Default	: 0

- Switches the position scale counting direction.
- For more details, refer to “9.2.1. Position Scale.”

★ **FC** : **Friction Compensation**

Format	: FC data
Data	: 0 ~ 2047
Shipping set	: 0
Default	: 0

- “FC” is used to specify a compensation value to cancel rotational static friction of the Motor.
- If 0 is specified in ‘data’ the function is deactivated.
- Parameter FC can be obtained with the formula shown below.

$$\text{FC 'data'} = 2047 \times \frac{\text{Static friction torque}}{\text{Motor maximum torque}}$$

- The setting can be read with “TS” or “?FC” command.

★ **FD** : **Feed Back Direction Mode**

Format	: FD data
Data	: 0, 1
Shipping set	: 0
Default	: 0

- Reverses the output timing between ϕA and ϕB of the position feedback signal.
FD0 : Standard; ϕA signal is always ahead of ϕB signal.
FD1 : Reverse; ϕB signal is always ahead of ϕA signal.
- “TS” or “?FD” command reports the current setting.

★ **FF** : **Feed Forward Gain**


Format	: FF data
Data	: 0.0000 ~ 1.0000
Shipping set	: 0
Default	: 0

- FF sets the feed forward compensation gain.
- For more details, refer to “9.2.3. Feed Forward Compensation.”
- Setting 0 cancels the feed forward compensation function.
- “TS” or “?FF” command reports the current setting.

★ **FO** : **Low-pass Filter OFF Velocity**

Format	: FO data
Data	: Motor series
	YS, JS1, JS2, RS : 0, 0.01 ~ 3.00 [r.p.s]
	SS : 0, 0.01 ~ 3.75 [r.p.s]
	AS, BS, JS0 : 0, 0.01 ~ 4.50 [r.p.s]
Default	: 0

- Sets the low pass filters (parameter FP and FS), depending upon velocity.
- FO data sets the velocity threshold which turns ON and OFF the low pass filters.



- When this function is set, it is possible to lower the resonance noise level without affecting on the settling time.
- When “FO” is set to 0 the function is invalid. (The low-pass filters are always active.)

★ **FP** : **Low-pass Filter, Primary**

Format	: FP data
Data	: 0, 10 ~ 500 [Hz] or /AJ (Adjusting mode)
Shipping set	: 0
Default	: 0

- FP sets the frequency of the primary low-pass filter of the velocity loop.
- When 0 is input, the velocity-loop primary low-pass filter is set to “off”. At this time, [PRI.LPF OFF] appears on the display.
- When data other than 0 (i.e, 0 ~ 500) is input, the frequency specified by the data is set.
- The set value can be read by the “TS” command and “?FP”.
- Inputting FP/AJ can set to adjusting mode.

★ FR : Feed Back Signal Resolution

Format	: FR data
Data	: 0 or 1
Shipping set	: 0
Default	: 0

- Sets the resolution specification of the position feedback signal ϕA and ϕB .
FR0 : 10-bit resolution specification
FR1 : 12-bit resolution specification
- For more details about the resolution, refer to “4.2.2.2. Functional Specification.”
- Set FR0 when the resolver resolution is set to 10-bit or automatic resolution switching by the RR parameter. If FR1 is set, ϕA and ϕB will not be output.
- Both FR0 and FR1 can be selected when the resolver resolution is set to 12-bit specification by the RR parameter.
- “TS” or “?FR” command reports the current setting.

★ FS : Low-pass Filter, Secondary

Format	: FS data
Data	: 0, 10 ~ 500 [Hz] or /AJ (Adjusting mode)
Shipping set	: 0
Default	: 0

- Sets the frequency of the secondary low-pass filter of the velocity loop.
- When 0 is input, the velocity-loop secondary low-pass filter is set to “off”. At this time, [SEC.LPF OFF] appears on the display.
- When data other than 0 (i.e, 10 ~ 500) is input, the frequency specified by the data is set.
- The set value can be read by the “TS” command and “?FS”.
- Inputting FP/AJ can set to adjusting mode.

★ FW : FIN Width

Format	: FW data
Data	: 0 or 0.3 ~ 100 [0.1 second]
Shipping set	: 1
Default	: 0

- Sets the width (length) of IPOS output. Unit is 0.1 sec.
- If it is set to FW1, the time length of the IPOS output will be 0.1 sec.
- If it is set to FW0, IPOS output is in standard state and always closed when the position error counter value is less than the “IN” setting.
- When it is set to FW0.3 ~ FW100, IPOS output is closed for the moment as set when the position error counter value is less than the “IN” value.
- Refer to “9.1.7. In-Position Output” for the output timing.
- “TS” or “?FW” command reports the current setting.
- Set FW0 when the system is performing the pulse train command operation.

★ FZ : Feedback Phase Z Configuration

Format	: FZ data
Data	: 0 or 1
Shipping set	: 0
Default	: 0

- FZ selects the output type of the position feedback signal CHZ (CN2 output).
FZ0 : Outputs the ϕ Z signal from CHZ.
FZ1 : Outputs MSB of the digital position signal from CHZ.
- Refer to “9.1.8. Position Feedback Signal” for the output timing of the ϕ Z signal or MSB.
- “TS” or “?FZ” command reports the current setting.

HA : Home Return Acceleration

Format	: HA data
Data	: Motor series
	YS, JS1, JS2, RS : 0, 0.01 ~ 40 [r.p.s/s]
	SS : 0, 0.01 ~ 50 [r.p.s/s]
	AS, BS, JS0 : 0, 0.01 ~ 60 [r.p.s/s]

- Sets the home return acceleration.
- “TS” or “?HA” command reports the current setting.

★ **HD** : Home Return Direction

Format	: HD data
Data	: 0 or 1
Shipping set	: 1
Default	: 0

- For more details about the home return operation, refer to “10.2. Home Return.”
HD0 : Home return in the CW direction
HD1 : Home return in the CCW direction

★ **HO** : Home Offset

Format	: HA data
Data	: Motor series
	YS, JS1, JS2, RS : -610304 ~ +610304 [pulse]
	SS : -487424 ~ +487424 [pulse]
	AS, BS, JS0 : -405504 ~ +405504 [pulse]

- Specifies an offset from the point where the position error counter reaches 0 for the first time, after the home position limit switch input (HLS on CN2) goes inactive, to the point where the Motor stops.
- “TS” or “?HO” command reports the current setting.
- Refer to “10.2. Home Return” for more details.

HS : Home Return Start

Format	: HS
--------	------

- Starts the home return.
- Input HS/LS to adjust the installation position of the home limit switch (sensor).
- For more details, refer to “10.2.2. Adjusting the Home Limit Switch and Home Offset Value.”

HV : Home Return Velocity

Format	: HV data
Data	: Motor series
	YS, JS1, JS2, RS : 0.01 ~ 3.00 [r.p.s]
	SS : 0.01 ~ 3.75 [r.p.s]
	AS, BS, JS0 : 0.01 ~ 4.50 [r.p.s]
Shipping set	: 0.2
Default	: 0

- Sets the home return velocity.
- “TS” or “?HV” command reports the current setting.

***HZ* : Home Return Near-Zero Velocity**

Format : HZ data
Data : 0.01 ~ 0.20 [r.p.s.]
Shipping set : 0.01 [r.p.s.]
Default : Not omissible

- Sets the home return near-zero velocity.
- “TS” or “?HZ” command reports the current setting.

***ID* : Incremental Positioning, Degree**

Format : ID data
Data : -99999999 ~ +99999999 [0.01°]
Default : 0

- Executes the incremental positioning command (in units of degrees) in the RS-232C communication operation.
- Data is in the units of 0.01°.
- The data sign specifies the direction of rotation.
data > 0 : plus direction (CW)
data < 0 : minus direction (CCW)
Example : ID-10000 : The Motor turns 100° in the minus direction

★ *ILV* : Integration Limit

Format : ILV data
Data : 0.0 ~ 100.0 [%]
Shipping set : 100

- Provides the velocity loop integration with a limiter.
- For the details, refer to “9.2.4. Integrator Limiter : ILV.”
- “TS” or “?ILV” command reports the current setting.

***IN* : In-position**

Format : IN data
Data : 0 ~ 99 999 999 [pulse]
Shipping set : 100
Default : 0

- Specify an in-position width (criterion of detecting completion of positioning.) If the position error counter reads a value below the IN set value, the IPOS is output.
- “TS” or “?IN” command reports the current setting.
- When the resolver is set to 10-bit resolution, the resolution becomes one-fourth of the 12-bit setting. Therefore, only a multiple of 4 can be set (valid) as IN data.

IO : Input/Output Monitor

Format : IO data opt.
 Data : 0 or default
 Opt (option code) : /RP

- Verifies on/off (closed/open) of the control input and output signals on CN2.
- The status of the inputs and outputs is indicated as 1's or 0's.
 - 'data' = 0 or default
 - Input : 0 : off, 1 : on
 - Output : 0 : open, 1 : close
 - 'data' = 1 : For the B contact input, the meaning of 1 and 0 are reversed.
- Option code /RP
 - /RD default : Indicates the present status.
 - IO data /RD : Reading is repeated automatically.
- To terminate automatic reading, press the BS key.
- Method of indication
 - The reading will be shown in 13 digits. All 1's and 0's represent the status of each signal as shown in the table below.
 - I₁ I₂ I₃ I₄ I₅ I₆ I₇ I₈ / O₁ O₂ O₃ O₄
 - (For each I₁ I₂ I₃ I₄ I₅ I₆ I₇ I₈ / O₁ O₂ O₃ O₄, 1's or 0's will be indicated. O₄ is always 0.)

	Input signal								/	Output signal			
	I ₁	I ₂	I ₃	I ₄	I ₅	I ₆	I ₇	I ₈		O ₁	O ₂	O ₃	O ₄
TY1	SVON	EMST	RUN	HLS	PRG3	PRG2	PRG1	PRG0	Input/ Output separation	DRDY	BRK	IPOS	–
TY2	SVON	EMST	RUN	HLS	PRG3	PRG2	DIR	JOG		DRDY	BRK	IPOS	–
TY3	SVON	EMST	RUN	HLS	PRG3	PRG2	OTM	OTP		DRDY	BRK	IPOS	–
TY4	SVON	EMST	RUN	HLS	HOS	CLR	OTM	OTP		DRDY	BRK	IPOS	–
TY7	SVON	EMST	RUN	HLS	DIR	JOG	OTM	OTP		DRDY	BRK	IPOS	–

IR : Incremental Positioning, Resolver

Format : IR data
 Data : –99999999 ~ +99999999 [pulse]
 Default : 0

- Executes the incremental positioning command (in the units of pulse) in the RS-232C communication operation.
- The data sign specifies the direction of rotation (movement).
 - data > 0 : plus direction (CW direction)
 - data < 0 : minus direction (CCW direction)

★ **IS** : *In-position Stability Timer*

Format : IS data
Data : 0 or 0.3 ~ 100.0 [0.1 sec]
Default : 0

- Specifies the output condition of the positioning completion signal (IPOS).
 - ISO0 : The IPOS output closes in positioning if the value of the position error counter is within the IN set range.
 - IS data (data ≠ 0) : The IPOS output closes in positioning if the value of the position error counter is stable within the IN set range for the time specified in IS. The timer value is specified in 'data' in units of 0.1 second. It may be 0.03 to 10 seconds if data is specified as 0.3 to 100.
- "TS" or "?IS" command reports the current setting.
- This parameter is invalid in the pulse train operation mode.

JA : *Jog Acceleration*

Format : JA data
Data : Motor series
YS, JS1, JS2, RS : 0.01 ~ 40 [r.p.s/s]
SS : 0.01 ~ 50 [r.p.s/s]
AS, BS, JS0 : 0.01 ~ 60 [r.p.s/s]
Shipping set : 1
Default : Not omissible

- Sets the acceleration for Jog operation.
- "TS" or "?JA" command reports the current setting.

JP : *Jump*

Format : JP data
Data : 0 ~ 15
Default : 0

- "JP" is used to specify the destination of unconditional jumping in a channel.
- If a channel with a "JP" command is executed, processing jumps to channel 'data' unconditionally.
- The "JP" command may be input under the condition where a channel to be programmed is selected with a "CH" command, the Driver Unit outputs "?," and the system waits for a command to be entered. If it is entered in the normal stand-by state, an error occurs. (normal stand-by state : a colon ":" is displayed)

JV : Jog Velocity

Format	: JV data
Data	: Motor series
	YS, JS1, JS2, RS : 0.01 ~ 3.00 [r.p.s]
	SS : 0.01 ~ 3.75 [r.p.s]
	AS, BS, JS0 : 0.01 ~ 4.50 [r.p.s]
Shipping set	: 0.1
Default	: 0

- Sets the velocity for Jog operation.
- “TS” or “?JV” command reports the current setting.

LG : Lower Gain

Format	: LG data
Data range	: 10 ~ 100 [%]
Shipping set	: 50
Default	: Not omissible

Caution : Factory use only. Do not change the setting.

LO : Load Inertia

Format	: LO data
Data range	: 0.000 ~ 50.000 [kgm ²]
Shipping set	: 0
Default	: 0

- This sets the actual load inertia automatically when the automatic tuning is performed.
- “TS” or “?LO” command reports the current setting.

★ *LR : Low Torque Ripple*

Format	: LR data
Data range	: 0, 1
Shipping set	: 0
Default	: 0

- Sets torque specification.
 - 0 : Standard
 - 1 : Low torque ripple. (the maximum Motor torque will be lowered)
- “TS” or “?LR” command reports the current setting.

MA : Move Acceleration

Format	: MA data
Data	: Motor series
	YS, JS1, JS2, RS : 0.01 ~ 40 [r.p.s/s] or /AJ (Adjust mode)
	SS : 0.01 ~ 50 [r.p.s/s] or /AJ (Adjust mode)
	AS, BS, JS0 : 0.01 ~ 60 [r.p.s/s] or /AJ (Adjust mode)
Shipping set	: 1.00 [r.p.s./s]
Default	: Not omissible

- Sets the rotational acceleration of the RS-232C communication positioning.
- “TS” or “?MA” command reports the current setting.
- MA/AJ command gets into adjusting mode.

MI : Read Motor ID

Format	: MI
--------	------

- MI indicates the system ROM ID No. and the torque ROM ID No.

★ MM : Multi-line Mode

Format	: MM data
Data	: 0, 1
Shipping set	: 1
Default	: 0

- Sets the display format of commands or parameters settings with “TA”, “TC” and “TS” commands.
- “MM0” reports all contents continuously.
- When “MM1” is input, the display reports the setting pausing at each item. At this time, the colon “:” appears the end of command or parameter.
[Example : MA0.01 :]
 - To step to the next report, press the space key.
 - To quit from the report, press the backspace key. The colon “:” appears in the display and the system waits for next command.
- “TS” or “?MM” reports the current setting.

MO : Motor Off

Format	: MO
--------	------

- When the SVON input (CN2) is ON and the Motor is in the servo-on state, inputting the MO command turns the Motor servo off.
- To active the Motor servo, input the SV command or the MS command.
- When the MS command is input, the Motor stops in the servo-on state. This also clears the previously input operation command.

MS : Motor Stop

Format : MS

- When the MS command is input during the execution of an operation, the Motor abandons the instruction and stops. At this time, the Motor is in the servo-on state.
- The operation instruction specified before the Motor stop is cleared. If the MO command is input to turn off the Motor servo, inputting the MS command sets the Motor to servo-on again. This also clears the operation instruction executed preceding the input of the MO command.

MT : Factory Use Only

Shipping set : Already set properly for every system.

Caution : Do not change the setting since the parameter is properly set at the plant.

- “TS” or “?MT” command reports the current setting.

MV : Move Velocity

Format : MV data

Data : Motor series

YS, JS1, JS2, RS : 0.01 ~ 3.00 [r.p.s] or /AJ (Adjust mode)

SS : 0.01 ~ 3.75 [r.p.s] or /AJ (Adjust mode)

AS, BS, JS0 : 0.01 ~ 4.50 [r.p.s] or /AJ (Adjust mode)

Shipping set : 1.00 [r.p.s.]

Default : Not omissible

- Sets the rotational velocity of the Motor in the RS-232C communication positioning command.
- “TS” or “?MV” command reports the current setting.
- “MV/AJ” command sets to adjusting mode.

★ NP : Notch Filter, Primary (primary notch filter frequency)

Format : NP data

Data : 0 or 10 ~ 500 [Hz]

Shipping set : 0

Default : 0

- NP is used to specify the frequency of the 1st stage notch filter of the velocity loop.
- If 0 is specified, the 1st stage notch filter of the velocity loop is deactivated. In such a case, “PRI.NF OFF” is displayed.
- If a value other than 0 (i.e., 10 ~ 500) is entered, the value is adopted as the frequency.
- “TS” or “?NP” command reports the current setting.
- “NP/AJ” command sets to adjusting mode.

★ **NW** : **Neglect Width**

Format	: NW data
Data	: 0 ~ 4
Shipping set	: 2
Default	: 0

- RUN and HOS are edge-triggered inputs. To protect against multiple inputs due to contact chattering, the NW parameter sets a timer length to confirm the receipt of that input; when NW data is specified, the input pulse is detected a specified time after it initially went high (rising edge).
Timer = data × 2.8 [ms]
- “TS” or “?NW” command reports the current setting.

OE : **Sequence Option Edit**

Format	: OE data
Data	: * or &
Default	: Not omissible

- OE changes the sequence code of a program already specified in a channel.
- If this command is entered under the condition where a channel whose sequence code shall be changed is selected with a CH command, the Driver Unit outputs “?” and the system waits for a command to be entered, the sequence code of the program already specified in the channel is changed into ‘data.’ If OE is entered in the normal stand-by state, an error occurs.
- “Data” indicates the sequence code. Adding the sequence code enables to execute the positioning of next channel without selecting channel externally.
 - * ----- After the positioning is over, “IPOS” signal is output and execute next channel’s program.
 - & ----- After the positioning is over, output “IPOS” signal and stops. Then execute the next channel’s program when “RUN” command is input.

★ **OG** : **Origin Set**

Format	: OG
--------	------

Caution : This “OG” command is for factory use only. Do not change the setting.

★ **OL** : **Overload Limit**

Format	: OL data
Data	: 0 ~ 100
Shipping set	: Unique value for each System
Default	: 0

- Do not change the OL setting. OL is properly set for each System. If it needs to be changed, contact NSK.
- If 0 is specified, “THERMAL OFF” is displayed and this function is deactivated.
- TS or ?OL command reports the current setting.

★ **OS** : **Origin Setting Mode**

Format	: OS data
Data	: 1, 3, 4, 5
Shipping set	: 4
Default	: Not omissible

- Sets the “Home return” mode.
 - OS1 : Completes “Home return” at where “HLS” input goes OFF after entering “HLS” ON range.
 - OS3 : Completes “Home return” at where the Motor advances “HO” value after going out from “HLS” ON range.
 - OS4 : Completes “Home return” at where the Motor advances for “HO” value after entering “HLS” ON range.
 - OS5 : Completes “Home return” at where “HLS” input goes ON.
 - Refer to “10.2. Home Return” for more details.
 - The home return setting can be checked with “TS” or “?OS” command.
-

★ **OTP** ★ **OTM** : **Overtravel Limit Switch Position**

Format	: OTP data, OTM data
Data	: -99999999 ~ +99999999 [pulse]
Shipping set	: OTP0, OTM0
Default	: 0

- Sets the software overtravel limit values in the position scale.
 - OTP : Sets the overtravel limit value in the plus direction in the units of pulse.
 - OTM : Sets the overtravel limit value in the minus direction in the units of pulse.
 - “OTP/ST” and “OTM/ST” command enables to set the position by teaching.
 - * For more details, refer to “9.1.4.2. Software Overtravel Limit.”
 - TS or ?OTP, ?OTM command reports the current setting.
-

★ **PA** : **Phase Adjust**

Format	: PA data
Data	: 24 ~ 1048
Shipping set	: 700
Default	: 0

- Sets the compensation value of the resolver installation position.
- The resolver is set to the optimum installation position before shipment. Do not input PA in normal use.
- “TS” or “?PA” command reports the current setting.

★ PC : Pulse Command

Format	: PC data
Data	: 0 ~ 4
Shipping set	: 0
Default	: 0

- Sets the format of the pulse train input.
 - PC0 : CW & CCW format
 - PC1 : Pulse & direction format
 - PC2 : $\phi A/\phi B$ input $\times 1$ format
 - PC3 : $\phi A/\phi B$ input $\times 2$ format
 - PC4 : $\phi A/\phi B$ input $\times 4$ format
- “TS” or “?PC” command reports the current setting.

PG : Position Gain

Format	: PG data
Data	: 0.001 ~ 1.000 or /AJ (Adjust mode)
Shipping set	: 0.1
Default	: Not omissible

- Specifies a position gain.
- “TS” or “?PG” command reports the current setting.

★ PH : Program Home Return

Format	: PH data
Data	: 0, 1, 2
Shipping set	: 0
Default	: 0

- Sets when the Home return shall be executed.
 - PH0 : Program Home return invalid.
 - PH1 : Execute Home return only once when the power is turned on and the home position is not certain.
 - PH2 : Execute Home return everytime when the programmable indexer positioning is performed.
- “HS” command saves one channel program area.
- “TC/AL” or “?PH” reports the current setting.

★ **PS** : **Position Scale**

Format	: PS data
Data	: 0, 1, 2 ~ 99
Shipping set	: 1
Default	: 0

- Specifies the internal position scale type of the Megatorque Motor system.
 - PS0 : Linear position scale
 - PS1 : Single-rotation position scale
 - PS2 to 99 : Multi-rotation position scale
- For more details about the position scale, refer to “9.2.1. Position Scale.”
- “TS” or “?PS” command reports the current setting.

★ **RC** : **Rated Current (Software Thermal)**

Format	: RC data
Data	: 0 ~ 100
Shipping set	: Unique value for each System
Default	: 0

- Do not change the RC setting. RC is properly set for each System. If it needs to be changed, contact NSK.
- “TS” or “?RC” command reports the current setting.

★ **RI** : **Factory Use Only**

Shipping set : Set properly to each Motor.

Caution : Do not change setting. It is properly set for each Motor at the factory.

- “TS” or “?RI” reports the current setting.

★ **RR** : **Resolver Resolution**

Format	: RR data
Data	: 0, 1, -1
Shipping set	: -1
Default	: 0

- Sets the resolution of the resolver.
 - RR0 : 10-bit setting
 - RR1 : 12-bit setting
 - RR-1 : Automatic resolution switching
- For the details about the resolution, refer to “4.2.2.2. Functional Specification.”
- “TS” or “?RR” command reports the current setting.

SG : Servo Gain

Format	: SG data
Data	: 0 ~ 30 [Hz] or /AJ (Adjust mode)
Shipping set	: 0
Default	: Not omissible

- Sets the band of position loop.
 - Automatic tuning sets “SG” value.
- When “SG” value is changed, “PG” (position gain), “VG” (velocity gain) and VI (velocity integrator frequency) settings will be automatically revised.
- “SG/AJ” command sets the adjusting program.
- “TS” or “?SG” reports the current setting.

★ SI : Set Initial Parameters

Format	: SI/data
Data range	: None, AL, SY
Default	: None

- Resets parameters to the shipping set value.
 - The SI command can be input only immediately after inputting the password and when the Motor is servo-off.
 - The following parameters will be initialized by SI :
 - SI : Initializes servo-related parameters (PG, VG, VI, DBP, ILV, FF, FP, FS, NP, LG, TL, SG, LO, FO, FC))
 - SI/AL : Initializes all the parameters.
 - SI/SY : Initializes all the parameters excluding PA.
- * Executing “SI/AL” entails resolver phase adjustment. Be careful that the Motor is not locked by an external force. Do not perform initializing only to the Driver Unit.

Caution : *System initialization takes about 30 seconds. Do not turn off the power while initialization is being performed; otherwise, the memory will become faulty.*

* When the memory is faulty, SI/AL will be executed even if SI or SI/SY is input.

★ SM : Servo On Mode

Shipping set	: 1
--------------	-----

Caution : *“SM” is properly set at the factory. Do not change the setting.*

SP : Start Program

Format : SP data
Data range : 0 ~ 15 or /AJ (Adjust mode)
Default : 0

- Execute Programmable Indexer of a channel which number is specified in 'data'.
- SP/AJ command executes the demonstration program (back and forth operation).

SV : Servo-on

Format : SV

- When the Motor servo is turned off by MO command, executing the SV command will turn the Motor servo on.
- To turn the Motor servo on by the SV command, the SVON input of CN2 must be on.

TA : Tell Alarm Status

Format : TA

- Read out alarm status. For more details, refer to "13.1.2. Using TA Command".

TC : Tell Channel Program

Format : TC data
Data : 0 ~ 15 or /AL
Default : 0

- Reports the program contents of a channel specified on 'data'.
- No data is displayed if program is not set to the channel.
- "TC/AL" command is to scroll all channels with pressing the space key.

TE : Tell Position Error Counter

Format : TE/RP

- Reads the value of the position error counter. The displayed value is between -2 147 483 648 and +2 147 483 647. If it exceeds or lowers below the upper or lower limit, it is changed into the lower or upper limit with a reversed sign.
- If an /RP option is added to a TE command, reading is repeated automatically.
- In automatic reading, a value consisting of up to six figures is read out. If a value consists of more than six figures, "*****" is displayed.
- To terminate automatic reading, press the BS key.
- When only "TE" is entered, the display shows the value at the moment.

TL : Torque Limit Rate

Format	: TL data
Data	: 0 ~ 100 [%]
Shipping set	: 100
Default	: 0

- Sets the torque limit.
- The Motor torque will be reduced to a percentage (%) of the maximum torque immediately after “TL” is input and the Motor torque is controlled not to exceed the limit.
- “TS” or “?TL” reads the current setting.

TP : Tell Position

Format	: TP data/RP
Data	: 2, 5
Shipping set	: None
Default	: Not omissible

- “TP” command reads the current position of the Motor in the position scale set by PS parameter.
- If /RP is executed with an /RP option, reading is repeated automatically.
- If only “TP data” is executed, the display shows the position at the moment.
- To terminate automatic reading, press the BS key.
- TP2/RP: in the units of pulse
 - YS, JS1, JS2, RS : 614400 pulses/revolution
 - SS : 491250 pulses/revolution
 - AS, BS, JS0 : 409600 pulses/revolution
- TP5/RP : in the units of 0.01°
36000/revolution

TR : Tell RDC Position Data

Format	: TR/RP
--------	---------

- TR reads data of RDC position data.
- Data is between 0 and 4095.
- If TR command is executed with /RP option, reading is repeated automatically.
- To terminate automatic reading, press the BS key.
- “TR” command reads out the status at the moment.

TS : Tell Settings

Format : TS data
 Data : 0 ~ 12
 Default : 0

- Reads the parameters. The parameters to be read vary with data.

TS0 : All the following parameters

TS1 : PG, VG, VI, VM, LG, TL

TS2 : FO, FP, FS, NP, DBP, ILV, FF, FC

TS3 : CO, IN, IS, FW

TS4 : CR, PC, RR

TS5 : FD, FZ, FR

TS6 : PS, DI, OTP, OTM

TS7 : MV, MA, JV, JA, HV, HA, HZ

TS8 : OS, HD, HO

TS9 : PA, OL, RC

TS10 : TY, AB, SM, NW

TS11 : MM, BM, CM, AN, AX

TS12 : LO, SG, MT, RI, ZP, ZV

★ TY : I/O Type

Format : TY data
 Data : 1, 2, 3, 4, 7
 Shipping set : 1
 Default : Not omissible

- Sets the input/output signal type of the CN2 connector.
- The set value can be read by the “TS” command or “?TY”.
- The input/output signals of each type are shown below.

CN2 connector pin No.	Input signal								Output signal		
	25	12	24	11	23	10	22	9	2 15	3	14
TY1	SVON	EMST	RUN	HLS	PRG3	PRG2	PRG1	PRG0	DRDY	BRK	IPOS
TY2	SVON	EMST	RUN	HLS	PRG3	PRG2	DIR	JOG			
TY3	SVON	EMST	RUN	HLS	PRG3	PRG2	OTM	OTP			
TY4	SVON	EMST	RUN	HLS	HOS	CLR	OTM	OTP			
TY7	SVON	EMST	RUN	HLS	DIR	JOG	OTM	OTP			

- For more details,, refer to “5.2.1. Setting I/O Type”.

VG : Velocity Gain

Format : VG data
Data : 0.1 ~ 255.0 or /AJ (Adjust mode)
Shipping set : 1.0
Default : Not omissible

- Sets the velocity loop gain.
- “VG/AJ” command sets to adjusting mode.
- “TS” or “?VG” reports the current setting.

VI : Velocity Integrator Frequency

Format : VI data
Data : 0.10 ~ 63.00 [Hz] or /AJ (Adjust mode)
Shipping set : 1.00
Default : Not omissible

- Specifies velocity integrator frequency.
- “VG/AJ” command sets to adjusting mode.
- “TS” or “?VI” command reports the current setting.

★ VM : Velocity Integrator Mode

Format : VM data
Data : 0, 1
Shipping set : 1
Default : 0

- Changes the velocity loop integrator control as shown below.
VM0 : Velocity loop P control.
VM1 : Velocity loop PI control.

★ ZP : Factory Use Only

Shipping set : 1.00

- Caution** : ● The parameter is for the automatic tuning function and is set at the factory.
- Do not change the setting.
 - “TS” or “?ZP” command reports the current setting.

★ ZV : Factory Use Only

Shipping set : 1.4

- Caution** : ● The parameter is for automatic tuning function and to be set at the factory
- Do not change the setting.
 - “TS” or “?ZP” command reports the current setting.

(Blank Page)

12. Maintenance

12.1. Precautions

- Back up Motor and Driver Unit
 - We recommend having a back up Motor and Driver Unit for unexpected shut down of the system.
- Parameter and program back up
 - For an unexpected shut down of the Driver Unit, all parameters and programs should be recorded.
 - For your convenience, the list of parameter and program is provided in the last page of this manual.
- How to replace the driver Unit.
 - Standard ESA23 Driver Units are interchangeable with each other. It may be replaced simply by inputting same parameter settings of old Driver Unit.
Following shows reference number of standard ESA23 Driver Unit.
 - M-ESA-*****A23
 - M-ESA-*****C23
- If your Driver Unit is not standard, refer to the specification documents for interchangeability.
- When replacing the Driver Unit, refer to “Appendix 4. How to replace ESA23 Driver Unit”.
- ESA23 Driver Unit has EEPROM and does not need a battery for memory back up.

(Life of EEPROM : approximately 100000 cycles of writing on and off.)

12.2. Maintenance Check

12.2.1. Motor

- Since a Megatorque Motor does not have any parts which will wear out, a daily maintenance check should be enough.
- The table below shows the maintenance check and intervals. The checking interval shown in the table is reference only. It should be decided accordingly to the actual use conditions.

Caution : Do not disassemble the Motor and resolver. If disassembling Motor is necessary, contact your local NSK representative.

Table 12-1 : Motor maintenance check

Item	Checking interval	How to check	Remarks
Vibration/Noise	Daily	● Touching and hearing	● Watch daily changes
Appearance	According to environment	● Wipe off dust/slag ● Blow off slag	—
Insulation	Once/year	● Resistance test (Motor coil and ground earth) (Disconnect Driver Unit)	● Resistance $\geq 10M\Omega$
Full check	According to Motor condition	● Overhaul (NSK)	—

12.2.2. Driver Unit and Cable Set

- As a Driver Unit does not have any contact point and highly reliable semiconductors are used, the daily check is not necessary. Checkings as shown in Table 12-2 are necessary at least once a year.

Table 12-2

Item	Interval	Check point	Remarks
Retighten screws	Once/year	● Terminal block screw. ● Connector fixing screw.	—
Cleaning	Once/year	● Remove dust or contaminants inside of Driver Unit.	—
Cable check	Once/year	● Check for damages and cracks of cables.	● When the cable is forced to bend or twist, checking frequency should be increased.

12.3. Periodical Replacement of Parts

12.3.1. Motor

- There is no parts which is required to be replaced periodically.
- Refer to “12.2. Maintenance Check”.

12.3.2. Driver Unit

- Electrolytic condenser
 - The gradual chemical change of electrolytic condensers will deteriorate system function and it may result in the system failure.

Table 12-3

Parts	Function	Life	How to replace
Electrolytic condenser	Equalize power voltage	10 years	<ul style="list-style-type: none">● Replace *PCB● Replace whole unit

*PCB: Printed circuit board

Note : Life of electrolytic condenser relies on the operating conditions. The 10 years of life is rough estimation under continuous operation in normal room environment.

12.4. Storing

- Store the Motor and Driver Unit in clean and dry indoor condition.
- A Driver Unit has a lot of ventilation holes and should be covered properly to protect from dust.

Table 12-4

Storing condition		Remarks
Temperature	-20°C ~ +70°C	—
Humidity	20% ~ 80%	No condensation

12.5. Limited Warranty

- NSK Ltd. warrants its products to be free from defects in material and/or workmanship which NSK Ltd. is notified of in writing within, which comes first, one (1) year of shipment or 2400 total operation hours. NSK Ltd., at its option, and with transportation charges prepaid by the claimant, will repair or replace any product which has been proved to the satisfaction of NSK Ltd. to have a defect in material and/or workmanship.
- This warranty is the sole and exclusive remedy available, and under no circumstances shall NSK Ltd. be liable for any consequential damages, loss of profits and/or personal injury as a result of claim arising under this limited warranty. NSK Ltd. makes no other warranty express or implied, and disclaims any warranties for fitness for a particular purpose or merchantability.

(Blank Page)

13. Alarms

13.1. Identifying Alarms

- The DRDY output opens when error occurs in ESA23 Driver Unit.
- The front panel is provided with a 7-segment LED display to indicate the type of alarm. Also the TA command can be used to identify alarms.

13.1.1. Using LED

Figure 13-1






Figure 13-2 : Abnormal (example)



(Example) Excess position error F1 + Heat Sink Over-Temperature P0


Figure 13-3 : Shows that the LED is indicating normal state.




13.1.2. Using TA Command

- “TA” command displays the same alarm code as that is displayed on the 7–segment LED display.
- In this case, the code is not displayed at different time as the LED display.
 - Example
 - Excess position error and heat sink over temperature alarms will be displayed as shown in Figure 13-4.

Figure 13-4 : Alarm display



[Example 1] Alarm is detected and identify the alarm.



- Thus the alarm is identified as “Excess position error”.

13.1.3. Alarm List

- Alarms are listed in Table 13-1.

Table 13-1 : Alarm list

Alarm	7 segments LED	Display
Memory Error	E0	E0>Memory Error
EEPROM Error	E2	E2>EEPROM Error
Excess Position Error	F1	F1>Excess Position Error
Software Over Travel Limit	F2	F2>Software Over Travel
Hardware Over Travel Limit	F3	F3>Hardware Over Travel
Emergency Stop	F4	F4>Emergency Stop
Program Error	F5	F5>Program Error
Automatic Turing Error	F8	F8>AT Error
Resolver Circuit Error	A0	A0>Resolver Circuit Error
Software Thermal Sensor	A3	A3>Overload
Heat Sink Overheat	P0	P0>Over Heat
Abnormal Main AC Line Voltage	P1	P1>Main AC Line Trouble
Over Current	P2	P2>Over Current
Control AC Line Under Voltage	P3	P3>Control AC Line Under Voltage

13.2. Detail of Alarm

Caution : The DRDY output is normally closed. It opens on abnormal condition.

13.2.1. Normal State

- When the Motor does not operate even in normal state, following causes should be considered as shown in Table 13-2.

Table 13-2

Status	Motor condition	DRDY	Cause	Remedy
Power-off	Servo-OFF	open	Power is not supplied.	Turn on power.
CPU Initializing	Servo-OFF	open	Initializing the CPU.	Wait for the CPU to be initialized.
SVON Input OFF	Servo-OFF	closed	SVON input is not active.	Activate the SVON input.

13.2.2. Alarms Related to Power Amplifier

13.2.2.1. Heat Sink Over Temperature

[Output]	DRDY : Open
[TA]	P0 > Over Heat
[LED]	P0
[Motor Condition]	Servo-OFF

Table 13-3 : Cause and Remedy : Heat sink over temperature

Cause	Remedy
① Duty cycles of the Motor is too high. ② Excessive load is applied.	<ul style="list-style-type: none"> Reduce the load and/or operation duty. Readjust acceleration/ deceleration. (Stop operation, air-cool the Driver Unit.)
③ Ambient temperature is above 50°C. ④ Heat sink temperature exceeds 90°C due to continued heavy torque demand.	<ul style="list-style-type: none"> Check surrounding condition of the Driver Unit. Stop the operation and air-cool the Motor and driver Unit. Then check followings. <ul style="list-style-type: none"> Whether the duty cycle is too high. Whether excessive load is applied. If no troubles are found in the above check and this alarm occurs frequently, contact NSK.
⑤ Defective PCB. (As soon as the control power is turned on, the alarm is activated.)	<ul style="list-style-type: none"> Replace Driver Unit. (Refer to “Appendix 4. How to Replace ESA23 Driver Unit”.)

Note : (1) Stop operation immediately.

(2) Even the alarm is deactivated, it is activated again when the thermal sensor is still on.

13.2.2.2. Abnormal Main AC Line Voltage

[Output]	DRDY : Open
[TA]	P1 > Main AC Line Trouble
[LED]	P1
[Motor Condition]	Servo-OFF

Table 13-4 : Cause and Remedy : Abnormal main AC line voltage (Over/Under)

Cause	Remedy
① Abnormal power supply voltage.	<ul style="list-style-type: none"> ● Check main power supply. (Excessive voltage, low voltage and power source capacity.) ● Check fuse, power source and the cable, then turn power on again.
② ○ Main circuit voltage is excessive due to high acceleration/deceleration under heavy load.	
○ Defective power source gives over 290V to the main power supply for power amplifier main circuit.	
③ Defective power source gives under 40V to power amplifier main circuit.	
④ Blown fuse. (Motor over temperature, abnormal power supply wiring, Driver Unit abnormal.)	<ul style="list-style-type: none"> ● Check blown fuse. ● Check the fuse, power supply and cables, then turn on power again.
⑤ Excessive regeneration voltage.	<ul style="list-style-type: none"> ● Readjust operation duty, the load and acceleration/deceleration.
⑥ Defective PCB. (When the alarm is on after the Motor stops even power source and fuse are normal.)	<ul style="list-style-type: none"> ● Replace Driver Unit. (Refer to “Appendix 4. How to Replace ESA23 Driver Unit”.)

Note : (1) When the regeneration dump resistor can not process regenerative current, the voltage of direct current to main circuit will be too high and the alarm will be on.

(2) Decrease acceleration/deceleration.

13.2.2.3. Over Current

[Output]	DRDY : Open
[TA]	P2 > Over Current
[LED]	P2
[Motor Condition]	Servo-OFF

Table 13-5 : Cause and Remedy : Over current

Cause	Remedy
① Poor insulation of the Motor. (Refer to “Appendix 2. How to Check Motor Condition”.)	<ul style="list-style-type: none"> ● Replace Motor.
② Defective Motor Cable. (Refer to “Appendix 2. How to Check Motor Condition”.)	<ul style="list-style-type: none"> ● Replace Cable.
③ Defective FET of Power Amplifier. (When the alarm is on even the Motor and Motor cable are normal.)	<ul style="list-style-type: none"> ● Replace Driver Unit. (Refer to “Appendix 4. How to Replace ESA23 Driver Unit.”.)

Note : The alarm may be accompanied with abnormal main AC line voltage (blown fuse) alarm due to excessive current flow.

13.2.2.4. Control AC Line Under-Voltage

[Output] DRDY : Open
 [TA] P3 > Control AC Line Under Voltage
 [LED] P3
 [Motor Condition] Servo-OFF

Table 13-6 : Cause and Remedy : Control AC line under-voltage

Cause	Remedy
① Low voltage of control power input.	<ul style="list-style-type: none"> ● Check control power voltage. (Low voltage due to over current or output shorting.)
② Control circuit voltage for the power amplifier falls below 70V due to faulty power supply.	<ul style="list-style-type: none"> ● Turn off power check the power supply and power cable, then turn on power again.
③ Faulty PCB. (When the alarm is on after control power is turned on.)	<ul style="list-style-type: none"> ● Replace Driver Unit. (Refer to “Appendix 4. How to Replace ESA23 Driver Unit”.)

13.2.3. Alarms Related to Motor

13.2.3.1. Resolver Circuit Error

[Output]	DRDY : Open
[TA]	A0 > Resolver Circuit Error
[LED]	A0
[Motor Condition]	Servo-OFF

Table 13-7 : Cause and Remedy : Resolver circuit error

Cause	Remedy
① Resolver cable disconnected. (Refer to “Appendix 2. How to Check Motor Condition”.)	<ul style="list-style-type: none"> • Turn off power, check the resolver cable and connector.
② Breakage of resolver cable. (Refer to “Appendix 2. How to Check Motor Condition”.)	<ul style="list-style-type: none"> • Replace resolver cable.
③ Faulty resolver. (Refer to “Appendix 2. How to Check Motor Condition”.)	<ul style="list-style-type: none"> • Replace Motor.
④ Faulty PCB. (When the alarm is on even when the resolver and the cable are normal and the connector is properly secured.)	<ul style="list-style-type: none"> • Replace Driver Unit. (Refer to “Appendix 4. How to Replace ESA23 Driver Unit”.)

Note : (1) Check the resolver cable for disconnection and shorted of wires.

(2) Check the connector for contact failure.

(3) When the resolver Cable is forced to move and bend, the bending radius and frequency will affect on the life the cable. It is necessary to have a insulation and continuity tests periodically.

13.2.3.2. Software Thermal Sensor

[Output]	DRDY : Open
[TA]	A3 > Overload
[LED]	A3
[Motor Condition]	Servo-OFF

Table 13-8 : Cause and Remedy : Overload

Cause	Remedy
① Excessive Motor duty cycle.	<ul style="list-style-type: none"> ● Reduce duty cycle and the load. Re-adjust acceleration/ deceleration. ● The Motor is overheated and air-cooling is necessary after the Motor stops. Then turn on power. (After stopping operation, keep control power on.)
② Mechanical restraint to the Motor such as brake or an obstacle.	<ul style="list-style-type: none"> ● Remove mechanical restraint.
③ Improper gain setting.	<ul style="list-style-type: none"> ● Readjust gain. (Refer to “8. Trial Running and Adjustment”.)
④ Unmatched combination of Motor and Driver Unit.	<ul style="list-style-type: none"> ● Check the combination. (Reference number of Motor and Driver Unit.)

Note : Do not change a parameter “CL” setting. It is properly set before shipment.

13.2.4. Alarms Related to Control

13.2.4.1. Memory Error

[Output]	DRDY : Open
[TA]	E0 > Memory Error
[LED]	E0
[Motion Condition]	Servo-OFF

Table 13-9 : Cause and Remedy : Memory error

Cause	Remedy
① Parameters stored in the memory have been rewritten by noise or other cause.	<ul style="list-style-type: none"> Initialize the memory then reenter the parameters. (Refer to “11. Command and Parameter”.)
② Faulty PCB. (When the memory is not functioning after initialized.)	<ul style="list-style-type: none"> Replace Driver Unit. (Refer to “Appendix 4. How to Replace ESA23 Driver Unit”.)

- Command “SI” initializes the memory. After initializing, some parameters are reset to shipping set. Resetting parameters are necessary.
- When the memory error occurs, read out of a parameter with “TA” command will be all “0” (Zero).

13.2.4.2. EEPROM Error

[Output]	DRDY : Open
[TA]	E2 > EEPROM Error
[LED]	E2
[Motor Condition]	Servo Free

Table 13-10 : Cause and Remedy : EEPROM error

Cause	Remedy
① Faulty EEPROM of control circuit.	<ul style="list-style-type: none"> Turn the power on again. Replace Driver Unit. (Refer to “Appendix 4. How to Replace ESA23 Driver Unit”.)

13.2.4.3. CPU Error

[Output]	DRDY : Open
[TA]	Disabled
[LED]	Unstable
[Motor Condition]	Servo-OFF

Table 13-11 : Cause and Remedy : CPU error

Cause	Remedy
① CPU is out of control due to noise.	<ul style="list-style-type: none"> Turn power on again. The alarm is deactivated when the power is turned on again. If the alarm occurs frequently, contact NSK.
② Faulty PCB. (When the alarm is not deactivated after the power is turned on.)	<ul style="list-style-type: none"> Replace Driver Unit. (Refer to “Appendix 4. How to Replace ESA23 Driver Unit”.)

Note : (1) CPU is not functioning. RS-232C communication and other controls are disabled.

(2) Contact NSK if the alarm occurred.

13.2.4.4. Excess Position Error

[Output] DRDY : Open
 [TA] F1 > Excess Position Error
 [LED] F1
 [Motor Condition] Servo Lock

Table 13-12 : Cause and Remedy : Excess position error

Cause	Remedy
① Position error counter value is over “CO” setting due to mechanical restraint such as brake.	<ul style="list-style-type: none"> ● Remove mechanical restraint.
② Improper gain setting.	<ul style="list-style-type: none"> ● Readjust gain. (Refer to “Chapter 8. Trial Running and Adjustment”.)
③ Excessive acceleration/deceleration.	<ul style="list-style-type: none"> ● Decrease acceleration/deceleration.
④ “CP” setting is too low.	<ul style="list-style-type: none"> ● Increase “CO” setting. ● Activate the “CLR” input to cancel alarm, then position error counter is cleared to 0 (Zero). ● Adjust servo parameters (VG, VI, PG). ● Adjust acceleration/deceleration (MA). ● Check the applied load.
⑤ Unmatched combination of Motor and Driver Unit.	<ul style="list-style-type: none"> ● Check reference number of Motor and Driver Unit.
⑥ Improper “PA” setting.	<ul style="list-style-type: none"> ● Set “PA” to 700.
⑦ Faulty PCB. (When the alarm is on even “RUN” command is not executed.)	<ul style="list-style-type: none"> ● Replace Driver Unit. (Refer to “Appendix 4. How to Replace ESA23 Driver Unit”.)

13.2.4.5. Software Over Travel Limit

[Output] DRDY : Open
 [TA] F2 > Software Over Travel
 [LED] F2
 [Motor Condition] Servo Lock in one direction.
 (The Motor will only rotate in a direction opposite to that of the rotation limit.)

Table 13-13 : Cause and Remedy : Software over travel

Cause	Remedy
① The Motor enters the inhibited area set by OTP and OTM	<ul style="list-style-type: none"> ● Get out of inhibited area.

Note : If the Motor can not make a full turn due to obstacle or restricted area, “OTM and OTP” must be set to the point where the Motor can stop before entering the restricted area where the alarm is activated.

13.2.4.6. Hard ware Over Travel Limit

[Output]	DRDY : Open
[TA]	F3 > Hardware Over Travel
[LED]	F3
[Motor Condition]	Servo Lock in one direction. (The Motor will only rotate in the direction opposite to that of the rotation limit.)

Table 13-14 : Cause and Remedy : Software over travel

Cause	Remedy
① Motor activated travel limit switch.	● Get out of the restricted area.
② Mistaken setting of input port polarity.	● Confirm the parameter “AB”.
③ Faulty travel limit switch or wiring.	● Check the limit switch and wiring.

13.2.4.7. Emergency Stop

[Output]	DRDY : Closed
[TA]	F4 > Emergency Stop
[LED]	F4
[Motor Condition]	Servo Lock

Table 13-15 : Cause and Remedy : Emergency stop

Cause	Remedy
① Mistaken setting of input port polarity.	● Confirm the parameter “AB”.
② EMST is input. (A contact)	● Clear EMST input after the Motor stops.
③ EMST is input. (B contact)	● Input EMST on after the Motor stops.
④ Faulty wiring.	● Check wiring.

13.2.4.8. Program Error

[Output]	DRDY : Closed
[TA]	F5 > Program Error
[LED]	F5
[Motor Condition]	Servo Lock

Table 13-16 : Cause and Remedy : Program error

Cause	Remedy
① A non-programmed channel is started.	<ul style="list-style-type: none"> ● Check the program. ● Check wiring of PRG0~PRG3 input. ● Confirm sequence.

13.2.4.9. Automatic Tuning Error

[Output] DRDY : Closed
 [TA] F8 > AT Error
 [LED] F8
 [Motor Condition] Normal Servo State

Table 13-17 : Cause and Remedy : Automatic tuning error

Cause	Remedy	Terminal display
① System is in Servo-OFF when executing automatic tuning ② EMST or Over Travel Limit is input when executing automatic tuning.	<ul style="list-style-type: none"> ● Check input signal and execute automatic tuning again. 	AT Error 1
③ Automatic tuning can not be executed due to unbalanced load.	<ul style="list-style-type: none"> ● Check the load condition. ● Set parameters manually. 	AT Error 2
④ Resonant vibration occurs due to low rigidity of the load or the mounting base.	<ul style="list-style-type: none"> ● Check the load or the mounting base. Increase rigidity. ● Set parameters manually. 	

14. Troubleshooting

14.1. Identifying Problem

- If problems do occur, check the items shown in Table 14-1.
- When reporting problems to the manufacturer, explanation of the items in Table 14-1 will help to identify the problem.


Table 14-1

	Items	Point to be checked
1	Combination of Motor and Driver Unit	• Whether Motor and Driver Unit combination is proper or not.
2	Power supply voltage	• Voltage variation of power source is in specification.
3	Trouble recurrence	• Frequency
4	Occurrence in special occasion	• When a particular command is executed. • A particular equipment is in operation.
5	Occurrence under a particular operation	• Same position/direction • Accelerating/decelerating
6	Alarm	• Which alarm is detected.

14.2. Troubleshooting

- When troubleshooting, refer to the flow chart shown below.


Figure 14-1 : Troubleshooting flow



14.2.1. Power Trouble

Power is not turned on.


Figure 14-2 : Power trouble



14.2.2. Motor Trouble


(1) Motor servo is not turned on.

Figure 14-3 : Motor trouble 1



(2) **Motor does not run stably. / Motor vibrates or runs away.**


Figure 14-4 : Motor trouble 2



14.2.3. Command Trouble


(1) Home Return command causes no motion

Figure 14-5 : Command trouble 1




(2) **Motor does not stop in Home Return.**

Figure 14-6 : Command trouble 2




(3) **Home Return command fails to stop Motor in position.**

Figure 14-7 : Command trouble 3




(4) Run input does not start Motor.

Figure 14-8 : Command trouble 4



(5) Pulse train input does not run Motor.


Figure 14-9 : Command trouble 5



14.2.4. Terminal Trouble

Communication is Disabled

Figure 14-10 : Terminal trouble



Appendix 1 : Verify Input/Output Signal

IO: Read Out Input/Output Signal Status.

Format : IO/opt. ENT (opt. : option)

Option Code : /RP

- Verifies on/off (open/closed) status of the control Input and Output signals on CN2 connector.
- When IO command is executed with option code /RP, reading is repeated automatically on the display. This means that the Driver Unit is repeatedly outputting signals as follow.

Space code (20H) + Read Out + Carriage Return Code (0DH)

Input the back space code (08H) to get out the automatic reading.


- Read Out format is shown in Table A-1.

Table A-1 : Input/Output signal table

Display	Input signal								/	Output signal			
	Input signal is ON when "1" is displayed.									Output signal circuit is closed when "1" is displayed.			
	0	0	0	0	0	0	0	0		0	0	0	0
TY1	SVON	EMST	RUN	HLS	PRG3	PRG2	PRG1	PRG0	Input/ output separation	DRDY	BRK	IPOS	—
TY2	SVON	EMST	RUN	HLS	PRG3	PRG2	DIR	JOG					
TY3	SVON	EMST	RUN	HLS	PRG3	PRG2	OTM	OTP					
TY4	SVON	EMST	RUN	HLS	HOS	CLR	OTM	OTP					
TY7	SVON	EMST	RUN	HLS	DIR	JOG	OTM	OTP					

↑ Input signals vary with the setting of the TY parameter (I/O Type).
Refer to "5.2.3. CN2 Signal List".

[Example] Verify the channel program start command “RUN” is ON.



- Above example shows that read out of RUN input is “1”, which indicates “RUN” input is ON.

[Reference]


- Read-out follows the changes of signal status while repeating reading-out.
(Signals ON and OFF are followed by 1 and 0 in the display.)
- If the option code “/RP” is not entered, the read-out at the moment will be displayed for only once.

Appendix 2 : How to Check Motor Condition

- Examine the resistance and isolation of Motor windings to find out its condition.
- Firstly conduct the checkings with the Cable Set. If the result does not meet the specification, check the Motor only.


(1) Motor windings Resistance

Figure A-1 : With Cable Set



- Refer to Table A-2 for pin numbers to be checked.

Figure A-2 : Motor only



- Refer to Table A-2 for pin numbers to be checked.

Table A-2 : Pin number to be checked.

	Cable connector	Motor connector	Result
Phase A	① ↔ ②	⑤ ↔ ④	
	(A+) (A-)	(A+) (A-)	
Phase B	③ ↔ ④	⑩ ↔ ⑨	
	(B+) (B-)	(B+) (B-)	
Phase C	⑤ ↔ ⑥	⑮ ↔ ⑭	
	(C+) (C-)	(C+) (C-)	


Table A-3 : Specification

Motor number	Motor winding resistance (Ω)	Tolerance
YS2005	35.0	1. Allowance : ±30% 2. Variations between each phase : 1Ω or less (øA, øB, øC)
YS2020	4.5	
YS3008	47.0	
YS3040	6.4	
YS4080	5.2	
YS5120	3.5	
JS0002	9.6	
JS1003	15.4	
JS2006	9.2	
JS2014	14.6	

- For special Motor windings or long cable (over 4m), contact NSK for specification.


(2) Resolver windings Resistance

Figure A-3 : With cable set



- Refer to Table A-4 for pin numbers to be checked.

Figure A-4 : Resolver only



- Refer to Table A-4 for pin numbers to be checked.

Table A-4 : Pin number to be checked


	Cable connector	Motor connector	Result
Phase A	⑧ ↔ ④ (REA) (COM)	① ↔ ② (REA) (COM)	
Phase B	⑦ ↔ ④ (REB) (COM)	⑥ ↔ ② (REB) (COM)	
Phase C	⑮ ↔ ④ (REC) (COM)	⑪ ↔ ② (REC) (COM)	

Table A-5 : Specification

Motor number	Resolver winding resistance (Ω)	Tolerance
YS2005	3.8	1. Allowance : ±30% 2. Variations between each phase : 1.0Ω or less (øA, øB, øC)
YS2020	3.8	
YS3008	3.7	
YS3040	3.7	
YS4080	2.8	
YS5120	2.6	
YS5240	2.6	
JS0002	2.3	
JS1003	2.6	
JS2006	3.9	
JS2014	3.8	

- For special Motor windings or long cable (over 4m), contact NSK for specification.

Figure A-5 : Resolver wiring (For your reference)



(3) Motor Windings Isolation

Caution : Disconnect Driver Unit from Motor when conducting resistance test.

Caution : Do not apply more than DC500V.

Figure A-6 : With Cable Set




Figure A-7 : Motor only




Table A-6 : Pins to be checked

	Cable connector	Motor connector	
Phase A — FG	① ↔ ⑦ (A+) (FG)	⑤ ↔ ⑬ (A+) (FG)	
Phase B — FG	③ ↔ ⑦ (B+) (FG)	⑩ ↔ ⑬ (B+) (FG)	
Phase C — FG	⑤ ↔ ⑦ (C+) (FG)	⑮ ↔ ⑬ (C+) (FG)	
Phase A — B	① ↔ ③ (A+) (B+)	⑤ ↔ ⑩ (A+) (B+)	
Phase B — C	③ ↔ ⑤ (B+) (C+)	⑩ ↔ ⑮ (B+) (C+)	
Phase C — A	⑤ ↔ ① (C+) (A+)	⑮ ↔ ⑤ (C+) (A+)	

Table A-7 : Specification (For all Motor series)

Specification
With cable : 1MΩ minimum
Motor only : 2MΩ minimum


(4) Motor and cables appearance check

- Check for Motor damage.
- Check for cracks of cables.

Appendix 3 : Initializing Driver Unit

- When troubleshooting or replacing Motor or Driver Unit, initializing Driver Unit may be necessary.
- When initializing Driver Unit, follow procedures described hereafter.
- Use Handy Terminal FHT11 for inputting command.
- Procedures

Figure A-8



Explanations

- ① Read out parameter settings and channel programs and note down them. Especially “PA” value is important.

(i) Connect the Handy Terminal FHT11 to CN1 connector of the Driver Unit and turn on the power.



(ii) Monitor the parameters with “TS0” command.



(iii) After monitoring, turn the power off.

- ② Initialize the Driver Unit.

(i) Connect the Handy Terminal FHT11 to CN1 connector of the Driver Unit.



(ii) Turn on the control power only.



(iii) Input the password. When the colon “ : ” is displayed,

Press.



(iv) The Driver Unit echoes back “NSK ON”.



(v) Input “SI/AL” command.

Press.



(vi) The Driver Unit echoes back “INITIALIZE”. A colon “ : ” will be displayed to indicate completion of initializing.

- ③ Input the noted parameter settings and channel programs.

(i) Firstly set “PA” parameter.

- Input the password.

Press.

The Driver Unit echoes back “NSK ON”.



(ii) Press

(** must be the same data as noted.)



(iii) Set other parameters and programs accordingly.



(iv) Make sure that all parameters and programs are set properly.

- Monitor the settings with “TS0” and “TC□” commands.




(v) Turn off the power.

Appendix 4 : How to replace ESA23 Driver Unit

Danger : Make sure the power is turned off when replacing ESA23 Driver Unit.

- In the reference number of ESA23 Driver Unit, second digit from the last denotes whether it is interchangeable or not.

Figure A-9



- For interchangeable (standard) ESA23 Driver Unit, replace with the Driver Unit which has same reference number. Set the same parameters to new Driver Unit.
- When replacing the Driver Unit which is not interchangeable, the compensation ROM of the old Driver Unit must be transferred to the new Driver Unit. When transferring the ROM, ESA23 Driver Unit must be disassembled. To disassemble the Driver Unit, follow the procedures described hereafter.
 - For a special Driver Unit, contact your local NSK representative.
 - Before replacing the Driver Unit, record all parameters and channel programs. The record list is provided in the last page of this manual.
 - Especially, following items shall be recorded.
 - PA, VG, VI, PG, CO, MA, MV, and HO
 - Programs and other settings in channels.
 - When replacing Driver Unit, following tools and Handy Terminal FHT11 are necessary.
 - ① A screwdriver (cross recessed, 4mm)
 - ② A ROM remover

Dissemble ESA23 Driver Unit

1. Remove side panel

Figure A-10





Figure A-11



- Remove the compensation ROM (U21) from the commutation board of old Driver Unit.
(Use a ROM remover.)

Figure A-12





Figure A-13



- Insert the ROM to new Driver Unit commutation board.

- Be careful of the orientation of the ROM. Make sure the ROM is securely set to the socket.

Figure A-14





Figure A-15



4. Assemble the side panel

Figure A-16





Figure A-17

- Fasten all screws securely



5. After replacing the compensation ROM, initialize new Driver Unit.

- ① Connect Handy Terminal FHT11 to CN1 connector.
- ② Turn on the control power only.
(Control power input ports are indicated as “CONT” on the terminal block.)
 - If the main and control power can not be turned on and off separately, disconnect CN2 connector. If CN2 connector is not disconnected, the parameters can not be input properly and the Motor may run away. (Make sure that CN2 connector is disconnected.)

- ③ When control power is turned on, Handy Terminal displays “NSK MEGATORQUE ***”.

- After the display shows a colon “:”, input

/ N S K SP O N ENT


and

S I / A L ENT

Initialization will take about 30 seconds.

- ④ After the display shows a colon “:”, log in all parameters and channel program referring the recorded value and settings.

Figure A-19



- Consult to NSK for the recommendations in other cases.

Parameter • Program Setting List

Reference No.: _____

S/N: _____

Parameter

• Black settings are factory set.

Date: _____

Parameter	Setting		Parameter	Setting		Parameter	Setting	
	Factory set	Your setting		Factory set	Your setting		Factory set	Your setting
PG	0.1		PC	0		PA	700	
VG	1.0		RR	-1		OL	*	
VI	1.0		FD	0		RC	*	
VM	1		FZ	0		LR	0	
LG	50		FR	0		TY	1	
TL	100		PS	1		AB	X0X0XX00	
FO	0		DI	0		SM	1	
FP	0		OTP	0		NW	2	
FS	0		OTM	0		MM	1	
NP	0		MV	1		BM	1	
DBP	0		MA	1		CM	0	
ILV	100		JV	0.1		AN	0	
FF	0		JA	1		LO	0	
FC	0		HV	0.2		SG	0	
CO	50000		HA	1		MT	*	
IN	100		HZ	0.01		RI	*	
IS	0		OS	4		ZP	1.00	
FW	1		HD	1		ZV	1.4	
CR	X1		HO	0				

(*: Setting differs with Motor size.)

Channel Program

• For channels not in use, leave in blank.

Date: _____

CH	Program	CH	Program	CH	Program	CH	Program
0	Command: CV: CA:	4	Command: CV: CA:	8	Command: CV: CA:	12	Command: CV: CA:
1	Command: CV: CA:	5	Command: CV: CA:	9	Command: CV: CA:	13	Command: CV: CA:
2	Command: CV: CA:	6	Command: CV: CA:	10	Command: CV: CA:	14	Command: CV: CA:
3	Command: CV: CA:	7	Command: CV: CA:	11	Command: CV: CA:	15	Command: CV: CA:

World-wide Manufacturing and Marketing Organization

NSK Ltd. INTERNATIONAL DIVISION

JAPAN: Tokyo Phone: 03-3779-7120

NSK CORPORATION

U.S.A.: Ann Arbor Phone: 313-761-9500

[Precision Products Business Unit]

U.S.A. : Chicago Phone: 630-924-8000

: Los Angeles Phone: 562-926-3578

: Ann Arbor Phone: 761-761-9500

NSK-RHP CANADA INC.

CANADA : Toront Phone: 905-890-0740

: Montreal Phone: 514-633-1240

: Vancouver Phone: 800-663-5445

NSK RODAMIENTOS MEXICANA, S.A. DE C.V.

MEXICO: Mexico City Phone: 5-301-2741,5-301-3115

NSK DO BRASIL INDUSTRIA E COMÉRCIO DE ROLAMENTOS LTDA.

BRASIL : São Paulo Phone: 001-269-4700

: Porto Alegre Phone: 051-222-1324

: Belo Horizonte Phone: 031-224-2508

NSK-RHP UK LTD

ENGLAND : Ruddington Phone: 0115-936-6600

NSK-RHP DEUTSCHLAND G.m.b.H

GERMANY : Düsseldorf Phone: 02102-4810

: Stuttgart Phone: 0711-79082-0

: Leipzig Phone: 0341-5631241

NSK-RHP FRANCE S.A.

FRANCE : Paris Phone:1.30.57.39.39

: Lyon Phone: 72.15.29.00

NSK-RHP NEDERLAND B.V.

NETHERLAND: Amsterdam Phone: 020-6470711

NSK-RHP ITALIA S.p.A.

ITALIA: Milano Phone: 02-995191

NSK-RHP IBERICA, S.A.

SPAIN: Barcelona Phone: 93-575-1662

NSK-RHP AUSTRALIA PTY, LTD.

AUSTRALIA : Melbourne Phone: 03-9764-8302

: Sydney Phone: 02-9893-8322

: Brisbane Phone: 07-3393-1388

: Adelaide Phone: 08-8373-4811

: Perth Phone: 089-434-1311

NSK-RHP BEARINGS NEW ZEALAND LTD.

NEW ZEALAND: Auckland Phone: 09-276-4992

NSK KOREA CO., LTD.

KOREA: Seoul Phone: 02-3287-6001

NSK SINGAPORE (PRIVATE) LTD.

SINGAPORE: Singapore Phone: 2781711

NSK BEARINGS (THAILAND) CO., LTD.

THAILAND : Bangkok Phone: 2-6412150-60

: Chiang mai Phone: 053-246993-4

TAIWAN NSK PRECISION CO., LTD.

TAIWAN: Taipei Phone: 02-591-0656

MEGATORQUE® MOTOR SYSTEM

User's Manual (ESA23 Driver Unit System)

Document Number: C20053-06

March 22, 1996

2nd Edition 1st Printing

September 17, 1997

3rd Edition 1st Printing

July 6, 1998

4th Edition 1st Printing

August 23, 1999

5th Edition 1st Printing

September 28, 1999

6th Edition 1st Printing

April 10, 2000

6th Edition 2nd Printing

NSK Ltd.

NSK